

Winthrop, Shelby

To: Lee, Weston
Subject: RE: Leachate pump operations manual

From: Lee, Weston
Sent: Wednesday, March 14, 2018 4:13 PM
To: Winthrop, Shelby
Cc: McWilliams, Clark; Reynolds, Benjamin; Zweifel, Jarrod
Subject: Leachate pump operations manual

Shelby,

Could you put this into the SW database for permit number 0249-S1-R2 AFIN 03-00051

<S:\Facilities\AFIN-01 to 25\03-00051 Nabors Landfill\NABORS Closure AFT Work.pdf>

Thank you,
-Wes

Rec'd Digitally	
AFIN: 03-00051	S W M D
PMT#: 0249-S1-R2	
<div>RECEIVED By Shelby Winthrop at 4:30 pm, Mar 14, 2018</div>	
DOC ID#: 73348	
TO: AC>File <SW	



Project Manual – Specification
Closure of Inactive N.A.B.O.R.S. Landfill
1320 Landfill Road, Mountain Home, Arkansas 72653
Project Number 930160R

Prepared For:
Kolb Grading, LLC
5731 Westwood
St. Charles, MO 63304

Prepared By:
Advanced Fluid Technologies, Inc.
7801 Warden Road
Sherwood, AR 72120

INDEX

- Control Panels and Supporting Documents
- Fiberglass Tanks
- Concrete Containment and Vent Vaults
- Pumps and Motors
- High Density Poly Pipe and Fittings
- Heat trace and Insulation
- Field Records
- Force Main Leak Test Records



Leachate Collection System

Operators & Troubleshooting Guide

Equipment ID	Description	JOB#	Stock#
LCS1 – LCS 9	Control Panel	93041601R	AFT612001

Rev	Rev Date	Description of Change	Revised By
1	8/29/17	Original Document	M. Rankins

7801 Warden Road * Sherwood, AR 72120
Phone: (501) 835-3200 Fax: (501) 835-3251
<mailto:sales@advancedfluidtech.com>

FORWARD

The design, material, and workmanship incorporated in the construction of Leachate Collection Systems makes them capable of giving long, trouble-free service. The life and satisfactory service of any system, however, is enhanced and extended by correct application, proper installation, periodic inspection and careful maintenance. This instruction manual was prepared to assist operators in understanding the construction and the correct methods of operating and maintaining this system.

TABLE OF CONTENTS

SECTION 1 – INSTALLATION	PAGE
I-A Description of system	2
I-B Uncrating & Inventorying Component/Kits	3
I-C Determining System Location	3
SECTION II – PREPRATION FOR OPERATION	
II-A Initializing Power	4
II-B Checking voltage and phase	4
II-C Documentation	4
SECTION III – OPERATION	
III-A Starting the Pump	5
III-B Initial Inspection after Startup	5
SECTION IV – CARE AND MAINTENANCE	
IV-A Inspections	6
SECTION V – TROUBLE CHECK LIST	
V-A Pump Not Working or Pumping	7
V-B No power	7
V-C Lights not Flashing	7
SECTION V1 – RECOMMENDED SPARE PARTS	
V1-A Spare parts for every 10 Systems.....	8
SECTION V11 – FIGURES	
V11-Fig 1 Installation Record at Startup.....	9
V11-Fig 2 Drawing WM-1A-1.....	11
V11-Fig 3 Drawing WM-1A-2.....	12
V11-Fig 3 Drawing WM-1A-3.....	13
V11-Fig 3 Drawing WM-1A-4.....	14

SECTION 1 – INSTALLATION

1-A Description of system

Furnish one AFT Simplex Control Panel to operate a pump motor and auxiliary equipment in manual or automatic mode. This control panel enclosure shall be NEMA type 4x.

The enclosure shall be equipped with a window in the outer door, an inner door, and a tamper resistant latch. The NEMA type 4x enclosure will be white powder coated stainless steel.

The control system will operate from a 230 Volt, 60 Hertz, single phase power supply. Pump control components will be sized to operate a pump motor of specified horsepower.

UL Listed, UL 508A Industrial Control Panels.

The control panel shall include the following as standard features:

Main Disconnect Breaker: The main disconnect breaker shall be 20 Amp rated.

“Hand-Off-Auto” Selector Switch: Allows manual or automatic operation of the pump motor. The selector switch shall be a heavy duty, oil tight, NEMA 4 rated switch mounted on the inner door.

Variable Frequency Drive: The variable frequency drive shall be sized to safely operate pumps ranging from 0.25 to 3 horsepower.

Control Transformer: A transformer shall be installed to provide for easier and safer field wiring of accessories. It shall lower incoming voltage to 24 Volts.

Identification Strobes: Three strobe lights will be mounted directly on top of the control panel. Green strobe shall indicate that the pump is running. Red light shall indicate that the liquid level is above point of compliance. Amber light shall indicate a failure of a component in the control panel.

Level Simulator: The level simulator shall be mounted on the inner door. The level simulator is a built-in test circuit designed to simulate a 4-20mA load to assist in level meter setup and troubleshooting.

Surge Arrester: Shall be grounded, metal-to-metal. When properly grounded, the surge arrester will protect electrical equipment against all electrical surges. An additional surge arrester shall be installed for additional protection specifically for the submersible pressure transmitter.

Terminal Strip: A labeled and numbered terminal strip provides easy connection of external components.

Corrosion Inhibitor Emitter: Inclusion of an industrial corrosion inhibitor emitter shall protect internal components of control panel from corrosion for up to one year and shall be replaceable.

Other options are available to meet specific needs.

System Logic and Function

The controller is designed to start and stop a pump using a programmable logic controller with a submersible pressure transmitter. The pump starts at the pump start level set point and continues to run until the liquid level decreases to the pump stop level set point as programmed in the logic controller. If the liquid level rises to the high level alarm set point, the red strobe beacon will begin flashing. If the liquid level rises to the high-high level fail-safe set point, the pump motor will shut off. The pressure transmitter level sensor shall have a range of 0 to 23.1 feet with a 4-20 mA output signal.

I-C Uncrating & inspecting Panels

- Remove plastic wrapping
- Check for dents, scratches, broken lights, ect..

I-D Determining System Location

- There are two types of mounting the panel, directly to the headwall or free standing.
- If mounting to the headwall, vapor/gas seal-offs must be used to prevent landfill gas from entering the cabinet.
- If mount free standing , it is recommended that the panel be a minimum of 10 feet from the raiser pipe


I-D Wiring up the control panel from a commercial source.

- All connections should be performed by a licensed electrician or trained service person.




**Hazardous voltages exist within enclosure.
Service should be performed only by trained
service personnel.**

Power Distribution Bus



Terminal Block -1




SECTION II – PREPRATION FOR OPERATION

II-A Preparation for power-up

- Ensure all power connection are tight.
- Ensure all breakers are in the off position
- Turn on power to the control panel, record readings on **Installation Record at Startup (Fig 1)**.
- Follow the steps on **Installation Record at Startup**

II-B Set operating parameters.

Control Panel Operations



To Change A Setpoint

- Scroll to the screen you wish to change
- Press the **MOD** button
- Then the **Increase** or **Decrease** till the desired value is reached
- Then press **Enter** to finish

- | | |
|--------------------------|--------------|
| 1 = Level | |
| 2 = Pump On Setpoint | |
| 3 = Pump Off Setpoint | |
| 4 = POC Set Point | |
| 5 = Low level Setpoint | |
| 6 = Sensor Fail Setpoint | |
| 7 = XDucer Select | 1 = 0-5 PSI |
| 8 = Total Run Hours | 2 = 0-10 PSI |
| 9 = 24 Hr Run time | 3 = 0-15 PSI |
| 10= Alarms | |

SECTION III – OPERATION

III-A Starting the Pump

- Place the pump HAND/OFF/AUTO selector switch in the AUTO position, Pumping system is now in operation.


III-B Initial Inspection after Startup

- After 30 minutes of operation, check to see if level is dropping. If yes place system in a schedule maintenance program. If not, see trouble shooting

SECTION IV – CARE AND MAINTENANCE

IV-A Inspections:

- Quarterly
 - o Run simulation test to see if strobes flash, pump starts and stops at the proper set points
 - o Use to Test Set Points instructions below.
- Annual Inspections
 - o Check all quarterly inspection items
 - o Check panel for damage, Rust, loose connections, broken lights, ect.)



TO TEST SETPOINTS

- Turn and hold switch in **TEST** position
- Press the **UP/DN** button to simulate level Changes
- When complete the switch should return to **RUN** automatically

SECTION V – TROUBLE CHECK LIST

V-A Pump not working or pumping

Cause	Possible Solution
Selector switch	Must be placed in either Hand or Auto
Tank Inter-lock	Tank full, empty tank
Low level Alarm	Make sure the sump has liquid
Pump Fault	Check wiring drive to motor, Meg Motor, motor should have a minimum of 5 MΩ Replace motor Replace drive

V-B Pump running with no liquid

Cause	Possible Solution
Low level	Low level setting set to low
4-20 ma	4-20ma level signal bad, replace level probe
Pump plugged or bad	Clean or replace pump

V-B Lights not flashing

Cause	Possible Solution
Strobe Bunt-out	Replace strobe, see replacement parts for Part# Replace strobe unit, see replacement parts for Part #

V1--Recommended Spare Parts

V1-A Recommended Spare Parts needed every 10 systems.

Item #	AFT Part #	Description	QTY Needed	UOM
1	341007	Franklin 4" Submersible Motor, 0.5HP, 230V 2w, Single Phase, STD WW	1	EA
2	301003	4" Submersible Pump Head, 25gpm, 316ss	1	EA
3	611011	Acculevel/81335/10 PSIG/mA+RS485/150'PE Cable OP13/0.25%	1	EA
4	611025	Altivar, VFD 3 HP, 230 v Single Phase to 230 v Three phase	1	EA
5	631001	Flash Tube Assembly (Strobe Light Replacement Bulb)	2	EA
6	631008	Strobe Light, Low Profile, 120 volts, Pipe mount full assembly	1	EA

SECTION V11 – Figures

Figure 1

Installation Record at Startup

Project Job Number _____ Startup Date: _____

Installer's Name _____

Sump ID _____ Choose an item. Choose an item.

Side Slope Information:

Vertical Information:

Slope __:1

Riser Diameter _____ Inches

Sump Diameter _____ Inches

Riser Length _____ Feet

Sump Depth _____ Feet

Vertical Depth _____ Feet

Pump & Motor Information:

Mfg _____ Model # _____ S/N _____

GPM _____ @ _____ Ft. TDH

Motor Mfg _____ Model _____ S/N _____

Hp _____ Voltage _____ Phase _____ FLA _____

Motor Cable # of Conductors _____ Wire Size AWG _____ Length _____

Power Service Supply:

Breaker Size _____ Wire Size AWG _____ Length _____

Incoming Voltage;

No Load L1-L2 _____ L2-L3 _____ L1-L3 _____ % Unbalance _____

Full Load L1-L2 _____ L2-L3 _____ L1-L3 _____

Full Load Amps L1 _____ L2 _____ L3 _____ % Unbalanced _____

Motor Run Amps: L1 _____ L2 _____ L3 _____ % Unbalanced _____

Xducer/Float Information:

Xducer Mfg _____ Serial # _____ PSI Rating _____

Float Mfg _____ Float 1 NO – NC (Circle One) Float 2 NO – NC (Circle One) Float 3 NO - NC (Circle One)

Control Panel:

MFG _____ Model # _____ Serial # _____

Panel Style _____ Simplex/Duplex/Lead Lag (Circle One)

Set Points:

Pump On _____ Pump Off _____ POC _____

Low Level _____ Sensor Fail _____ Xducer _____

VFD Set Hz _____ Motor Starter Overload Setting _____

Float 1 _____ Inches Float 2 _____ Inches Float 3 _____ Inches

How to figure 3 Phase Unbalance % (Same For Volts)


EXAMPLE:

$$\begin{array}{r} T1 = 51 \text{ amps} \\ T2 = 46 \text{ amps} \\ + T3 = 53 \text{ amps} \\ \hline \text{Total} = 150 \text{ amps} \end{array}$$

$$\frac{150}{3} = 50 \text{ amps}$$

$$50 - 46 = 4 \text{ amps}$$

$$\frac{4}{50} = 0.08 \text{ or } 8\%$$




ABOVE POC = FLASHING RED BEACON
ALARMS /FAULT = FLASHING AMBER BEACON
PUMP RUNNING = FLASHING GREEN BEACON

	MFE	DISPLAY
POINT OF COMPLIANCE	=	_____
PUMP ON SETPOINT	=	_____
BOTTOM OF LINER	=	_____
PUMP OFF SETPOINT	=	_____
LOW LEVEL ALARM	=	_____
BOTTOM OF SUMP	=	_____

OPERATOR CONTROL

LEVEL is in INCHES
FLOW is in GPM




SCREEN SEQUENCE

- 1 = LEVEL & FLOW
- 2 = PUMP ON SETPOINT
- 3 = PUMP OFF SETPOINT
- 4 = POC HIGH SETPOINT
- 5 = POC LOW SETPOINT
- 6 = SENSOR FAIL
- 7 = XDUCER SELECT
- 8 = ETM / DC
- 10 = ALARMS

CHANGE VALUE
INCREASE VALUE
DECREASE VALUE

- 1 = 0-5 psi
2 = 0-10 psi
3 = 0-15 psi




TO TEST SETPOINTS

TURN AND HOLD SWITCH IN TEST POS.
PRESS THE UP / DN BUTTONS TO SIMULATE LEVEL CHANGES

TO CHANGE A SETPOINT

SCROLL TO THE SCREEN YOU WISH TO CHANGE-
PRESS THE MOD BUTTON, THEN THE INCREASE OR
DECREASE BUTTONS TILL THE DESIRED VALUE IS
REACHED - THEN PRESS ENTER TO FINISH



Advanced Fluid Technologies

WM-1A

SHERWOOD, AZ 531-835-3200
EXTEMP_AFT_2.JPG

SIZE

Filename

WM_1A_1

DWG NO.

10350

REV


DATE 2/16/2012

DRAWN BY: TLI

SCALE

SHEET

1 of 4




ABOVE POC = FLASHING RED BEACON

ALARMS / FAULT = FLASHING AMBER BEACON

PUMP RUNNING = FLASHING GREEN BEACON

	MFE	DISPLAY
POINT OF COMPLIANCE	=	_____
PUMP ON SETPOINT	=	_____
BOTTOM OF LINER	=	_____
PUMP OFF SETPOINT	=	_____
LOW LEVEL ALARM	=	_____
BOTTOM OF SUMP	=	_____

OPERATOR CONTROL




TO CHANGE A SETPOINT

SCROLL TO THE SCREEN YOU WISH TO CHANGE-
PRESS THE MOD BUTTON, THEN THE INCREASE OR
DECREASE BUTTONS TILL THE DESIRED VALUE IS
REACHED - THEN PRESS ENTER TO FINISH


SCREEN SEQUENCE

- 1 = LEVEL & FLOW
- 2 = PUMP ON SETPOINT
- 3 = PUMP OFF SETPOINT
- 4 = POC HIGH SETPOINT
- 5 = POC LOW SETPOINT
- 6 = SENSOR FAIL
- 7 = XDUCER SELECT ————
 - 1 = 0-5 psi
 - 2 = 0-10 psi
 - 3 = 0-15 psi
- 8 = ETM / DC
- 10 = ALARMS



TO TEST SETPOINTS

TURN AND HOLD SWITCH IN TEST POS.
PRESS THE UP / DN BUTTONS TO SIMULATE LEVEL
CHANGES



CONNECTION DETAIL TB-1





QUICK TROUBLESHOOTING GUIDE

For the Pump to run you MUST HAVE :

- HOA in AUTO or HAND
- a Pump Call (Output #2 on the PLC)
- No Faults
- the Low Level Alarm must be Clear
- and the Interlock Input must be Connected

IF	LOOK FOR
NO Pump Call-----	Interlock Missing 4-20 ma Level Signal Missing or Bad Pump Fault
Pump Fault-----	Fault Line from Drive (input #2 on PLC) Check wiring from Drive to Motor Check Drive Settings - if correct, Replace Drive

REVISIONS				
ZONE	REV	DESCRIPTION	DATE	APPROVED



CONNECTION DETAIL TB-1

E:\Temp\AFT_2.JPG

Advanced Fluid Technologies
SHERWOOD, AR. 531-835-3200

WM-1A ENCLOSURE LAYOUT

SIZE

FSCM NO.

DWG NO.

REV

A

WM_1A_4

10350

SCALE

SHEET 4 of 4

Technical Characteristics

Ampere Rating	10A
Application	Variable & Constant
Conformal Coating	Yes
Embedded Communication	Modbus
Heatsink	Yes
Enclosure Rating	Open
Degree of Protection	IP20
Horsepower Rating	3HP
Motor Power Rating	2.2kW
Input Voltage	230Vac
Marketing Trade Name	Altivar 12
Output Voltage	230Vac
Input Phase	1-Phase
Output Phase	3-Phase
Type	ATV12

Shipping and Ordering

Category	22042 -
Discount Schedule	CP4B
GTIN	00785901897491
Package Quantity	1
Weight	4.31 lbs.
Availability Code	Stock Item: This item is normally stocked in our distribution facility.
Returnability	Y
Country of Origin	ID

document.

Altivar 312

Variable speed drives
for asynchronous motors

Programming manual

07/2014



The information provided in this documentation contains general descriptions and/or technical characteristics of the performance of the products contained herein. This documentation is not intended as a substitute for and is not to be used for determining suitability or reliability of these products for specific user applications. It is the duty of any such user or integrator to perform the appropriate and complete risk analysis, evaluation, and testing of the products with respect to the relevant specific application or use thereof. Neither Schneider Electric nor any of its affiliates or subsidiaries shall be responsible or liable for misuse of the information contained herein. If you have any suggestions for improvements or amendments or have found errors in this publication, please notify us.

No part of this document may be reproduced in any form or by any means, electronic, or mechanical, including photocopying, without express written permission of Schneider Electric.

All pertinent state, regional, and local safety regulations must be observed when installing and using this product. For reasons of safety and to help ensure compliance with documented system data, only the manufacturer should perform repairs to components.

When devices are used for applications with technical safety requirements, the relevant instructions must be followed.

Failure to use Schneider Electric software or approved software with our hardware products may result in injury, harm, or improper operating results.

Failure to observe this information can result in injury or equipment damage.

© 2013 Schneider Electric. All rights reserved.

Contents

Important information	4
Before you begin	5
Documentation structure	7
Software enhancements	8
Steps for setting up the drive	9
Setup - Preliminary Recommendations	10
Factory configuration	11
Basic functions	12
Remote display terminal option, ATV31	14
Remote graphic display terminal option, ATV61/ATV71	15
Remote display terminal option, ATV12	19
Structure of the parameter tables	20
Compatibility of functions	21
List of functions that can be assigned to inputs/outputs	23
List of functions that can be assigned to the Network and Modbus control word bits	25
Checklist	26
Programming	27
[SPEED REFERENCE] (rEF-) menu	31
[SETTINGS] (SEt-) menu	32
[MOTOR CONTROL] (drC-) menu	41
[INPUTS / OUTPUTS CFG] (I-O-) menu	47
[COMMAND] (CtL-) menu	50
[COMMAND] (CtL-) menu	61
[APPLICATION FUNCT.] (FUn-) menu	62
[FAULT MANAGEMENT] (FLt-) menu	91
[COMMUNICATION] (COM-) menu	98
[MONITORING] (SUP-) menu	100
Migration ATV31 - ATV312	105
Diagnostics and troubleshooting	106
Index of functions	111
Index of parameter codes and customer settings	112

Important information

NOTICE

Read these instructions carefully, and look at the equipment to become familiar with the device before trying to install, operate, or maintain it. The following special messages may appear throughout this documentation or on the equipment to warn of potential hazards or to call attention to information that clarifies or simplifies a procedure.



The addition of this symbol to a Danger or Warning safety label indicates that an electrical hazard exists, which will result in personal injury if the instructions are not followed.



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

DANGER

DANGER indicates an imminently hazardous situation which, if not avoided, will result in death, serious injury or equipment damage.

WARNING

WARNING indicates a potentially hazardous situation which, if not avoided, can result in death, serious injury or equipment damage.

CAUTION

CAUTION indicates a potentially hazardous situation which, if not avoided, can result in injury or equipment damage.

CAUTION

CAUTION, used without the safety alert symbol, indicates a potentially hazardous situation which, if not avoided, can result in equipment damage.

PLEASE NOTE

The word "drive" as used in this manual refers to the "controller portion" of the adjustable speed drive as defined by NEC.

Electrical equipment should be installed, operated, serviced, and maintained only by qualified personnel. No responsibility is assumed by Schneider Electric for any consequences arising out of the use of this documentation.

© 2013 Schneider Electric. All rights reserved.

Before you begin

Read and understand these instructions before performing any procedure with this drive.

DANGER

HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH

- Only appropriately trained persons who are familiar with and understand the contents of this manual and all other pertinent product documentation and who have received safety training to recognize and avoid hazards involved are authorized to work on and with this drive system. Installation, adjustment, repair and maintenance must be performed by qualified personnel.
- The system integrator is responsible for compliance with all local and national electrical code requirements as well as all other applicable regulations with respect to grounding of all equipment.
- Many components of the product, including the printed circuit boards, operate with mains voltage. Do not touch. Use only electrically insulated tools.
- Do not touch unshielded components or terminals with voltage present.
- Motors can generate voltage when the shaft is rotated. Prior to performing any type of work on the drive system, block the motor shaft to prevent rotation.
- AC voltage can couple voltage to unused conductors in the motor cable. Insulate both ends of unused conductors of the motor cable.
- Do not short across the DC bus terminals or the DC bus capacitors or the braking resistor terminals.
- Before performing work on the drive system:
 - Disconnect all power, including external control power that may be present.
 - Place a "Do Not Turn On" label on all power switches.
 - Lock all power switches in the open position.
 - Wait 15 minutes to allow the DC bus capacitors to discharge. The DC bus LED is not an indicator of the absence of DC bus voltage that can exceed 800 Vdc.
 - Measure the voltage on the DC bus between the DC bus terminals using a properly rated voltmeter to verify that the voltage is < 42 Vdc.
 - If the DC bus capacitors do not discharge properly, contact your local Schneider Electric representative.
- Install and close all covers before applying voltage.

Failure to follow these instructions will result in death or serious injury.

DANGER

UNINTENDED EQUIPMENT OPERATION

- Read and understand this manual before installing or operating the Altivar 312 drive.
- Any changes made to the parameter settings must be performed by qualified personnel.

Failure to follow these instructions will result in death or serious injury.

WARNING

DAMAGED EQUIPMENT

Do not install or operate any drive that appears damaged.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

WARNING

LOSS OF CONTROL

- The designer of any control scheme must consider the potential failure modes of control paths and, for critical control functions, provide a means to achieve a safe state during and after a path failure. Examples of critical control functions are emergency stop, overtravel stop, power outage, and restart.
- Separate or redundant control paths must be provided for critical control functions.
- System control paths may include communication links. Consideration must be given to the implications of unanticipated transmission delays or failures of the link.
- Observe all accident prevention regulations and local safety guidelines.^a
- Each implementation of the product must be individually and thoroughly tested for proper operation before being placed into service.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

a. For USA: Additional information, refer to NEMA ICS 1.1 (latest edition), "Safety Guidelines for the Application, Installation, and Maintenance of Solid State Control" and to NEMA ICS 7.1 (latest edition), "Safety Standards for Construction and Guide for Selection, Installation and Operation of Adjustable Speed Drive Systems."

Documentation structure

The following Altivar 312 technical documents are available on the Schneider Electric website (www.schneider-electric.com).

Installation Manual

This manual describes how to install and connect the drive.

Programming manual

This manual describes the functions and parameters of the drive's terminals and how to use them.

Quick Start

This document describes how to connect and configure the drive so that the motor can be started both quickly and easily for basic applications. This document is supplied with the drive.

Manuals for Modbus[®], CANopen[®], etc.

These manuals describe the installation process, the bus or network connections, signaling, diagnostics and the configuration of parameters specific to communication.

They also describe the communication services of the protocols.

Software enhancements

Since it was first marketed, the Altivar ATV 312 has been equipped with additional functions. Software version V5.1 IE 50 has now been updated to V5.1 IE 54. This documentation relates to version V5.1 IE 54.
The software version appears on the rating plate attached to the side of the drive.

Enhancements made to version V5.1 IE 54 in comparison to V5.1 IE 50

New possible configuration

- Local configuration : By pressing the MODE button during 3 seconds, the drive switches automatically to Local configuration. The embedded Jog Dial works as a potentiometer (Fr1 = AIV1) and embedded RUN button is activated.
- Remote configuration : This is the factory configuration.

INSTALLATION

1. Please refer to the Installation Manual.

PROGRAMMING



Tips:

- Before beginning programming, complete the customer setting tables, page [112](#).
- Use the [\[Restore config.\] \(FCS\)](#) parameter, page [46](#), to return to the factory settings at any time.
- To locate the description of a function quickly, use the index of functions on page [111](#).
- Before configuring a function, read carefully the "Function compatibility" section on pages [21](#) and [22](#).
- **Note:**
The following operations must be performed for optimum drive performance in terms of accuracy and response time:
 - Enter the values indicated on the (motor) rating plate in the [\[MOTOR CONTROL\] \(drC-\)](#) menu, page [41](#).
 - Perform auto-tuning with the motor cold and connected using the [\[Auto-tuning\] \(tun\)](#) parameter, page [43](#).
 - Adjust the [\[FreqLoopGain\] \(FLG\)](#) parameter, page [33](#) and the [\[Fr.Loop.Stab\] \(StA\)](#) parameter, page [34](#).

2. Apply input power to the drive, but do not give a run command.

3. Configure:

- The nominal frequency of the motor [\[Standard mot. freq\] \(bFr\)](#) page [41](#) if this is not 50 Hz,
- The motor parameters in the [\[MOTOR CONTROL\] \(drC-\)](#) menu, page [41](#), only if the factory configuration of the drive is not suitable,
- The application functions in the [\[INPUTS / OUTPUTS CFG\] \(I-O-\)](#) menu, page [47](#), the [\[COMMAND\] \(CtL-\)](#) menu, page [50](#), and the [\[APPLICATION FUNCT.\] \(FUn-\)](#) menu, page [62](#), only if the factory configuration of the drive is not suitable.

4. In the [\[SETTINGS\] \(SEt-\)](#) menu, adjust the following parameters:

- [\[Acceleration\] \(ACC\)](#), page [32](#) and [\[Deceleration\], \(dEC\)](#) page [32](#),
- [\[Low speed\] \(LSP\)](#), page [33](#) and [\[High speed\] \(HSP\)](#), page [33](#),
- [\[Mot. therm. current\] \(ItH\)](#), page [33](#).

5. Start the drive.

Setup - Preliminary Recommendations

Before powering up the drive

⚠ DANGER

UNINTENDED EQUIPMENT OPERATION

Make sure that all logic inputs are inactive to avoid any unintended operation.

Failure to follow these instructions will result in death or serious injury.

Before configuring the drive

⚠ DANGER

UNINTENDED EQUIPMENT OPERATION

- Read and understand this manual before installing or operating the ATV312 drive.
- Any changes made to the parameter settings must be performed by qualified personnel.
- Make sure that all logic inputs are inactive to avoid any unintended operation when parameters are being changed.

Failure to follow these instructions will result in death or serious injury.

Start-up

Note: When factory settings apply and during power-up/manual reset or after a stop command, the motor can only be powered once the "forward", "reverse" and "DC injection stop" commands have been reset. If they have not been reset, the drive will display [Freewheel stop] (nSt) but will not start. If the automatic restart function has been configured ([Automatic restart] (Atr) parameter in the [FAULT MANAGEMENT] (FLt-) menu, page 91), these commands are taken into account without a reset (to zero) being necessary.

Line contactor

CAUTION

RISK OF DAMAGE TO DRIVE

- Frequent use of the contactor will cause premature ageing of the filter capacitors.
- Do not have cycle times less than 60 seconds.

Failure to follow these instructions can result in equipment damage.

Using a motor with a lower rating or dispensing with a motor altogether

- With the factory settings, motor output phase loss detection is active ([Output Phase Loss] (OPL) = [YES] (YES), page 94). To avoid having to use a motor with the same rating as the drive when testing the drive or during a maintenance phase, deactivate motor output phase loss detection ([Output Phase Loss] (OPL) = [No] (nO)). This can prove particularly useful if very powerful drives are being used.
- Set the [U/F mot 1 selected] (UFt) parameter, page 44, on [Cst. torque] (L) in the [MOTOR CONTROL] (drC-) menu.

CAUTION

RISK OF DAMAGE TO MOTOR

Motor thermal protection will not be provided by the drive if the motor's nominal current is 20% lower than that of the drive. Find an alternative source of thermal protection.

Failure to follow these instructions can result in equipment damage.

Factory configuration

Factory settings

The Altivar 312 is factory-set for the most common operating conditions:

- Display: drive ready **[Ready] (rdY)** with motor stopped, and motor frequency with motor running.
- The LI5 and LI6 and logic inputs, AI3 analog input, AOC analog output, and R2 relay are unaffected.
- Stop mode when fault detected: freewheel

Code	Description	Value	Page
b F r	[Standard mot. freq]	[50Hz IEC]	41
l l l	[2/3 wire control]	[2 wire] (2C) : 2-wire control	30
u F l	[U/F mot 1 selected]	[SVC] (n) : Sensorless flux vector control for constant torque applications	44
A l l d e l	[Acceleration] [Deceleration]	3.00 seconds	63
L S P	[Low speed]	0 Hz	33
H S P	[High speed]	50 Hz	33
i t h	[Mot. therm. current]	Nominal motor current (value depending on drive rating)	33
S d c l	[Auto DC inj. level 1]	0.7 x nominal drive current, for 0.5 seconds	35
S F r	[Switching freq.]	4 kHz	40
r r 5	[Reverse assign.]	[LI2] (LI2) : Logic input LI2	48
P S 2	[2 preset speeds]	[LI3] (LI3) : Logic input LI3	72
P S 4	[4 preset speeds]	[LI4] (LI4) : Logic input LI4	72
F r 1	[Ref.1 channel]	[AI1] (AI1) - Analog input AI1	29
S A 2	[Summing ref. 2]	[AI2] (AI2) - Analog input AI2	70
r l	[R1 Assignment]	[No drive flt] (FLt) : The contact opens when a fault is detected or when the drive has been switched off	49
b r A	[Dec ramp adapt.]	[Yes] (YES) : Function active (automatic adaptation of deceleration ramp)	64
A l r	[Automatic restart]	[No] (nO) : Function inactive	91
S t l	[Type of stop]	[Ramp stop] (rMP) : On ramp	65
C F G	[Macro configuration]	[Factory set.] (Std) (1)	45

Check whether the values above are compatible with the application. If necessary, the drive can be used without changing the settings.

(1) If you want to keep the drive's presettings to a minimum, select the macro configuration **[Macro configuration] (CFG) = [Start/stop] (StS)** followed by **[Restore config.] (FCS) = [Factory Set.] (InI)** (page [46](#)).

The **[Start/stop] (StS)** macro configuration is the same as the factory configuration, apart from the I/O assignment:

- Logic inputs:
 - LI1, LI2 (reversing): 2-wire transition detection control, LI1 = run forward, LI2 = run reverse.
 - LI3 to LI6: Inactive (not assigned).
- Analog inputs:
 - AI1: Speed reference 0-10 V.
 - AI2, AI3: Inactive (not assigned).
- Relay R1: The contact opens in the event of a detected fault (or drive off).
- Relay R2: Inactive (not assigned).
- Analog output AOC: 0-20 mA, inactive (not assigned).


Drive thermal protection

Functions:

Thermal protection by PTC probe fitted on the heatsink or integrated in the power module.

Indirect protection of the drive against overloads by tripping in the event of an overcurrent. Typical tripping values:

- Motor current = 185% of nominal drive current: 2 seconds
- Motor current = 150% of nominal drive current: 60 seconds



Drive ventilation

The fan starts up when the drive is powered up then shuts down after 10 seconds if a run command has not been received.

The fan is powered automatically when the drive is unlocked (direction of operation + reference). It is powered down a few seconds after the drive is locked (motor speed < 0.2 Hz and injection braking completed).


Basic functions

Motor thermal protection

Function:

Thermal protection by calculating the I^2t .

The protection takes account of self-cooled motors.



CAUTION

RISK OF DAMAGE TO MOTOR

External protection against overloads is required under the following circumstances:

- When the product is being switched on again, as there is no memory to record the motor thermal state
- When supplying more than one motor
- When supplying motors with ratings less than 0.2 times the nominal drive current
- When using motor switching


Failure to follow these instructions can result in equipment damage.

Remote display terminal option, ATV31

This terminal is a local control unit which can be mounted on the door of the wall-mounted or floor-standing enclosure. It has a cable with connectors, which is connected to the drive serial link (see the manual supplied with the terminal). Its display capabilities are practically identical to those of the Altivar 312. With this terminal, however, up and down arrows are used for navigation rather than a jog dial. There is also an access locking switch for the menus. There are three buttons for controlling the drive (1):

- FWD/REV: Reversal of the direction of rotation
- RUN: Motor run command
- STOP/RESET: Motor stop command or reset

Pressing the button a first time stops the motor, and if DC injection standstill braking is configured, pressing it a second time stops this braking.



Note: Protection via customer confidential code has priority over the switch.

Note:

- The remote terminal access locking switch also locks access by the drive keys.
- When the remote display terminal is disconnected, any locking remains active for the drive keys.
- The remote display terminal will only be active if the [Modbus baud rate] (tbr) parameter in the [COMMUNICATION] (COM-) menu, page 98, still has its factory setting: [19.2 Kbps] (19.2).

(1) To activate the buttons on the remote display terminal, you first have to configure [HMI command] (LCC) = [Yes] (YES), page 61.

Saving and loading configurations

Up to four complete configurations for ATV312 drives without an option card can be stored on the remote display terminal. These configurations can be saved, transported and transferred from one drive to another of the same rating. 4 different operations for the same device can also be stored on the terminal.

See the [Saving config.] (SCS) and [Restore config.] (FCS) parameters in the [MOTOR CONTROL] (drC-) menu, pages 45 and 46, the [INPUTS / OUTPUTS CFG] (I-O-) menu, pages 49 and 49, the [COMMAND] (CtL-) menu, pages 61 and 61, and the [APPLICATION FUNCT.] (FUn-) menu, pages 90 and 90.

To transfer a configuration between an ATV31 and an ATV32, follow the procedure on page 90.

Description of the terminal

Thanks to the screen size of this graphic display terminal, which works with FLASH V1.1IE19 or higher and is part of the ATV71, it is possible to display more detailed information than can be shown on an on-board display. It is connected in the same way as the ATV31 remote display terminal.




Note: Keys **3**, **4**, **5** and **6** can be used to control the drive directly, if control via the terminal is activated.


To activate the buttons on the remote display terminal, you first have to configure [\[HMI command\] \(LCC\) = \[Yes\] \(YES\)](#), page [61](#).

Powering up the graphic display terminal for the first time


When powering up the graphic display terminal for the first time, the user has to select the required language.



Display after the graphic display terminal has been powered up for the first time. Select the language and press ENT.




The drive's rating details will now appear.



The [\[MAIN MENU\]](#) follows automatically.


3 seconds
or ENT




Automatically switches to the [\[DRIVE MENU\]](#) menu after 3 seconds. Select the menu and press ENT.

Powering up the drive for the first time

When powering up the drive for the first time, the user immediately accesses the 3 parameters below: [Standard mot. freq] (bFr), [Ref.1 channel] (Fr1), and [2/3 wire control] (tCC), page 30. .




Display after the drive has been powered up for the first time.



The [MAIN MENU] follows automatically.


3 seconds



Automatically switches to the [DRIVE MENU] menu after 3 seconds. Select the menu and press ENT.


MOTOR CONTROL
INPUTS / OUTPUTS CFG
COMMAND
APPLICATION FUNCT.
FAULT MANAGEMENT
COMMUNICATION

ESC




The word "Ready" appears on the graphic display terminal if you press the ESC key when in the [DRIVE MENU].

Subsequent power-ups




Display after powering up.




The [\[MAIN MENU\]](#) follows automatically.

3 seconds



Automatically switches to the [\[DRIVE MENU\]](#) menu after 3 seconds.
Select the menu and press ENT.

ESC




The word "Ready" appears on the graphic display terminal if you press the ESC key when in the [\[DRIVE MENU\]](#).

Remote display terminal option, ATV12

Description of the terminal

This terminal is a local control unit which can be mounted on the door of the wall-mounted or floor-standing enclosure. It has a cable with connectors, which is connected to the drive serial link (see the manual supplied with the terminal). Its display capabilities are practically identical to those of the Altivar 312. With this terminal, up and down arrows are used for navigation rather than a jog dial.




(1) If the drive is locked by a code ([PIN code 1] (COd), page 103), pressing the Mode key enables you to switch from the [MONITORING] (SUP-) menu to the [SPEED REFERENCE] (rEF-) menu and vice versa.

To activate the buttons on the remote display terminal, you first have to configure [HMI command] (LCC) = [Yes] (YES), page 61.

Structure of the parameter tables

The parameter tables contained in the descriptions of the various menus are organized as follows.

Example :



- 1. Name of menu on 4-digit 7-segment display
- 2. Submenu code on 4-digit 7-segment display
- 3. Parameter code on 4-digit 7-segment display
- 4. Parameter value on 4-digit 7-segment display
- 5. Name of menu on ATV61/ATV71 graphic display terminal
- 6. Name of submenu on ATV61/ATV71 graphic display terminal
- 7. Name of parameter on ATV61/ATV71 graphic display terminal
- 8. Value of parameter on ATV61/ATV71 graphic display terminal

Compatibility of functions

Incompatible functions

The following functions will be inaccessible or deactivated in the cases described below:

Automatic restart

This is only possible for the 2-wire level control type ([2/3 wire control] (tCC) = [2 wire] (2C) and [2 wire type] (tCt) = [Level] (LEL) or [Fwd priority] (PFO)).

Catch on the fly

This is only possible for the 2-wire level control type ([2/3 wire control] (tCC) = [2 wire] (2C) and [2 wire type] (tCt) = [Level] (LEL) or [Fwd priority] (PFO)).

This function is locked if automatic standstill injection has been configured as DC ([Auto DC injection] (AdC) = [Continuous] (Ct)).

Function compatibility table

The choice of application functions may be limited by the number of I/O and by the fact that some functions are incompatible with one another. Functions which are not listed in this table are compatible.

If there is an incompatibility between functions, the first function configured will prevent the others being configured.

To configure a function, first check that functions which are incompatible with it are unassigned, especially those which are assigned in the factory settings.

	Summing inputs (factory setting)	+/- speed (1)	Management of limit switches	Preset speeds (factory setting)	PI regulator	Jog operation	Brake control	DC injection stop	Fast stop	Freewheel stop
Summing inputs (factory setting)		●		↑	●	↑				
+/- speed (1)	●			●	●	●				
Management of limit switches					●					
Preset speeds (factory setting)	↑	●			●	↑				
PI regulator	●	●	●	●		●	●			
Jog operation	↑	●		↑	●		●			
Brake control					●	●		●		
DC injection stop							●			↑
Fast stop										↑
Freewheel stop								↑	↑	

(1) Excluding special application with reference channel [Ref.2 channel] (Fr2) (see diagrams 53 and 55)

● Incompatible functions □ Compatible functions ■ Not applicable

Priority functions (functions which cannot be active at the same time):

← ↑ The function marked with the arrow takes priority over the other.

Stop functions take priority over run commands.

Speed references via logic command take priority over analog references.

Compatibility of functions

Logic and analog input application functions

Each of the functions on the following pages can be assigned to one of the inputs.

A single input can activate several functions at the same time (reverse and 2nd ramp for example). **The user must therefore ensure that these functions can be used at the same time.**

The [\[MONITORING\] \(SUP-\)](#) menu ([\[\[\[LOGIC INPUT CONF.\]\] \(LIA-\)](#) parameter, page [104](#), and [\[\[ANALOG INPUTS IMAGE\]\] \(AIA-\)](#) parameter, page [104](#)) can be used to display the functions assigned to each input in order to check their compatibility.

Before assigning a reference, command or function to a logic or analog input, the user must check that this input has not already been assigned in the factory settings and that no other input has been assigned to an incompatible or unwanted function.

- Example of incompatible function to be unassigned:
In order to use the "+speed/-speed" function, the preset speeds and summing input 2 must first be unassigned.

The table below lists the factory-set input assignments and the procedure for unassigning them.

Assigned input	Function	Code	To unassign, set to:	Page
LI2	Run reverse	rr 5	nO	48
LI3	2 preset speeds	PS 2	nO	72
LI4	4 preset speeds	PS 4	nO	72
AI1	Reference 1	Fr 1	Anything but AI1	58
LI1	Run forward	LC C	2C or 3C	47
AI2	Summing input 2	SA 2	nO	70

List of functions that can be assigned to inputs/outputs

Logic inputs	Page	Code	Factory setting
Not assigned	-	-	LI5 - LI6
Run forward	-	-	LI1
2 preset speeds	72	<i>P 5 2</i>	LI3
4 preset speeds	72	<i>P 5 4</i>	LI4
8 preset speeds	72	<i>P 5 8</i>	
16 preset speeds	73	<i>P 5 16</i>	
2 preset PI references	80	<i>P r 2</i>	
4 preset PI references	81	<i>P r 4</i>	
+ speed	77	<i>u 5 P</i>	
- speed	77	<i>d 5 P</i>	
Jog operation	75	<i>J o G</i>	
Ramp switching	64	<i>r P 5</i>	
2nd current limit switching	86	<i>L C 2</i>	
Fast stop via logic input	65	<i>F 5 t</i>	
DC injection via logic input	66	<i>d C i</i>	
Freewheel stop via logic input	67	<i>n 5 t</i>	
Run reverse	48	<i>r r 5</i>	LI2
External fault	93	<i>E t F</i>	
RESET	92	<i>r 5 F</i>	
Forced local mode	99	<i>F L o</i>	
Reference switching	59	<i>r F C</i>	
Control channel switching	60	<i>C C 5</i>	
Motor switching	87	<i>C H P</i>	
Forward limit switch	89	<i>L A F</i>	
Reverse limit switch	89	<i>L A r</i>	
Fault inhibition	96	<i>i n H</i>	

Analog inputs	Page	Code	Factory setting
Not assigned	-	-	AI3
Reference 1	58	<i>F r 1</i>	AI1
Reference 2	58	<i>F r 2</i>	
Summing input 2	70	<i>S A 2</i>	AI2
Summing input 3	70	<i>S A 3</i>	
PI regulator feedback	80	<i>P i F</i>	

List of functions that can be assigned to inputs/outputs

Analog/logic output	Page	Code	Factory setting
Not assigned	-	-	AOC/AOV
Motor current	48	o C r	
Motor frequency	48	o F r	
Motor torque	48	o t r	
Power supplied by the drive	48	o P r	
Drive detected fault (logic data)	48	F L t	
Drive running (logic data)	48	r u n	
Frequency threshold reached (logic data)	48	F t A	
High speed (HSP) reached (logic data)	48	F L A	
Current threshold reached (logic data)	48	C t A	
Frequency reference reached (logic data)	48	S r A	
Motor thermal threshold reached (logic data)	48	t S A	
Brake sequence (logic data)	48	b L C	

Relay	Page	Code	Factory setting
Not assigned	-	-	R2
Detected fault	49	F L t	R1
Drive running	49	r u n	
Frequency threshold reached	49	F t A	
High speed (HSP) reached	49	F L A	
Current threshold reached	49	C t A	
Frequency reference reached	49	S r A	
Motor thermal threshold reached	49	t S A	
Brake sequence	49	b L C	
Copy of the logic input	49	L , 1 to L , 5	

List of functions that can be assigned to the Network and Modbus control word bits

Bits 11 to 15 of the control word	Page	Code
2 preset speeds	72	<i>PS 2</i>
4 preset speeds	72	<i>PS 4</i>
8 preset speeds	72	<i>PS 8</i>
16 preset speeds	73	<i>PS 16</i>
2 preset PI references	80	<i>Pr 2</i>
4 preset PI references	81	<i>Pr 4</i>
Ramp switching	64	<i>r P 5</i>
2nd current limit switching	86	<i>LC 2</i>
Fast stop via logic input	65	<i>FSt</i>
DC injection	66	<i>dC i</i>
External fault	93	<i>EtF</i>
Reference switching	59	<i>r F C</i>
Control channel switching	60	<i>CC 5</i>
Motor switching	87	<i>CHP</i>

Checklist

Carefully read the information contained in the programming, installation and simplified manuals, as well as the information in the catalog. Before starting to use the drive, please check the following points relating to mechanical and electrical installations. For the full range of documentation, please visit www.schneider-electric.com.

1. Mechanical installation (see the simplified and installation manuals)

- For details of the different installation types and recommendations concerning ambient temperature, please refer to the installation instructions in the simplified or installation manuals.
- Install the drive vertically in accordance with the specifications. Please refer to the installation instructions in the simplified or installation manuals.
- When using the drive, both the environmental conditions defined under standard 60721-3-3 and the levels defined in the catalog must be respected.
- Install the required options for your application. Refer to the catalog for details.

2. Electrical installation (see the simplified and installation manuals)


- Ground the drive. See the sections on how to ground equipment in the simplified and installation manuals.
- Make sure the input supply voltage matches the nominal drive voltage and connect the line supply in accordance with the simplified and installation manuals.
- Make sure you use appropriate input line fuses and circuit breakers. See the simplified and installation manuals.
- Arrange the cables for the control terminals as required (see the simplified and installation manuals). Separate the supply and control cables in accordance with EMC compatibility rules.
- The ATV312●●●●M2 and ATV312●●●●N4 ranges include an EMC filter. Using an IT jumper helps reduce leakage current. This is explained in the paragraph about the internal EMC filter on the ATV312●●●●M2 and the ATV312●●●●N4 in the installation manual.
- Make sure the motor connections are right for the voltage (star, delta).

3. Using and starting up the drive

- Start the drive. [Standard mot. freq] (bFr), page 29, is displayed the first time the drive is powered up. Make sure the frequency defined by frequency bFr (the factory setting is 50 Hz) matches the motor's frequency.
- When the drive is powered up for the first time, the [Ref.1 channel] (Fr1) parameter, page 29, and the [2/3 wire control] (tCC) parameter, page 30, are displayed after [Standard mot. freq] (bFr). These parameters will need to be adjusted if you wish to control the drive locally.
- When the drive is powered up subsequently, [Ready] (rdY) is displayed on the HMI.
- The [Restore config.] (FCS) function, page 46, is used to reinitialize the drive with the factory settings.

Description of the HMI

Functions of the display and the keys



Note1: In LOCAL configuration, the three Leds REF, MON, and CONF are blinking simultaneously in programming mode and are working as a Led chaser in control mode.

Normal display, with no fault code displayed and no startup:

- **4 3 0**: Displays the parameter selected in the **[MONITORING] (SUP-)** menu (default: motor frequency). If the current is limited, the display flashes. In such cases, CLI will appear at the top left if an ATV61/ATV71 graphic display terminal is connected to the drive.
- **1 n i t**: Initialization sequence
- **r d y**: Drive ready
- **d C b**: DC injection braking in progress
- **n S t**: Freewheel stop
- **F S t**: Fast stop
- **t u n**: Auto-tuning in progress

In the event of a detected fault, the display will flash to notify the user accordingly. If an ATV61/ATV71 graphic display terminal is connected, the name of the detected fault will be displayed.

- (1) If the drive is locked by a code (**[PIN code 1] (COd)**, page 103), pressing the Mode key enables you to switch from the **[MONITORING] (SUP-)** menu to the **[SPEED REFERENCE] (rEF-)** menu and vice versa. It is no longer possible to switch between LOCAL and REMOTE configurations.

Easy REMOTE and LOCAL configuration

The LOCAL configuration allows to activate automatically the embedded RUN button and the jog dial as a potentiometer.

In that configuration, the speed adjustment will also be effective on remote keypads. MODE button on ATV12 remote display terminal and on ATV61/71 graphic display terminal (function key F4) is also active to switch from one configuration to another.

[Ref.1 channel] (Fr1) is set to [AI Virtual 1] (AIV1) and [2/3 wire control] (tCC) are set to [Local] (LOC) when switching to LOCAL configuration.

Choose the configuration (REMOTE or LOCAL) before starting the parameters adjustment of the drive.

For parameters interdependencies reasons, switching from one configuration to another will change other parameters (for example : Input/Output assignment will return to their factory value).

⚠ DANGER


UNINTENDED EQUIPMENT OPERATION

When switching from REMOTE to LOCAL configuration, all the assignments involving the logic inputs will revert to their default values.

- Check that this change is compatible with the wiring diagram used.

Failure to follow these instructions will result in death or serious injury.




Structure of the menus




Configuring the [Standard mot. freq] (bFr), [2/3 wire control] (tCC), and [Ref.1 channel] (Fr1) parameters

These parameters can only be modified when the drive is stopped and no run command is present.

Code	Description	Adjustment range	Factory setting
bFr 50 60	<input type="checkbox"/> [Standard mot. freq] This parameter is only visible the first time the drive is powered up. It can be modified at any time in the [MOTOR CONTROL] (drC-) menu. [50Hz IEC] (50): 50 Hz [60Hz NEMA] (60): 60 Hz This parameter modifies the presets of the following parameters: [High speed] (HSP), page 33, [Freq. threshold] (Ftd), page 39, [Rated motor freq.] (FrS), page 41, and [Max frequency] (tFr), page 44		[50Hz IEC] (50)
Fr1 A11 A12 A13 A1V1 UPdt UPdH LCC Mdb nEt	<input type="checkbox"/> [Ref.1 channel] <input type="checkbox"/> [AI1] (AI1) - Analog input AI1 <input type="checkbox"/> [AI2] (AI2) - Analog input AI2 <input type="checkbox"/> [AI3] (AI3) - Analog input AI3 <input type="checkbox"/> [AI Virtual 1] (AIV1) - In terminal control mode, the jog dial functions as a potentiometer. If [ACCESS LEVEL] (LAC) = [Level 2] (L2) or [Level 3] (L3), the following additional assignments are possible: <input type="checkbox"/> [+/- SPEED] (UPdt): +/- speed reference via LI. See configuration page 77. <input type="checkbox"/> [+/-spd HMI] (UPdH): +/- speed reference by turning the jog dial on the ATV312 keypad. To use, display the frequency [Output frequency] (rFr), page 101. The +/- speed function via the keypad or the terminal is controlled from the [MONITORING] (SUP-) menu by selecting the [Output frequency] (rFr) parameter. If [ACCESS LEVEL] (LAC) = [Level 3] (L3), the following additional assignments are possible: <input type="checkbox"/> [HMI] (LCC) reference via the remote display terminal, [HMI Frequency ref.] (LFr) parameter in the [SETTINGS] (SEt-) menu, page 32 <input type="checkbox"/> [Modbus] (Mdb): Reference via Modbus <input type="checkbox"/> [Com. card] (nEt): Reference via network communication protocol		[AI1] (AI1)

Code	Description	Adjustment range	Factory setting
<div>ttt</div> <div>2C</div> <div>3C</div> <div>LOC</div> <div> 2 s</div>	<div><input type="checkbox"/> [2/3 wire control]</div> <div><div><div><div>⚠ DANGER</div><div>UNINTENDED EQUIPMENT OPERATION</div><div>When the [2/3 wire control] (ttt) parameter is changed, the [Reverse assign.] (rrs) parameter, page 48, and the [2 wire type] (tCt) parameter, page 47, and all the assignments involving the logic inputs will revert to their default values. Check that this change is compatible with the wiring diagram used. Failure to follow these instructions will result in death or serious injury.</div></div></div><div>Control configuration:<div><div><input type="checkbox"/> [2 wire] (2C): 2-wire control</div><div><input type="checkbox"/> [3 wire] (3C): 3-wire control</div><div><input type="checkbox"/> [Local] (LOC): Local control (RUN/STOP/RESET drive) (invisible if [ACCESS LEVEL] (LAC) = [Level 3] (L3), page 58)</div></div><div>2-wire control: The open or closed state of the input controls running or stopping. Wiring example:<div><div>Ll1: Forward</div><div>Llx: Reverse</div><div></div></div><div>3-wire control (pulse control): A "forward" or "reverse" pulse is sufficient to control startup, a "stop" pulse is sufficient to control stopping. Wiring example:<div><div>Ll1: Stop</div><div>Ll2: Forward</div><div>Llx: Reverse</div><div></div></div></div></div></div></div>		[2 wire] (2C)

 2 s

The jog dial (ENT) needs to be pressed and held down (for 2 s) to change the assignment for this parameter.

[SPEED REFERENCE] (rEF-) menu

The [SPEED REFERENCE] (rEF-) menu displays [HMI Frequency ref.] (LFr), [Image input AIV1] (AIV1) or [Frequency ref.] (FrH) depending on which control channel is active.

During local control, the HMI's jog dial functions as a potentiometer, making it possible to increase or reduce the reference value within limits defined by the [Low speed] (LSP) and [High speed] (HSP) parameters.


When local control is deactivated, by the [Ref.1 channel] (Fr1) parameter, only the reference values are displayed. The value will be read-only and can only be changed via the jog dial (the speed reference is supplied by an AI or another source).

The reference displayed will depend on how the drive has been configured.

Code	Description	Factory setting
LFr	<div><input type="checkbox"/> [HMI Frequency ref.]</div> <div>This parameter only appears if the function has been enabled. It is used to change the speed reference from the remote control. ENT does not have to be pressed to enable a change of reference.</div>	0 to 500 Hz
AIV1	<div><input type="checkbox"/> [Image input AIV1]</div> <div>Used to amend the speed reference via the jog dial</div>	0 to 100%
FrH	<div><input type="checkbox"/> [Frequency ref.]</div> <div>This parameter is read-only. It enables you to display the speed reference applied to the motor, regardless of which reference channel has been selected.</div>	LSP to HSP Hz

[SETTINGS] (SEt-) menu

REF -
SEt -
drC -
i-D -
LFL -
Fun -
FLt -
LdP -
SdP -



The adjustment parameters can be modified with the drive running or stopped.

Note: Changes should preferably be made with the drive stopped.




Code	Description	Adjustment range	Factory setting
LFr	<input type="checkbox"/> [HMI Frequency ref.]	0 to HSP	-
★	This parameter is displayed if [HMI command] (LCC) = [Yes] (YES), page 61 or if [Ref.1 channel] (Fr1)/[Ref.2 channel] (Fr2) = [HMI] (LCC) page 58, and if a remote display terminal is connected. In such cases, [HMI Frequency ref.] (LFr) can also be accessed via the drive's keypad. [HMI Frequency ref.] (LFr) is reinitialized to 0 when power is switched off.		
rPi	<input type="checkbox"/> [Internal PID ref.]	0.0 to 100%	0%
★	Parameter is only visible if [PID feedback ass.] (PIF) is not set to [No] (nO), page 80.		
ACC	<input type="checkbox"/> [Acceleration]	In accordance with inr, page 63	3 s
	Defined to accelerate from 0 to the nominal frequency [Rated motor freq.] (FrS) in the [MOTOR CONTROL] (drC-) menu.		
AC2	<input type="checkbox"/> [Acceleration 2]	In accordance with inr, page 63	5 s
★	Parameter can be accessed if [Ramp 2 threshold] (Frt) > 0, page 64, or if [Ramp switch ass.] (rPS) is assigned, page 64.		
dE2	<input type="checkbox"/> [Deceleration 2]	In accordance with inr, page 63	5 s
★	Parameter can be accessed if [Ramp 2 threshold] (Frt) > 0, page 64, or if [Ramp switch ass.] (rPS) is assigned, page 64.		
dEC	<input type="checkbox"/> [Deceleration]	In accordance with inr, page 63	3 s
	Defined to decelerate from the nominal frequency [Rated motor freq.] (FrS) (parameter in the [MOTOR CONTROL] (drC-) menu) to 0. Check that the value for [Deceleration] (dEC) is not too low in relation to the load to be stopped.		



These parameters only appear if the corresponding function has been selected in another menu. When the parameters can also be accessed and set from within the configuration menu for the corresponding function, their description is detailed in these menus, on the pages indicated, to aid programming.

[SETTINGS] (SEt-) menu

REF -


Code	Description	Adjustment range	Factory setting	SEE -
L A 1 ★	<input type="checkbox"/> [Begin Acc round] Parameter can be accessed if the [Ramp type] (rPt) = [Customized] (CUS), page 62.	0 to 100	10	dr C -
L A 2 ★	<input type="checkbox"/> [End Acc round] Parameter can be accessed if the [Ramp type] (rPt) = [Customized] (CUS), page 62.	0 to (100-tA1)	10	C t L - F u n - F L t -
L A 3 ★	<input type="checkbox"/> [Begin Dec round] Parameter can be accessed if the [Ramp type] (rPt) = [Customized] (CUS), page 62.	0 to 100	10	C o n - S u P -
L A 4 ★	<input type="checkbox"/> [End Dec round] Parameter can be accessed if the [Ramp type] (rPt) = [Customized] (CUS), page 62.	0 to (100-tA3)	10	
L S P	<input type="checkbox"/> [Low speed] Motor frequency at min. reference	0 to HSP	0	
H S P	<input type="checkbox"/> [High speed] Motor frequency at max. reference: Ensure that this setting is appropriate for the motor and the application.	LSP to tFr	bFr	
I t H	<input type="checkbox"/> [Mot. therm. current] Set [Mot. therm. current] (ItH) to the nominal current indicated on the motor's rating plate. If you wish to suppress thermal protection, see [Overload fault mgt] (OLL), page 94.	0.2 to 1.5 In (1)	In accordance with the drive rating	
U F r	<input type="checkbox"/> [IR compensation] - For [U/F mot 1 selected] (UFt) = [SVC] (n) or [Energy sav.] (nLd), page 44: IR compensation - For [U/F mot 1 selected] (UFt) = [Cst. torque] (L) or [Var. torque] (P), page 44: Voltage boost Used to optimize the torque at very low speed (increase [IR compensation] (UFr) if the torque is insufficient). Check that the value for [IR compensation] (UFr) is not too high when the motor is in a hot state otherwise some instabilities can occur. Note: Changing [U/F mot 1 selected] (UFt), page 44, will cause [IR compensation] (UFr) to return to its factory setting (20%).	0 to 100%	20%	
F L G ★	<input type="checkbox"/> [FreqLoopGain] Parameter can only be accessed if [U/F mot 1 selected] (UFt) = [SVC] (n) or [Energy sav.] (nLd), page 44. The F L G parameter adjusts the drive's ability to follow the speed ramp on the basis of the inertia of the machine being driven. Too high a gain may result in operating instability. <div style="display: flex; justify-content: space-around; align-items: flex-end;">    </div>	1 to 100%	20%	

(1) In corresponds to the nominal drive current indicated in the Installation Manual and on the drive nameplate.

★ These parameters only appear if the corresponding function has been selected in another menu. When the parameters can also be accessed and set from within the configuration menu for the corresponding function, their description is detailed in these menus, on the pages indicated, to aid programming.

[SETTINGS] (SEt-) menu

REF -
SEt -
drC -
i - D -
CLL -
Fun -
FLt -
CaP -
SUP -

Code	Description	Adjustment range	Factory setting
SEt SLR	<p><input type="checkbox"/> [Fr.Loop.Stab]</p> <p>Parameter can only be accessed if [U/F mot 1 selected] (Uft) = [SVC] (n) or [Energy sav.] (nLd), page 44. Used to adapt the return to steady state after a speed transient (acceleration or deceleration), according to the dynamics of the machine. Gradually increase the stability to avoid any overspeed.</p> 	1 to 100%	20%
SLP	<p><input type="checkbox"/> [Slip compensation]</p> <p>Parameter can only be accessed if [U/F mot 1 selected] (Uft) = [SVC] (n) or [Energy sav.] (nLd), page 44. Adjusts the slip compensation around the value set by the nominal motor speed. The speeds given on motor rating plates are not necessarily exact.</p> <ul style="list-style-type: none"> • If slip setting < actual slip: the motor is not rotating at the correct speed in steady state. • If slip setting > actual slip: the motor is overcompensated and the speed is unstable. 	0 to 150%	100%
idC	<p><input type="checkbox"/> [DC inject. level 1] (2)</p> <p>0 to In (1)</p> <p>0.7 In (1)</p> <p>CAUTION</p> <p>RISK OF DAMAGE TO THE MOTOR</p> <ul style="list-style-type: none"> • Check that the motor will withstand this current without overheating.. <p>Failure to follow these instructions can result in equipment damage.</p> <p>Parameter can be accessed if [Type of stop] (Stt) = [DC injection] (dCI), page 65, or if [DC injection assign.] (dCI) is not set to [No] (nO), page 66. After 5 seconds, the injection current is limited to 0.5 [Mot. therm. current] (Ith) if set to a higher value.</p>		
tdC	<p><input type="checkbox"/> [DC injection time 2] (2)</p> <p>0.1 to 30 s</p> <p>0.5 s</p> <p>CAUTION</p> <p>RISK OF DAMAGE TO THE MOTOR</p> <ul style="list-style-type: none"> • Long periods of DC injection braking can cause overheating and damage the motor. • Protect the motor by avoiding long periods of DC injection braking. <p>Failure to follow these instructions can result in equipment damage.</p> <p>Parameter can be accessed if [Type of stop] (Stt) = [DC injection] (dCI), page 65.</p>		
tdC 1	<p><input type="checkbox"/> [Auto DC inj. time 1]</p> <p>0.1 to 30 s</p> <p>0.5 s</p> <p>CAUTION</p> <p>RISK OF DAMAGE TO THE MOTOR</p> <ul style="list-style-type: none"> • Long periods of DC injection braking can cause overheating and damage the motor. • Protect the motor by avoiding long periods of DC injection braking. <p>Failure to follow these instructions can result in equipment damage.</p> <p>Parameter can be accessed if [Auto DC injection] (AdC) is not set to [No] (nO), page 68.</p>		

(1) In corresponds to the nominal drive current indicated in the Installation Manual and on the drive nameplate.

(2) **Note:** These settings are not related to the "automatic standstill DC injection" function.



These parameters only appear if the corresponding function has been selected in another menu. When the parameters can also be accessed and set from within the configuration menu for the corresponding function, their description is detailed in these menus, on the pages indicated, to aid programming.

[SETTINGS] (SEt-) menu

Code	Description	Adjustment range	Factory setting
5 d C 1 ★	<input type="checkbox"/> [Auto DC inj. level 1]	0 to 1.2 In (1)	0.7 In (1)
	<p style="text-align: center;">CAUTION</p> <p>RISK OF DAMAGE TO THE MOTOR</p> <ul style="list-style-type: none"> Check that the motor will withstand this current without overheating. <p>Failure to follow these instructions can result in equipment damage.</p> <p>Parameter can be accessed if [Auto DC injection] (AdC) is not set to [No] (nO), page 68. Note: Check that the motor will withstand this current without overheating.</p>		
6 d C 2 ★	<input type="checkbox"/> [Auto DC inj. time 2]	0 to 30 s	0 s
	<p style="text-align: center;">CAUTION</p> <p>RISK OF DAMAGE TO THE MOTOR</p> <ul style="list-style-type: none"> Long periods of DC injection braking can cause overheating and damage the motor. Protect the motor by avoiding long periods of DC injection braking. <p>Failure to follow these instructions can result in equipment damage.</p> <p>Parameter can be accessed if [Auto DC injection] (AdC) is not set to [No] (nO), page 68.</p>		
5 d C 2 ★	<input type="checkbox"/> [Auto DC inj. level 2]	0 to 1.2 In (1)	0.5 In (1)
	<p style="text-align: center;">CAUTION</p> <p>RISK OF DAMAGE TO THE MOTOR</p> <ul style="list-style-type: none"> Check that the motor will withstand this current without overheating. <p>Failure to follow these instructions can result in equipment damage.</p> <p>Parameter can be accessed if [Auto DC injection] (AdC) is not set to [No] (nO), page 68. Note: Check that the motor will withstand this current without overheating.</p>		

(1) In corresponds to the nominal drive current indicated in the Installation Manual and on the drive nameplate.

(2) **Note:** These settings are not related to the "automatic standstill DC injection" function.

★ These parameters only appear if the corresponding function has been selected in another menu. When the parameters can also be accessed and set from within the configuration menu for the corresponding function, their description is detailed in these menus, on the pages indicated, to aid programming.

[SETTINGS] (SEt-) menu

REF -

SEt -

drC -

rD -

CLL -

Fun -

FLt -

CoN -

SUP -

Code	Description	Adjustment range	Factory setting
JPF	<input type="checkbox"/> [Skip Frequency] Helps to prevent prolonged operation at a frequency range of ± 1 Hz around [Skip Frequency] (JPF) . This function helps to prevent a critical speed which leads to resonance. Setting the function to 0 renders it inactive.	0 to 500 Hz	0 Hz
JF2	<input type="checkbox"/> [Skip Frequency 2] Helps to prevent prolonged operation at a frequency range of ± 1 Hz around [Skip Frequency 2] (JF2) . This function helps to prevent a critical speed which leads to resonance. Setting the function to 0 renders it inactive.	1 to 500 Hz	0 Hz
JGF	<input type="checkbox"/> [Jog frequency] Parameter can be accessed if [JOG] (JOG) is not set to [No] (nO) , page 75 .	0 to 10 Hz	10 Hz
rPG	<input type="checkbox"/> [PID prop. gain] Parameter is only visible if [PID feedback ass.] (PIF) is not set to [No] (nO) , page 80 . It provides dynamic performance when PI feedback is changing quickly.	0.01 to 100	1
rIG	<input type="checkbox"/> [PID integral gain] Parameter is only visible if [PID feedback ass.] (PIF) is not set to [No] (nO) , page 80 . It provides static precision when PI feedback is changing slowly.	0.01 to 100/s	1
FbS	<input type="checkbox"/> [PID fbk scale factor] Parameter is only visible if [PID feedback ass.] (PIF) is not set to [No] (nO) , page 80 . For adapting the process.	0.1 to 100	1
PIC	<input type="checkbox"/> [PID correct. reverse] Parameter is only visible if [PID feedback ass.] (PIF) is not set to [No] (nO) , page 80 . <input type="checkbox"/> [No] (nO) : Normal <input type="checkbox"/> [Yes] (YES) : Reverse		[No] (nO)
rP2	<input type="checkbox"/> [Preset ref. PID 2] Parameter is only visible if [PID feedback ass.] (PIF) is not set to [No] (nO) , page 80 , and if [2 preset PID ref.] (Pr2) , page 80 , has been enabled by the input selection.	0 to 100%	30%
rP3	<input type="checkbox"/> [Preset ref. PID 3] Parameter is only visible if [PID feedback ass.] (PIF) is not set to [No] (nO) , page 80 , and if [4 preset PID ref.] (Pr4) , page 81 , has been enabled by the input selection.	0 to 100%	60%
rP4	<input type="checkbox"/> [Preset ref. PID 4] Parameter is only visible if [PID feedback ass.] (PIF) is not set to [No] (nO) , page 80 , and if [4 preset PID ref.] (Pr4) , page 81 , has been enabled by the input selection.	0 to 100%	90%
SP2	<input type="checkbox"/> [Preset speed 2] See page 73 .	0 to 500 Hz	10 Hz



These parameters only appear if the corresponding function has been selected in another menu. When the parameters can also be accessed and set from within the configuration menu for the corresponding function, their description is detailed in these menus, on the pages indicated, to aid programming.

[SETTINGS] (SEt-) menu

REF -

drC -

,-D -

CTL -

Fun -

FLt -

CoP -

SUP -

Code	Description	Adjustment range	Factory setting
SP 3 ★	<input type="checkbox"/> [Preset speed 3] See page 73 .	0 to 500 Hz	15 Hz
SP 4 ★	<input type="checkbox"/> [Preset speed 4] See page 73 .	0 to 500 Hz	20 Hz
SP 5 ★	<input type="checkbox"/> [Preset speed 5] See page 73 .	0 to 500 Hz	25 Hz
SP 6 ★	<input type="checkbox"/> [Preset speed 6] See page 73 .	0 to 500 Hz	30 Hz
SP 7 ★	<input type="checkbox"/> [Preset speed 7] See page 73 .	0 to 500 Hz	35 Hz
SP 8 ★	<input type="checkbox"/> [Preset speed 8] See page 73 .	0 to 500 Hz	40 Hz
SP 9 ★	<input type="checkbox"/> [Preset speed 9] See page 73 .	0 to 500 Hz	45 Hz
SP 10 ★	<input type="checkbox"/> [Preset speed 10] See page 73 .	0 to 500 Hz	50 Hz
SP 11 ★	<input type="checkbox"/> [Preset speed 11] See page 74 .	0 to 500 Hz	55 Hz
SP 12 ★	<input type="checkbox"/> [Preset speed 12] See page 74 .	0 to 500 Hz	60 Hz
SP 13 ★	<input type="checkbox"/> [Preset speed 13] See page 74 .	0 to 500 Hz	70 Hz
SP 14 ★	<input type="checkbox"/> [Preset speed 14] See page 74 .	0 to 500 Hz	80 Hz
SP 15 ★	<input type="checkbox"/> [Preset speed 15] See page 74 .	0 to 500 Hz	90 Hz
SP 16 ★	<input type="checkbox"/> [Preset speed 16] See page 74 .	0 to 500 Hz	100 Hz



These parameters only appear if the corresponding function has been selected in another menu. When the parameters can also be accessed and set from within the configuration menu for the corresponding function, their description is detailed in these menus, on the pages indicated, to aid programming.

[SETTINGS] (SEt-) menu

REF -
SEt -
drC -
rD -
CLL -
Fun -
FLt -
Cn -
SUP -

Code	Description	Adjustment range	Factory setting
CL1	<input type="checkbox"/> [Current Limitation]	0.25 to 1.5 In (1)	1.5 In (1)
	<p style="text-align: center;">CAUTION</p> <p>RISK OF DAMAGE TO THE MOTOR AND THE DRIVE</p> <ul style="list-style-type: none"> Check that the motor will withstand this current, particularly in the case of permanent magnet synchronous motors, which are susceptible to demagnetization. Check that the profile mission complies with the derating curve given in the installation manual. <p>Failure to follow these instructions can result in equipment damage.</p> <p>Used to limit the torque and the temperature rise of the motor.</p>		
CL2	<input type="checkbox"/> [I Limit. 2 value]	0.25 to 1.5 In (1)	1.5 In (1)
★	<p style="text-align: center;">CAUTION</p> <p>RISK OF DAMAGE TO THE MOTOR AND THE DRIVE</p> <ul style="list-style-type: none"> Check that the motor will withstand this current, particularly in the case of permanent magnet synchronous motors, which are susceptible to demagnetization. Check that the profile mission complies with the derating curve given in the installation manual. <p>Failure to follow these instructions can result in equipment damage.</p> <p>Parameter is only visible if [Current limit 2] (LC2) is not set to [No] (nO), page 86.</p>		
tLS	<input type="checkbox"/> [Low speed time out]	0 to 999.9 s	0 (no time limit)
	<p>After operating at [Low speed] (LSP) for a given time, the motor is stopped automatically. The motor restarts if the frequency reference is greater than the [Low speed] (LSP) and if a run command is still present.</p> <p>Note: Value 0 corresponds to an unlimited period.</p>		
rSL	<input type="checkbox"/> [PID wake up thresh.]	0 to 100%	0%
★	<p style="text-align: center;">⚠ DANGER</p> <p>UNINTENDED EQUIPMENT OPERATION</p> <ul style="list-style-type: none"> Check that unintended restarts will not present any danger. <p>Failure to follow these instructions will result in death or serious injury</p> <p>Parameter is only visible if [PID feedback ass.] (PIF) is not set to [No] (nO), page 80.</p> <p>If the "PI" and "Low speed operating time" [Low speed time out] (tLS) functions, page 38, are configured at the same time, the PI regulator may attempt to set a speed lower than [Low speed] (LSP).</p> <p>This results in unsatisfactory operation, which consists of starting, operating at [Low speed] (LSP), then stopping, and so on.</p> <p>The [PID wake up thresh.] (rSL) parameter (restart error threshold) is used to set a minimum PID error threshold for restarting after a stop at prolonged [Low speed] (LSP).</p> <p>The function is inactive if [Low speed time out] (tLS) = 0.</p>		

(1) In corresponds to the nominal drive current indicated in the Installation Manual and on the drive nameplate.



These parameters only appear if the corresponding function has been selected in another menu. When the parameters can also be accessed and set from within the configuration menu for the corresponding function, their description is detailed in these menus, on the pages indicated, to aid programming.

[SETTINGS] (SEt-) menu

REF -

SEt -

dr C -

1 - 0 -



Ct L -

F u n -

FLt -

C a n -

S u P -

Code	Description	Adjustment range	Factory setting
uFr2	<p><input type="checkbox"/> [IR compensation 2]</p> <p>For [U/F mot.2 selected] (UFT2) = [SVC] (n) or [Energy sav.] (nLd): IR compensation. For [U/F mot.2 selected] (UFT2) = [Cst. torque] (L) or [Var. torque] (P): voltage boost. Used to optimize the torque at very low speed (increase [IR compensation 2] (UFR2) if the torque is insufficient). Check that the value for [IR compensation 2] (UFR2) is not too high when the motor is in a hot state otherwise some instabilities can occur. Changing [U/F mot.2 selected] (UFT2) will cause [IR compensation 2] (UFR2) to return to its factory setting (20%).</p>	0 to 100%	20%
FLG2	<p><input type="checkbox"/> [FreqLoopGain 2]</p> <p>Parameter can only be accessed if [U/F mot.2 selected] (UFT2) = [SVC] (n) or [Energy sav.] (nLd), page 88. The [FreqLoopGain 2] (FLG2) parameter adjusts the drive's ability to follow the speed ramp on the basis of the inertia of the machine being driven. Too high a gain may result in operating instability.</p> <div>  </div>	0 to 100%	20%
SEAR2	<p><input type="checkbox"/> [Freq. loop stability 2]</p> <p>Parameter can only be accessed if [U/F mot.2 selected] (UFT2) = [SVC] (n) or [Energy sav.] (nLd), page 88. Used to adapt the return to steady state after a speed transient (acceleration or deceleration), according to the dynamics of the machine. Gradually increase the stability to avoid any overspeed.</p> <div>  </div>	0 to 100%	20%
SLP2	<p><input type="checkbox"/> [Slip compensation 2]</p> <p>Parameter can only be accessed if [U/F mot.2 selected] (UFT2) = [SVC] (n) or [Energy sav.] (nLd), page 88. Adjusts the slip compensation around the value set by the nominal motor speed. The speeds given on motor rating plates are not necessarily exact.</p> <ul style="list-style-type: none"> • If slip setting < actual slip: The motor is not rotating at the correct speed in steady state. • If slip setting > actual slip: The motor is overcompensated and the speed is unstable. 	0 to 150%	100%
Ftd	<p><input type="checkbox"/> [Freq. threshold]</p> <p>Threshold beyond which the contact on the relay ([R1 Assignment] (r1) or [R2 Assignment] (r2) = [Freq.Th.att.] (FtA)) closes or output AOV = 10 V ([Analog./logic output] (dO) = [Freq. limit] (FtA)).</p>	0 to 500 Hz	bFr
tt d	<p><input type="checkbox"/> [Motor therm. level]</p> <p>Threshold beyond which the contact on the relay ([R1 Assignment] (r1) or [R2 Assignment] (r2) = [Th.mot. att.] (tSA)) closes or output AOV = 10 V ([Analog./logic output] (dO) = [Drv thermal] (tSA)).</p>	1 to 118%	100%
Ctd	<p><input type="checkbox"/> [Current threshold]</p> <p>Threshold beyond which the contact on the relay ([R1 Assignment] (r1) or [R2 Assignment] (r2) = [I attained] (CtA)) closes or output AOV = 10 V ([Analog./logic output] (dO) = [Current limit] (CtA)).</p>	0 to 1.5 In (1)	In (1)

(1) In corresponds to the nominal drive current indicated in the Installation Manual and on the drive nameplate.

★ These parameters only appear if the corresponding function has been selected in another menu. When the parameters can also be accessed and set from within the configuration menu for the corresponding function, their description is detailed in these menus, on the pages indicated, to aid programming.


[SETTINGS] (SEt-) menu

REF -
SEt -
drC -
rFr -
CLL -
Fun -
FLt -
Cn -
SUP -


Code	Description	Adjustment range	Factory setting
SdS	<p><input type="checkbox"/> [Scale factor display]</p> <p>Used to display a value in proportion to the output frequency [Output frequency] (rFr): the machine speed, the motor speed, etc.</p> <ul style="list-style-type: none"> If [Scale factor display] (SdS) ≤ 1, [Cust. output value] (SPd1) is displayed (possible definition = 0.01) If 1 < [Scale factor display] (SdS) ≤ 10, [Cust. output value] (SPd2) is displayed (possible definition = 0.1) If [Scale factor display] (SdS) > 10, [Cust. output value] (SPd3) is displayed (possible definition = 1) If [Scale factor display] (SdS) > 10 and [Scale factor display] (SdS) x [Output frequency] (rFr) > 9,999: <p>the display will show</p> $[\text{Cust. output value}] (\text{SPd3}) = \frac{[\text{Scale factor display}] (\text{SdS}) \times [\text{Output frequency}] (\text{rFr})}{1000} \text{ to 2 decimal places}$ <p>example: for 24,223, display will show 24.22</p> <ul style="list-style-type: none"> If [Scale factor display] (SdS) > 10 and [Scale factor display] (SdS) x [Output frequency] (rFr) > 65,535, display locked at 65.54 <p>Example: Display motor speed for 4-pole motor, 1,500 rpm at 50 Hz (synchronous speed): [Scale factor display] (SdS) = 30 [Cust. output value] (SPd3) = 1,500 at [Output frequency] (rFr) = 50 Hz</p>	0.1 to 200	30
SFr	<p><input type="checkbox"/> [Switching freq.] (1)</p> <p>Parameter can also be accessed in the [MOTOR CONTROL] (drC-) menu. The frequency can be adjusted to reduce the noise generated by the motor.</p> <p>If the frequency has been set to a value higher than 4 kHz, in the event of excessive temperature rise, the drive will automatically reduce the switching frequency and increase it again once the temperature has returned to normal.</p>	2.0 to 16 kHz	4 kHz

(1) Parameter can also be accessed in the [MOTOR CONTROL] (drC-) menu.

[MOTOR CONTROL] (drC-) menu



With the exception of [Auto tuning] (tUn), which can power up the motor, parameters can only be changed in stop mode, with no run command present.

On the optional ATV31 remote display terminal, this menu can be accessed with the switch in the  position.

Drive performance can be optimized by:

- Entering the values given on the motor rating plate in the Drive menu
- Performing an auto-tune operation (on a standard asynchronous motor)

Code	Description	Adjustment range	Factory setting
bFr 50 60	<input type="checkbox"/> [Standard mot. freq] [50Hz IEC] (50): 50 Hz: IEC [60Hz NEMA] (60): 60 Hz: NEMA This parameter modifies the presets of the following parameters: [High speed] (HSP), page 33, [Freq. threshold] (Ftd), page 39, [Rated motor freq.] (FrS), page 41, and [Max frequency] (tFr), page 44.		[50Hz IEC] (50)
unS	<input type="checkbox"/> [Rated motor volt.] Nominal motor voltage given on the rating plate. When the line voltage is lower than the nominal motor voltage, set [Rated motor volt.] (unS) to the same value as the line voltage for the drive terminals. ATV312...M2: 100 to 240 V ATV312...M3: 100 to 240 V ATV312...N4: 100 to 500 V ATV312...S6: 100 to 600 V	In accordance with the drive rating	In accordance with the drive rating
FrS	<input type="checkbox"/> [Rated motor freq.] Nominal motor frequency marked on the rating plate. The factory setting is 50 Hz, or 60 Hz if [Standard mot. freq] (bFr) is set to 60 Hz. Note: The ratio $\frac{[\text{Rated motor volt.}] (\text{unS}) (\text{in volts})}{[\text{Rated motor freq.}] (\text{FrS}) (\text{in Hz})}$ must not exceed the following values: ATV312...M2: 7 max. ATV312...M3: 7 max. ATV312...N4: 14 max. ATV312...S6: 17 max. The factory setting is 50 Hz, or preset to 60 Hz if [Standard mot. freq] (bFr) is set to 60 Hz.	10 to 500 Hz	50 Hz
nCr	<input type="checkbox"/> [Rated mot. current] Nominal motor current given on the rating plate.	0.25 to 1.5 In (1)	In accordance with the drive rating

(1) In corresponds to the nominal drive current indicated in the Installation Manual and on the drive nameplate.

[MOTOR CONTROL] (drC-) menu

REF -
SEt -
drC -
r - 0 -
CLtL -
FUn -
FLt -
CoP -
SuP -

Code	Description	Adjustment range	Factory setting
nSP	<input type="checkbox"/> [Rated motor speed] 0 to 9,999 rpm then 10.00 to 32.76 krpm If, rather than the nominal speed, the nameplate indicates the synchronous speed and the slip in Hz or as a %, calculate the nominal speed as follows: <ul style="list-style-type: none"> Nominal speed = synchronous speed x $\frac{100 - \text{slip as a \%}}{100}$ or Nominal speed = synchronous speed x $\frac{50 - \text{slip in Hz}}{50}$ (50 Hz motors) or Nominal speed = synchronous speed x $\frac{60 - \text{slip in Hz}}{60}$ (60 Hz motors) 	0 to 32,760 rpm	In accordance with the drive rating
CoS	<input type="checkbox"/> [Motor 1 Cosinus Phi] Motor Cos Phi given on the motor rating plate	0.5 to 1	In accordance with the drive rating
rSC no init BBBB	<input type="checkbox"/> [Cold stator resist.] <input type="checkbox"/> [No] (nO): function inactive. For applications which do not require high performance or do not tolerate automatic auto-tuning (passing a current through the motor) each time the drive is powered up. <input type="checkbox"/> [Init] (InIt): activates the function. To improve low-speed performance whatever the thermal state of the motor. <input type="checkbox"/> Value of cold state stator resistance used, in mΩ. Note: <ul style="list-style-type: none"> It is strongly recommended that this function is activated for mechanical handling applications. The function should only be activated [Init] (InIt) when the motor is cold. When [Cold stator resist.] (rSC) = [Init] (InIt), the [Auto-tuning] (tUn) parameter is forced to [Power on] (POn). At the next run command the stator resistance is measured with an auto-tune. The [Cold stator resist.] (rSC) then changes to a value of (BBBB) and maintains it, [Auto-tuning] (tUn) is still forced to [Power on] (POn). The [Cold stator resist.] (rSC) parameter remains at [Init] (InIt) as long as the measurement has not been performed. Value BBBB can be forced or changed using the jog dial (1). 		[No] (nO)

(1) Procedure:



- Check that the motor is cold.
- Disconnect the cables from the motor terminals.
- Measure the resistance between 2 of the motor terminals (U. V. W.) without modifying its connection.
- Use the jog dial to enter half the measured value.
- Increase the factory setting of [IR compensation] (UFR), page 33, to 100% rather than 20%.

Note: Do not use [Cold stator resist.] (rSC) if it is not set to [No] (nO) or = [Power on] (POn) with catch on the fly ([CATCH ON THE FLY] (FLr-), page 93).

Code	Description	Adjustment range	Factory setting
<p>tun</p> <p>no</p> <p>YES</p> <p>done</p> <p>run</p> <p>pon</p> <p>LI1</p> <p>to</p> <p>LI6</p>	<p><input type="checkbox"/> [Auto tuning]</p> <p>⚠ ⚠ DANGER</p> <p>HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH</p> <ul style="list-style-type: none"> During auto-tuning the motor operates at nominal current. Do not work on the motor during auto-tuning. <p>Failure to follow these instructions will result in death or serious injury.</p> <p>⚠ WARNING</p> <p>LOSS OF CONTROL</p> <ul style="list-style-type: none"> It is essential that the [Rated motor volt.] (UnS), [Rated motor freq.] (FrS), [Rated motor freq.] (nCr), [Rated motor speed] (nSP), [Motor 1 Cosinus Phi.] (COS) parameters are configured correctly before starting auto-tuning. When one or more parameters have been changed after auto-tuning has been performed, [Auto-tuning] (tUn) will return [No] (nO) and the procedure will have to be repeated. <p>Failure to follow these instructions can result in death, serious injury, or equipment damage.</p> <ul style="list-style-type: none"> <input type="checkbox"/> [No] (nO): Auto-tuning not performed <input type="checkbox"/> [Yes] (YES): Auto-tuning is performed as soon as possible, then the parameter automatically changes to [Done] (dOnE) or [No] (nO) in the event that Auto-tuning is not successful [AUTO TUNING FAULT] (tnF) is displayed if [Autotune fault mgt] (tnL) = [Yes] (YES), page 95). <input type="checkbox"/> [Done] (dOnE): Use of the values given the last time auto-tuning was performed <input type="checkbox"/> [Drv running] (rUn): Auto-tuning is performed every time a run command is sent. <input type="checkbox"/> [Power on] (POn): Auto-tuning is performed on every power-up. <input type="checkbox"/> [LI1] to [LI16] (LI1) to (LI6): Auto-tuning is performed on the transition from 0 → 1 of a logic input assigned to this function. <p>⚠ ⚠ DANGER</p> <p>HAZARD OF ELECTRIC SHOCK OR ARC FLASH</p> <p>When [Auto tuning] (tUn) is set [Power on] (POn), Auto tune will be performed every time the power will be switched on.</p> <ul style="list-style-type: none"> Check this action will not endanger personnel or equipment in any way. <p>Failure to follow these instructions will result in death or serious injury.</p> <p>Note:</p> <p>[Auto-tuning] (tUn) is forced to [Power on] (POn) if [Cold stator resist.] (rSC) = [Init] (InIt).</p> <p>Auto-tuning is only performed if no command has been activated. If a "freewheel stop" or "fast stop" function is assigned to a logic input, this input must be set to 1 (active at 0).</p> <p>Auto-tuning may take 1 to 2 seconds. Do not interrupt the process. Wait for the display to change to [Done] (dOnE) or [No] (nO).</p>		[No] (nO)
<p>tus</p> <p>tAb</p> <p>PEnd</p> <p>ProG</p> <p>FAiL</p> <p>done</p> <p>Strd</p> <p>CUS</p>	<p><input type="checkbox"/> [Auto tuning state]</p> <p>(For information only, cannot be modified)</p> <ul style="list-style-type: none"> <input type="checkbox"/> [Not done] (tAb): The default stator resistance value is used to control the motor. <input type="checkbox"/> [Pending] (PEnd): Auto-tuning has been requested but not yet performed. <input type="checkbox"/> [In Progress] (ProG): Auto-tuning in progress. <input type="checkbox"/> [Failed] (FAiL): Auto-tuning was unsuccessful. <input type="checkbox"/> [Done] (dOnE): The stator resistance measured by the auto-tuning function is used to control the motor. <input type="checkbox"/> [Entered R1] (Strd): The cold state stator resistance ([Cold stator resist.] (rSC) which is not set to [No] (nO)) is used to control the motor. <input type="checkbox"/> [Customized] (CUS): The value of [Cold stator resist.] (rSC) is set manually. 		[Not done] (tAb)

[MOTOR CONTROL] (drC-) menu

REF -
SEt -
drC -
r - 0 -
CLL -
Fun -
FLt -
COP -
SUP -

Code	Description	Adjustment range	Factory setting
uFt L P n nLd	<input type="checkbox"/> [U/F mot 1 selected] <input type="checkbox"/> [Cst. torque] (L): Constant torque for motors connected in parallel or special motors. <input type="checkbox"/> [Var. torque] (P): Variable torque for pump and fan applications. <input type="checkbox"/> [SVC] (n): Sensorless flux vector control for constant torque applications. <input type="checkbox"/> [Energy sav.] (nLd): Energy saving, for variable torque applications not requiring high dynamics (behaves in a similar way to the [Var. torque] (P) ratio with no load and the [SVC] (n) ratio on load). Voltage 		[SVC] (n)
nrd YES nO	<input type="checkbox"/> [Noise reduction] <input type="checkbox"/> [Yes] (YES): Frequency with random modulation. <input type="checkbox"/> [No] (nO): Fixed frequency. Random frequency modulation helps to prevent any resonance which may occur at a fixed frequency.		[Yes] (YES)
SFr	<input type="checkbox"/> [Switching freq.] (1) The frequency can be adjusted to reduce the noise generated by the motor. If the frequency has been set to a value higher than 4 kHz, in the event of excessive temperature rise, the drive will automatically reduce the switching frequency and increase it again once the temperature has returned to normal.	2.0 to 16 kHz	4 kHz
tFr	<input type="checkbox"/> [Max frequency] The factory setting is 60 Hz, or preset to 72 Hz if [Standard mot. freq] (bFr) is set to 60 Hz.	10 to 500 Hz	60 Hz
SrF nO YES	<input type="checkbox"/> [Speed loop filter] <input type="checkbox"/> [No] (nO): The speed loop filter is active (helps to prevent the reference being exceeded). <input type="checkbox"/> [Yes] (YES): The speed loop filter is suppressed (in position control applications, this reduces the response time and the reference may be exceeded). 		[No] (nO):

(1) Parameter can also be accessed in the [SETTINGS] (SEt-) menu.

[MOTOR CONTROL] (drC-) menu

Code	Description	Adjustment range	Factory setting
SCS no Set 2 s	<input type="checkbox"/> [Saving config.] <input type="checkbox"/> [No] (nO): Function inactive <input type="checkbox"/> [Config 1] (Str1): Saves the current configuration (but not the result of auto-tuning) to EEPROM. [Saving config.] (SCS) automatically switches to [No] (nO) as soon as the save has been performed. This function is used to keep another configuration in reserve, in addition to the current configuration. When drives leave the factory the current configuration and the backup configuration are both initialized with the factory configuration. <ul style="list-style-type: none"> If the ATV31 remote display terminal option is connected to the drive, the following additional selection options will appear: [File 1] (FIL1), [File 2] (FIL2), [File 3] (FIL3), [File 4] (FIL4) (files available in the remote display terminal's EEPROM memory for saving the current configuration). They can be used to store between 1 and 4 different configurations which can also be stored on or even transferred to other drives of the same rating. [Saving config.] (SCS) automatically switches to [No] (nO) as soon as the save has been performed.	(1)	[No] (nO)
CFG 2 s StS Std	<input type="checkbox"/> [Macro configuration] <div style="background-color: black; color: white; text-align: center; padding: 5px;">⚠ DANGER</div> <div style="background-color: yellow; padding: 10px;"> UNINTENDED EQUIPMENT OPERATION Check that the selected macro configuration is compatible with the wiring diagram used. Failure to follow these instructions will result in death or serious injury. </div> Choice of source configuration. <input type="checkbox"/> [Start/Stop] (StS): Start/stop configuration Identical to the factory configuration apart from the I/O assignments: <ul style="list-style-type: none"> Logic inputs: <ul style="list-style-type: none"> LI1, LI2 (reversing): 2-wire transition detection control, LI1 = run forward, LI2 = run reverse LI3 to LI6: Inactive (not assigned) Analog inputs: <ul style="list-style-type: none"> AI1: Speed reference 0-10 V AI2, AI3: Inactive (not assigned) Relay R1: The contact opens in the event of a detected fault (or drive off). Relay R2: Inactive (not assigned) Analog output AOC: 0-20 mA, inactive (not assigned) <input type="checkbox"/> [Factory set.] (Std): Factory configuration (see page 11). Note: The assignment of [Macro configuration] (CFG) results directly in a return to the selected configuration.	(1)	[Factory set.] (Std)

(1) [Saving config.] (SCS), [Macro configuration] (CFG), and [Restore config.] (FCS) can be accessed from several configuration menus, but they apply to all menus and parameters.


(2) Parameter can also be accessed in the [SETTINGS] (SEt-) menu.



The jog dial (ENT) needs to be pressed and held down (for 2 s) to change the assignment for this parameter.

[MOTOR CONTROL] (drC-) menu

REF -
SEt -
drC -
r - D -
CtL -
Fun -
FLt -
Cn -
SUP -

Code	Description	Adjustment range	Factory setting
FCS	<input type="checkbox"/> [Restore config.]	(1)	[No] (nO)
 2 s	<div style="background-color: #f0f0f0; padding: 10px; border: 1px solid #ccc;"> <p style="text-align: center;">⚠ DANGER</p> <p>UNINTENDED EQUIPMENT OPERATION</p> <p>Check that the changes made to the current configuration are compatible with the wiring diagram used.</p> <p>Failure to follow these instructions will result in death or serious injury.</p> </div> <div style="margin-top: 10px;"> <p><input type="checkbox"/> [No] (nO): Function inactive.</p> <p><input type="checkbox"/> [Internal 1] (rEC1): The current configuration becomes identical to the backup configuration previously saved by [Saving config.] (SCS) = [Config 1] (Str1). [Internal 1] (rEC1) is only visible if the backup has been carried out. [Restore config.] (FCS) automatically switches to [No] (nO) as soon as this action has been performed.</p> <p><input type="checkbox"/> [Factory Set.] (InI): The current configuration is replaced by the configuration selected by the [Macro configuration] (CFG) parameter (2). [Restore config.] (FCS) automatically switches to [No] (nO) as soon as this action has been performed.</p> <p>If the ATV31 remote display terminal option is connected to the drive (3), the following additional selection options appear, as long as the corresponding files in the remote display terminal's EEPROM memory have been loaded (0 to 4 files): [File 1] (FIL1), [File 2] (FIL2), [File 3] (FIL3), [File 4] (FIL4). They enable the current configuration to be replaced with one of the 4 configurations that may be loaded on the remote display terminal.</p> <p>[Restore config.] (FCS) automatically switches to [No] (nO) as soon as this action has been performed.</p> <p>Note: If nAd appears on the display briefly before the parameter switches to [No] (nO), this means that the configuration transfer is not possible and has not been performed (different drive ratings, for example). If nEr appears on the display briefly before the parameter switches to [No] (nO), this means that an invalid configuration transfer has occurred and that the factory settings will need to be restored using [Factory Set.] (InI).</p> <p>In both cases, check the configuration to be transferred before trying again.</p> </div>		

- (1) [Saving config.] (SCS), [Macro configuration] (CFG), and [Restore config.] (FCS) can be accessed from several configuration menus, but they apply to all menus and parameters.
- (2) The following parameters are not modified by this function; they retain their configuration:
- [Standard mot. freq] (bFr), page 41
 - [HMI command] (LCC), page 61
 - [PIN code 1] (COd), (terminal access code), page 103
 - The parameters in the [COMMUNICATION] (COM-) menu
 - The parameters in the [MONITORING] (SUP-) menu
- (3) Options [File 1] (FIL1) to [File 4] (FIL4) continue to be displayed on the drive, even after the ATV31 remote terminal has been disconnected.






The jog dial (ENT) needs to be pressed and held down (for 2 s) to change the assignment for this parameter.

[INPUTS / OUTPUTS CFG] (I-O-) menu

REF -
SEt -
drC -
I-O -
CLL -
Fun -
FLt -
Cof -
SUP -

Code	Description	Adjustment range	Factory setting
rrS	<input type="checkbox"/> [Reverse assign.] If [Reverse assign.] (rrS) = [No] (nO), run reverse remains active by means of negative voltage on AI2, for example. <input type="checkbox"/> [No] (nO): Not assigned <input type="checkbox"/> [LI1] (LI1): Logic input LI1 <input type="checkbox"/> [LI2] (LI2): Logic input LI2 can be accessed if [2/3 wire control] (tCC) = [2 wire] (2C), page 47. <input type="checkbox"/> [LI3] (LI3): Logic input LI3 <input type="checkbox"/> [LI4] (LI4): Logic input LI4 <input type="checkbox"/> [LI5] (LI5): Logic input LI5 <input type="checkbox"/> [LI6] (LI6): Logic input LI6		[LI2] (LI2)
CrL3	<input type="checkbox"/> [AI3 min. value]	0 to 20 mA	4 mA
CrH3	<input type="checkbox"/> [AI3 max. value] These two parameters are used to configure the input for 0-20 mA, 4-20 mA, 20-4 mA, etc. Frequency <div> </div>	4 to 20 mA	20 mA
AO1t	<input type="checkbox"/> [AO1 Type] This parameter is not visible when a communication card is connected to the product. <input type="checkbox"/> [Current] (OA): 0 - 20 mA configuration (use terminal AOC) <input type="checkbox"/> [Cur. 4-20] (4A): 4 - 20 mA configuration (use terminal AOC) <input type="checkbox"/> [Voltage] (10U): 0 - 10 V configuration (use terminal AOV)		[Current](OA)
do	<input type="checkbox"/> [Analog./logic output] This parameter is not visible when a communication card is connected to the product. <input type="checkbox"/> [No] (nO): Not assigned <input type="checkbox"/> [I motor] (OCr): Motor current. 20 mA or 10 V corresponds to twice the nominal drive current. <input type="checkbox"/> [Motor freq.] (Ofr): Motor frequency. 20 mA or 10 V corresponds to the maximum frequency [Max frequency] (tFr), page 44. <input type="checkbox"/> [Motor torq.] (Otr): Motor torque. 20 mA or 10 V corresponds to twice the nominal motor torque. <input type="checkbox"/> [P. supplied] (OPr): Power supplied by the drive. 20 mA or 10 V corresponds to twice the nominal drive power. Making the following assignments (1) will transform the analog output to a logic output (see diagram in the Installation Manual): <input type="checkbox"/> [Drive fault] (FLt): Fault detected <input type="checkbox"/> [Drv running] (rUn): Drive running <input type="checkbox"/> [Freq. limit] (FtA): Frequency threshold reached ([Freq. threshold] (Ftd) parameter in the [SETTINGS] (SEt-) menu, page 39) <input type="checkbox"/> [HSP limit] (FLA): [High speed] (HSP) reached <input type="checkbox"/> [I attained] (CtA): Current threshold reached ([Current threshold] (Ctd) parameter in the [SETTINGS] (SEt-) menu, page 39) <input type="checkbox"/> [Freq. ref.] (SrA): Frequency reference reached <input type="checkbox"/> [Drv thermal] (tSA): Motor thermal threshold reached ([Motor therm. level] (ttd) parameter in the [SETTINGS] (SEt-) menu, page 39) <input type="checkbox"/> [Brake seq] (bLC): Brake sequence (for information, as this assignment can only be activated or deactivated from the [APPLICATION FUNCT.] (FUN-) menu, page 84) <input type="checkbox"/> [No 4-20mA] (APL): Loss of 4-20 mA signal, even if [4-20mA loss] (LFL) = [No] (nO), page 95 The logic output is in state 1 (24 V) when the selected assignment is active, with the exception of [Drive fault] (FLt) (state 1 if the drive operation is normal). Note: (1) With these assignments, configure [AO1 Type] (AO1t) = [Current] (OA).		[No] (nO)

[INPUTS / OUTPUTS CFG] (I-O-) menu


Code	Description	Adjustment range	Factory setting
r 1 n o F L t r u n F t A F L A C t A S r A t S A A P L L I 1 to L I 6	<input type="checkbox"/> [R1 Assignment] This parameter is not visible when a communication card is connected to the product. <input type="checkbox"/> [No] (nO): Not assigned <input type="checkbox"/> [No drive flt] (FLt): No drive detected fault <input type="checkbox"/> [Drv running] (rUn): Drive running <input type="checkbox"/> [Freq.Th.att.] (FtA): Frequency threshold reached ([Freq. threshold] (Ftd) parameter in the [SETTINGS] (SEt-) menu, page 39) <input type="checkbox"/> [HSP attain.] (FLA): [High speed] (HSP) reached <input type="checkbox"/> [I attained] (CtA): Current threshold reached ([Current threshold] (Ctd) parameter in the [SETTINGS] (SEt-) menu, page 39) <input type="checkbox"/> [Freq.ref.att] (SrA): Frequency reference reached <input type="checkbox"/> [Th.mot. att.] (tSA): Motor thermal threshold reached ([Motor therm. level] (ttd) parameter in the [SETTINGS] (SEt-) menu, page 39) <input type="checkbox"/> [4-20mA] (APL): Loss of 4-20 mA signal, even if [4-20mA loss] (LFL) = [No] (nO), page 95 <input type="checkbox"/> [LI1] to [LI6] (LI1) to (LI6): Returns the value of the selected logic input The relay is energized when the selected assignment is active, with the exception of [No drive flt] (FLt) (energized if the drive has not detected a fault).		[No drive flt] (FLt)
r 2 n o F L t r u n F t A F L A C t A S r A t S A b L C A P L L I 1 to L I 6	<input type="checkbox"/> [R2 Assignment] <input type="checkbox"/> [No] (nO): Not assigned <input type="checkbox"/> [No drive flt] (FLt): No drive detected fault <input type="checkbox"/> [Drv running] (rUn): Drive running <input type="checkbox"/> [Freq.Th.att.] (FtA): Frequency threshold reached ([Freq. threshold] (Ftd) parameter in the [SETTINGS] (SEt-) menu, page 39) <input type="checkbox"/> [HSP attain.] (FLA): [High speed] (HSP) reached <input type="checkbox"/> [I attained] (CtA): Current threshold reached ([Current threshold] (Ctd) parameter in the [SETTINGS] (SEt-) menu, page 39) <input type="checkbox"/> [Freq.ref.att] (SrA): Frequency reference reached <input type="checkbox"/> [Th.mot. att.] (tSA): Motor thermal threshold reached ([Motor therm. level] (ttd) parameter in the [SETTINGS] (SEt-) menu, page 39) <input type="checkbox"/> [Brk control] (bLC): Brake sequence (for information, as this assignment can only be activated or deactivated from the [APPLICATION FUNCT.] (FUn-) - menu, page 84) <input type="checkbox"/> [4-20mA] (APL): Loss of 4-20 mA signal, even if [4-20mA loss] (LFL) = [No] (nO), page 95 <input type="checkbox"/> [LI1] to [LI6] (LI1) to (LI6): Returns the value of the selected logic input The relay is energized when the selected assignment is active, with the exception of [No drive flt] (FLt) (energized if the drive has not detected a fault).		[No] (nO)
S C S  2 s	<input type="checkbox"/> [Saving config.] (1) See page 45.		nO
C F G  2 s	<input type="checkbox"/> [Macro configuration] (1) See page 45.		Std
F C S  2 s	<input type="checkbox"/> [Restore config.] (1) See page 46.		nO

(1) [Saving config.] (SCS), [Macro configuration] (CFG), and [Restore config.] (FCS) can be accessed from several configuration menus, but they apply to all menus and parameters.



The jog dial (ENT) needs to be pressed and held down (for 2 s) to change the assignment for this parameter.

REF -
SEt -
drC -
I - D -
CLL -
Fun -
FLt -
CoP -
SuP -



Run commands (forward, reverse, etc.) and references can be sent using the following channels:


The [ACCESS LEVEL] (LAC) parameter in the [COMMAND] (CtL-) menu, page [58](#), can be used to select priority modes for the control and reference channels. It has 3 function levels:

- 50

[COMMAND] (CtL-) menu

These channels can be combined in order of priority if [ACCESS LEVEL] (LAC) = [Level 1] (L1) or [Level 2] (L2).

Highest priority to lowest priority: Forced local mode, Network, Modbus, Remote display terminal, Terminals/Keypad (from right to left in the diagram below)




See the detailed block diagrams on pages 53 and 54.

- On ATV312 drives, in factory settings mode, control and reference are managed by the terminals.
- With a remote terminal display, if [HMI command] (LCC) = [Yes] (YES) ([COMMAND] (CtL-) menu), control and reference are managed by the remote terminal display (reference via [HMI Frequency ref.] (LFr) in the [SETTINGS] (SEt-) menu).

The channels can be combined by configuration if [ACCESS LEVEL] (LAC) = [Level 3] (L3).

Combined control and reference ([Profile] (CHCF) parameter = [Not separ.] (SIM)):




The [Ref. 2 switching] (rFC) parameter can be used to select the [Ref.1 channel] (Fr1) or [Ref.2 channel] (Fr2) channel, or to configure a logic input or a control word bit for remote switching of either one.

See the detailed block diagrams on pages 55 and 57.

[COMMAND] (CtL-) menu


REF - Separate control and reference ([Profile] (CHCF) parameter = [Separate] (SEP)):

SEt - Reference



The [Ref. 2 switching] (rFC) parameter can be used to select the [Ref.1 channel] (Fr1) or [Ref.2 channel] (Fr2) channel, or to configure a logic input or a control word bit for remote switching of either one.

Control




The [Cmd switching] (CCS) parameter, page 60, can be used to select the [Cmd channel 1] (Cd1) or [Cmd channel 2] (Cd2) channel, or to configure a logic input or a control bit for remote switching of either one.

See the detailed block diagrams on pages 55 and 56.

[COMMAND] (CtL-) menu

Reference channel for [ACCESS LEVEL] (LAC) = [Level 1] (L1) or [Level 2] (L2)




Function can be accessed for
 [ACCESS LEVEL] (LAC) = [Level 2] (L2)


[COMMAND] (CtL-) menu

Control channel for [ACCESS LEVEL] (LAC) = [Level 1] (L1) or [Level 2] (L2)

The [Forced local assign.] (FLO) parameter, page 99, the [HMI command] (LCC) parameter, page 61, and the selection of the Modbus bus or network are common to the reference and control channels.
Example: If [HMI command] (LCC) = [Yes] (YES), the command and reference are given by the remote display terminal.




Key:



Reference channel for [ACCESS LEVEL] (LAC) = [Level 3] (L3)

Note: In order to configure the +/- speed command ([Ref.1 channel] (Fr1) = [+/- SPEED] (UPdt) or [+/-spd HMI] (UPdH)), the SA2/SA3 summing inputs and the preset speeds must be deconfigured beforehand.



Example: If the [Ref.1 channel] (Fr1) reference = [AI1] (AI1) (analog input at the terminals), control is via LI (logic input at the terminals).



EFF -

SEE -

 $dr[-$

- 0 -

CEL -



FLE -

Соп-

 $S \cup P -$

[COMMAND] (CtL-) menu

rEF -
SEt -
drC -
-D -
CtL -
Fun -
FLt -
Cn -
SUP -

Code	Description	Adjustment range	Factory setting
rFC Fr1 Fr2 L11 L12 L13 L14 L15 L16 C111 C112 C113 C114 C115 C211 C212 C213 C214 C215	[Ref. 2 switching] The [Ref. 2 switching] (rFC) parameter can be used to select the [Ref.1 channel] (Fr1) or [Ref.2 channel] (Fr2) channel, or to configure a logic input or a control word bit for remote switching of [Ref.1 channel] (Fr1) or [Ref.2 channel] (Fr2). <input type="checkbox"/> [ch1 active] (Fr1): Reference = reference 1 <input type="checkbox"/> [ch1 active] (Fr2): Reference = reference 2 <input type="checkbox"/> [LI1] (L11): Logic input LI1 <input type="checkbox"/> [LI2] (L12): Logic input LI2 <input type="checkbox"/> [LI3] (L13): Logic input LI3 <input type="checkbox"/> [LI4] (L14): Logic input LI4 <input type="checkbox"/> [LI5] (L15): Logic input LI5 <input type="checkbox"/> [LI6] (L16): Logic input LI6 If [ACCESS LEVEL] (LAC) = [Level 3] (L3), the following additional assignments are possible: <input type="checkbox"/> [C111] (C111): Bit 11 of Modbus control word <input type="checkbox"/> [C112] (C112): Bit 12 of Modbus control word <input type="checkbox"/> [C113] (C113): Bit 13 of Modbus control word <input type="checkbox"/> [C114] (C114): Bit 14 of Modbus control word <input type="checkbox"/> [C115] (C115): Bit 15 of Modbus control word <input type="checkbox"/> [C211] (C211): Bit 11 of network control word <input type="checkbox"/> [C212] (C212): Bit 12 of network control word <input type="checkbox"/> [C213] (C213): Bit 13 of network control word <input type="checkbox"/> [C214] (C214): Bit 14 of network control word <input type="checkbox"/> [C215] (C215): Bit 15 of network control word The reference can be switched with the drive running. [Ref.1 channel] (Fr1) is active when the logic input or control word bit is at state 0. [Ref.2 channel] (Fr2) is active when the logic input or control word bit is at state 1.		[ch1 active] (Fr1)
CHCF Sin SEP	[Profile] (control channels separated from reference channels) Parameter can be accessed if [ACCESS LEVEL] (LAC) = [Level 3] (L3), page 58. <input type="checkbox"/> [Not separ.] (SIM): Combined <input type="checkbox"/> [Separate] (SEP): Separate		[Not separ.] (SIM)
Cd1 ★ tEr LoC LCC ndb nEt	[Cmd channel 1] Parameter can be accessed if [Profile] (CHCF) = [Separate] (SEP), page 59, and [ACCESS LEVEL] (LAC) = [Level 3] (L3), page 58. <input type="checkbox"/> [Terminal] (tEr): Control via terminals <input type="checkbox"/> [Local] (LoC): Control via keypad <input type="checkbox"/> [Remot. HMI] (LCC): Control via remote display terminal <input type="checkbox"/> [Modbus] (Mdb): Control via Modbus <input type="checkbox"/> [Com. card] (nEt): Control via the network		[Terminal] (tEr)



These parameters only appear if the corresponding function has been selected in another menu. When the parameters can also be accessed and set from within the configuration menu for the corresponding function, their description is detailed in these menus, on the pages indicated, to aid programming.

[COMMAND] (CtL-) menu

REF -
SEt -
drC -
i-D -
CtL -
Fun -
FLt -
CoP -
SuP -





Code	Description	Adjustment range	Factory setting
<p>Cd2</p> <p>★</p> <p>tEr</p> <p>LoC</p> <p>LCC</p> <p>ndb</p> <p>nEt</p>	<p><input type="checkbox"/> [Cmd channel 2]</p> <p>Parameter can be accessed if [Profile] (CHCF) = [Separate] (SEP), page 59, and [ACCESS LEVEL] (LAC) = [Level 3] (L3), page 58.</p> <p><input type="checkbox"/> [Terminal] (tEr): Control via terminals</p> <p><input type="checkbox"/> [Local] (LOC): Control via keypad</p> <p><input type="checkbox"/> [Remot. HMI] (LCC): Control via remote display terminal</p> <p><input type="checkbox"/> [Modbus] (Mdb): Control via Modbus</p> <p><input type="checkbox"/> [Com. card (nEt): Control via the network</p>		[Modbus] (Mdb)
<p>CCS</p> <p>★</p> <p>Cd1</p> <p>Cd2</p> <p>L11</p> <p>L12</p> <p>L13</p> <p>L14</p> <p>L15</p> <p>L16</p> <p>C111</p> <p>C112</p> <p>C113</p> <p>C114</p> <p>C115</p> <p>C211</p> <p>C212</p> <p>C213</p> <p>C214</p> <p>C215</p>	<p><input type="checkbox"/> [Cmd switching]</p> <p>Parameter can be accessed if [Profile] (CHCF) = [Separate] (SEP), page 59, and [ACCESS LEVEL] (LAC) = [Level 3] (L3), page 58.</p> <p>The [Cmd switching] (CCS) parameter can be used to select the [Cmd channel 1] (Cd1) or [Cmd channel 2] (Cd2) channel, or to configure a logic input or a control word bit for remote switching of [Cmd channel 1] (Cd1) or [Cmd channel 2] (Cd2).</p> <p><input type="checkbox"/> [ch1 active] (Cd1): Control channel = channel 1</p> <p><input type="checkbox"/> [ch2 active] (Cd2): Control channel = channel 2</p> <p><input type="checkbox"/> [LI1] (LI1): Logic input LI1</p> <p><input type="checkbox"/> [LI2] (LI2): Logic input LI2</p> <p><input type="checkbox"/> [LI3] (LI3): Logic input LI3</p> <p><input type="checkbox"/> [LI4] (LI4): Logic input LI4</p> <p><input type="checkbox"/> [LI5] (LI5): Logic input LI5</p> <p><input type="checkbox"/> [LI6] (LI6): Logic input LI6</p> <p><input type="checkbox"/> [C111] (C111): Bit 11 of Modbus control word</p> <p><input type="checkbox"/> [C112] (C112): Bit 12 of Modbus control word</p> <p><input type="checkbox"/> [C113] (C113): Bit 13 of Modbus control word</p> <p><input type="checkbox"/> [C114] (C114): Bit 14 of Modbus control word</p> <p><input type="checkbox"/> [C115] (C115): Bit 15 of Modbus control word</p> <p><input type="checkbox"/> [C211] (C211): Bit 11 of network control word</p> <p><input type="checkbox"/> [C212] (C212): Bit 12 of network control word</p> <p><input type="checkbox"/> [C213] (C213): Bit 13 of network control word</p> <p><input type="checkbox"/> [C214] (C214): Bit 14 of network control word</p> <p><input type="checkbox"/> [C215] (C215): Bit 15 of network control word</p> <p>Channel 1 is active when the input or control word bit is at state 0, Channel 2 is active when the input or control word bit is at state 1.</p>		[ch1 active] (Cd1)
<p>CoP</p> <p>nO</p> <p>SP</p> <p>Cd</p> <p>ALL</p>	<p><input type="checkbox"/> [Copy channel 1<>2] (copy only in this direction)</p> <p>⚠ DANGER</p> <p>UNINTENDED EQUIPMENT OPERATION</p> <p>Copying the command and/or reference can change the direction of rotation.</p> <ul style="list-style-type: none"> Check that this is safe. <p>Failure to follow these instructions will result in death or serious injury.</p> <p>Parameter can be accessed if [ACCESS LEVEL] (LAC) = [Level 3] (L3), page 58.</p> <p><input type="checkbox"/> [No] (nO): No copy</p> <p><input type="checkbox"/> [Reference] (SP): Copy reference</p> <p><input type="checkbox"/> [Command] (Cd): Copy control</p> <p><input type="checkbox"/> [Cmd + ref.] (ALL): Copy control and reference</p> <ul style="list-style-type: none"> If channel 2 is controlled via the terminals, channel 1 control is not copied. If the channel 2 reference is set via AI1, AI2, AI3 or AIU1, the channel 1 reference is not copied. The reference copied is [Frequency ref.] (FrH) (before ramp), unless the channel 2 reference is set via +/- speed. <p>In this case, the reference copied is [Output frequency] (rFr) (after ramp).</p> <p>Note: Copying the control and/or reference can change the direction of rotation.</p>		[No] (nO)



These parameters only appear if the corresponding function has been selected in another menu. When the parameters can also be accessed and set from within the configuration menu for the corresponding function, their description is detailed in these menus, on the pages indicated, to aid programming.

[COMMAND] (CtL-) menu

rEF -
SEt -
drC -
I - D -
CtL -
Fun -
FLt -
COP -
SUP -

Code	Description	Adjustment range	Factory setting
LCC nO YES	<input type="checkbox"/> [HMI command] Parameter can only be accessed using a remote display terminal, and for [ACCESS LEVEL] (LAC) = [Level 1] (L1) or [Level 2] (L2), page 58. <input type="checkbox"/> [No] (nO): Function inactive <input type="checkbox"/> [Yes] (YES): Enables control of the drive using the STOP/RESET, RUN and FWD/REV buttons on the display terminal. Here, the speed reference is given by the [HMI Frequency ref.] (LFr) parameter in the [SETTINGS] (SEt-) menu. Only the freewheel stop, fast stop and DC injection stop commands remain active on the terminals. If the drive/terminal connection is cut or if the terminal has not been connected, the drive detects a fault and locks in [MODBUS FAULT] (SLF).		[No] (nO)
PSt  2 s nO YES	<input type="checkbox"/> [Stop Key priority] This parameter can be used to activate or deactivate the stop button on the drive and the remote terminals. The stop button will be deactivated if the active control channel is different from that on the integrated display terminal or remote terminals. <div style="border: 1px solid black; padding: 5px; text-align: center;"> ⚠ WARNING LOSS OF CONTROL You are going to disable the stop button located on the drive and remote display Do not select "nO" unless exterior stopping methods exist. Failure to follow these instructions can result in death, serious injury, or equipment damage. </div> <input type="checkbox"/> [No] (nO): Function inactive <input type="checkbox"/> [Yes] (YES): STOP key priority		[Yes] (YES)
rot dFr drS bot	<input type="checkbox"/> [Rotating direction] This parameter is only visible if [Ref.1 channel] (Fr1), page 29, or [Ref.2 channel] (Fr2), page 58, are assigned to LCC or RIU I . Direction of operation authorized for the RUN key on the keypad or the RUN key on the remote display terminal. <input type="checkbox"/> [Forward] (dFr): Forward <input type="checkbox"/> [Reverse] (drS): Reverse <input type="checkbox"/> [Both] (bOt): Both directions are authorized.		[Forward] (dFr)
SCS  2 s	<input type="checkbox"/> [Saving config.] See page 45.	(1)	nO
CFG  2 s	<input type="checkbox"/> [Macro configuration] See page 45.	(1)	Std
FCS  2 s	<input type="checkbox"/> [Restore config.] See page 46.	(1)	nO




The jog dial (ENT) needs to be pressed and held down (for 2 s) to change the assignment for this parameter.

(1) [Saving config.] (SCS), [Macro configuration] (CFG), and [Restore config.] (FCS) can be accessed from several configuration menus, but they apply to all menus and parameters.

[APPLICATION FUNCT.] (FUn-) menu

rEF -
SEt -
drC -
rD -
CLtL -
FUn -
FLt -
CaP -
SuP -



The parameters can only be modified when the drive is stopped and no run command is present.
On the optional remote display terminal, this menu can be accessed with the switch in the position.

Some functions have numerous parameters. In order to clarify programming and avoid having to scroll through endless parameters, these functions have been grouped in submenus.
Like menus, submenus are identified by a dash after their code: **PSS -** for example.

Note: There may be an incompatibility between functions (see the incompatibility table, page 21). In this case, the first function configured will prevent the remainder being configured.

Code	Name/Description	Adjustment range	Factory setting
rPC -	[RAMPS]		
rPt	<input type="checkbox"/> [Ramp type]		[Linear] (LIn)
LIn	Defines the shape of the acceleration and deceleration ramps		
S	<input type="checkbox"/> [Linear] (LIn): Linear		
U	<input type="checkbox"/> [S ramp] (S): S ramp		
CUS	<input type="checkbox"/> [U ramp] (U): U ramp		
	<input type="checkbox"/> [Customized] (CUS): Customized		
	S ramps		
		The rounding coefficient is fixed, where $t_2 = 0.6 \times t_1$ and t_1 = set ramp time.	
	U ramps		
		The rounding coefficient is fixed, where $t_2 = 0.5 \times t_1$ and t_1 = set ramp time.	
	Customized ramps		
		tA1 : Adjustable from 0 to 100% (of ACC or AC2) tA2 : Adjustable from 0 to (100% - tA1) (of ACC or AC2) tA3 : Adjustable from 0 to 100% (of DEC or DE2) tA4 : Adjustable from 0 to (100% - tA3) (of DEC or DE2)	

[APPLICATION FUNCT.] (FUn-) menu

Code	Name/Description	Adjustment range	Factory setting
rPC-	[RAMPS] (continued)		
LA1 ★	<input type="checkbox"/> [Begin Acc round] Parameter can be accessed if the [Ramp type] (rPt) = [Customized] (CUS), page 62.	0 to 100	10
LA2 ★	<input type="checkbox"/> [End Acc round] Parameter can be accessed if the [Ramp type] (rPt) = [Customized] (CUS), page 62.	0 to (100-tA1)	10
LA3 ★	<input type="checkbox"/> [Begin Dec round] Parameter can be accessed if the [Ramp type] (rPt) = [Customized] (CUS), page 62.	0 to 100	10
LA4 ★	<input type="checkbox"/> [End Dec round] Parameter can be accessed if the [Ramp type] (rPt) = [Customized] (CUS), page 62.	0 to (100-tA3)	10
lnr 0.01 0.1 1	<input type="checkbox"/> [Ramp increment] <input type="checkbox"/> [0.01] (0.01): Ramp can be set between 0.05 s and 327.6 s. <input type="checkbox"/> [0.1] (0.1): Ramp can be set between 0.1 s and 3,276 s. <input type="checkbox"/> [1] (1): Ramp can be set between 1 s and 32,760 s (1). This parameter applies to the [Acceleration] (ACC), [Deceleration] (dEC), [Acceleration 2] (AC2), and [Deceleration 2] (dE2) parameters. Note: Changing the [Ramp increment] (lnr) parameter causes the settings for the [Acceleration] (ACC), [Deceleration] (dEC), [Acceleration 2] (AC2), and [Deceleration 2] (dE2) parameters to be modified as well.	0.01 - 0.1 - 1	0.1
ACC dEC	<input type="checkbox"/> [Acceleration] (2) <input type="checkbox"/> [Deceleration] Defined to accelerate/decelerate between 0 and the nominal frequency [Rated motor freq.] (FrS) (parameter in the [MOTOR CONTROL] (drC-) menu). Check that the value for [Deceleration] (dEC) is not too low in relation to the load to be stopped.	In accordance with lnr , page 63	3 s 3 s

(1) When values higher than 9,999 are displayed on the drive or on the remote display terminal, a point is inserted after the thousands digit.


Note:

This type of display can lead to confusion between values which have two digits after a decimal point and values higher than 9,999. Check the value of the [Ramp increment] (lnr) parameter.

Example:

- If [Ramp increment] (lnr) = 0.01, the value 15.65 corresponds to a setting of 15.65 s.
- If [Ramp increment] (lnr) = 1, the value 15.65 corresponds to a setting of 15,650 s.

(2) Parameter can also be accessed in the [SETTINGS] (SEt-) menu.



These parameters only appear if the corresponding function has been selected in another menu. When the parameters can also be accessed and set from within the configuration menu for the corresponding function, their description is detailed in these menus, on the pages indicated, to aid programming.

[APPLICATION FUNCT.] (FUn-) menu

rEF -
SEt -
drC -
rD -
CLt -
Fun -
FLt -
CoN -
SuP -

Code	Name/Description	Adjustment range	Factory setting															
rPC -	■ [RAMPS] (continued)																	
rPS no L 11 L 12 L 13 L 14 L 15 L 16 CD 11 CD 12 CD 13 CD 14 CD 15	<input type="checkbox"/> [Ramp switch ass.]		[No] (nO)															
	This function remains active regardless of the control channel.																	
	<input type="checkbox"/> [No] (nO): Not assigned																	
	<input type="checkbox"/> [LI1] (LI1): Logic input LI1																	
	<input type="checkbox"/> [LI2] (LI2): Logic input LI2																	
	<input type="checkbox"/> [LI3] (LI3): Logic input LI3																	
	<input type="checkbox"/> [LI4] (LI4): Logic input LI4																	
	<input type="checkbox"/> [LI5] (LI5): Logic input LI5																	
	<input type="checkbox"/> [LI6] (LI6): Logic input LI6																	
	If [ACCESS LEVEL] (LAC) = [Level 3] (L3), the following assignments are possible:																	
<input type="checkbox"/> [CD11] (CD11): Bit 11 of the control word from a communication network																		
<input type="checkbox"/> [CD12] (CD12): Bit 12 of the control word from a communication network																		
<input type="checkbox"/> [CD13] (CD13): Bit 13 of the control word from a communication network																		
<input type="checkbox"/> [CD14] (CD14): Bit 14 of the control word from a communication network																		
<input type="checkbox"/> [CD15] (CD15): Bit 15 of the control word from a communication network																		
[Acceleration] (ACC) and [Deceleration] (dEC) are enabled when the logic input or control word bit is at state 0. [Acceleration 2] (AC2) and [Deceleration 2] (dE2) are enabled when the logic input or control word bit is at state 1.																		
FrE	<input type="checkbox"/> [Ramp 2 threshold]	0 to 500 Hz	0 Hz															
	The 2nd ramp is switched if [Ramp 2 threshold] (FrE) is not 0 (the value 0 corresponds to the inactive function) and the output frequency is higher than [Ramp 2 threshold] (FrE). Threshold ramp switching can be combined with switching via LI or bit as follows:																	
	<table><tr><th>LI or bit</th><th>Frequency</th><th>Ramp</th></tr><tr><td>0</td><td><FrE</td><td>ACC, dEC</td></tr><tr><td>0</td><td>>FrE</td><td>AC2, dE2</td></tr><tr><td>1</td><td><FrE</td><td>AC2, dE2</td></tr><tr><td>1</td><td>>FrE</td><td>AC2, dE2</td></tr></table>			LI or bit	Frequency	Ramp	0	<FrE	ACC, dEC	0	>FrE	AC2, dE2	1	<FrE	AC2, dE2	1	>FrE	AC2, dE2
	LI or bit	Frequency	Ramp															
	0	<FrE	ACC, dEC															
	0	>FrE	AC2, dE2															
	1	<FrE	AC2, dE2															
	1	>FrE	AC2, dE2															
AC2 ★	<input type="checkbox"/> [Acceleration 2] (1)	In accordance with inr, page 63	5															
	Parameter can be accessed if [Ramp 2 threshold] (FrE) > 0, page 64, or if [Ramp switch ass.] (rPS) is assigned, page 64.																	
dE2 ★	<input type="checkbox"/> [Deceleration 2] (1)	In accordance with inr, page 63	5															
	Parameter can be accessed if [Ramp 2 threshold] (FrE) > 0, page 64, or if [Ramp switch ass.] (rPS) is assigned, page 64.																	
brA no YES	<input type="checkbox"/> [Dec ramp adapt.]		[Yes] (YES)															
	Activating this function automatically adapts the deceleration ramp, if this has been set at too low a value for the inertia of the load.																	
	<input type="checkbox"/> [No] (nO): Function inactive <input type="checkbox"/> [Yes] (YES): Function active. The function is incompatible with applications requiring: <ul style="list-style-type: none">Positioning on a rampThe use of a braking resistor (the resistor would not operate correctly) [Dec ramp adapt.] (brA) is forced to [No] (nO) if brake control [Brake assignment] (bLC) is assigned, page 84.																	

(1) Parameter can also be accessed in the [SETTINGS] (SEt-) menu.

★ These parameters only appear if the corresponding function has been selected in another menu. When the parameters can also be accessed and set from within the configuration menu for the corresponding function, their description is detailed in these menus, on the pages indicated, to aid programming.

[APPLICATION FUNCT.] (FUn-) menu

REF -
SEt -
drC -
I - D -
CLL -
Fun -
FLt -
COP -
SUP -

Code	Name/Description	Adjustment range	Factory setting
StC -	■ [STOP MODES] (continued)		
Stt	□ [Type of stop] <p>Stop mode on disappearance of the run command or appearance of a stop command.</p> <ul style="list-style-type: none"> <input type="checkbox"/> [Ramp stop] (rMP): On ramp <input type="checkbox"/> [Fast stop] (FSt): Fast stop <input type="checkbox"/> [Freewheel] (nST): Freewheel stop <input type="checkbox"/> [DC injection] (dCI): DC injection stop 		[Ramp stop] (rMP)
rNP FSt nSt dCI			
FSt	□ [Fast stop] <p>[No] (nO): Not assigned</p> <p>[LI1] (LI1): Logic input LI1</p> <p>[LI2] (LI2): Logic input LI2</p> <p>[LI3] (LI3): Logic input LI3</p> <p>[LI4] (LI4): Logic input LI4</p> <p>[LI5] (LI5): Logic input LI5</p> <p>[LI6] (LI6): Logic input LI6</p> <p>If [ACCESS LEVEL] (LAC) = [Level 3] (L3), the following assignments are possible:</p> <ul style="list-style-type: none"> <input type="checkbox"/> [CD11] (CD11): Bit 11 of the control word from a communication network <input type="checkbox"/> [CD12] (CD12): Bit 12 of the control word from a communication network <input type="checkbox"/> [CD13] (CD13): Bit 13 of the control word from a communication network <input type="checkbox"/> [CD14] (CD14): Bit 14 of the control word from a communication network <input type="checkbox"/> [CD15] (CD15): Bit 15 of the control word from a communication network <p>The stop is activated when the logic state of the input changes to 0 and the control word bit changes to 1. The fast stop is a stop on a reduced ramp via the [Ramp divider] (dCF) parameter. If the input falls back to state 1 and the run command is still active, the motor will only restart if 2-wire level control has been configured [2/3 wire control] (tCC) = [2 wire] (2C), and [2 wire type] (tCt) = [Level] (LEL) or [Fwd priority] (PFO), page 47. In other cases, a new run command must be sent.</p>		[No] (nO)
nO LI1 LI2 LI3 LI4 LI5 LI6 CD11 CD12 CD13 CD14 CD15			
dCF	□ [Ramp divider] <p>Parameter can be accessed where [Type of stop] (Stt) = [Fast stop] (FSt), page 65, and where [Fast stop] (FSt) is not [No] (nO), page 65.</p> <p>Ensure that the reduced ramp is not too low in relation to the load to be stopped.</p> <p>The value 0 corresponds to the minimum ramp.</p>	0 to 10	4
★			



These parameters only appear if the corresponding function has been selected in another menu. When the parameters can also be accessed and set from within the configuration menu for the corresponding function, their description is detailed in these menus, on the pages indicated, to aid programming.

Code	Name/Description	Adjustment range	Factory setting	
5 t C -	■ [STOP MODES] (continued)			
d C ,	❑ [DC injection assign.]		[No] (nO)	
n o L , 1 L , 2 L , 3 L , 4 L , 5 L , 6 C d 1 1 C d 1 2 C d 1 3 C d 1 4 C d 1 5	<div>⚠ WARNING</div> <div>NO HOLDING TORQUE</div> <ul style="list-style-type: none">DC injection braking does not provide any holding torque at zero speed.DC injection braking does not work when there is a loss of power or when the drive detects a fault.Where necessary, use a separate brake to maintain torque levels. <div>Failure to follow these instructions can result in death, serious injury, or equipment damage.</div> <div>Note1: This function is incompatible with the "Brake control" function (see page 21).</div> <div>Note2: The DC injection stop is not effective when the drive is stopped with the JOG function activated.</div> <div><div>❑ [No] (nO): Not assigned</div><div>❑ [LI1] (LI1): Logic input LI1</div><div>❑ [LI2] (LI2): Logic input LI2</div><div>❑ [LI3] (LI3): Logic input LI3</div><div>❑ [LI4] (LI4): Logic input LI4</div><div>❑ [LI5] (LI5): Logic input LI5</div><div>❑ [LI6] (LI6): Logic input LI6</div></div> <div>If [ACCESS LEVEL] (LAC) = [Level 3] (L3), the following assignments are possible:</div> <div><div>❑ [CD11] (CD11): Bit 11 of the control word from a communication network</div><div>❑ [CD12] (CD12): Bit 12 of the control word from a communication network</div><div>❑ [CD13] (CD13): Bit 13 of the control word from a communication network</div><div>❑ [CD14] (CD14): Bit 14 of the control word from a communication network</div><div>❑ [CD15] (CD15): Bit 15 of the control word from a communication network</div></div> <div>Braking is activated when the logic state of the input or control word bit is at 1.</div>			
	, d C	❑ [DC inject. level 1]	(1)(3)	0 to ln (2)
	★	<div>CAUTION</div> <div>RISK OF DAMAGE TO MOTOR</div> <ul style="list-style-type: none">Check that the motor will withstand this current without overheating. <div>Failure to follow these instructions can result in equipment damage.</div> <div>Parameter can be accessed if [Type of stop] (Stt) = [DC injection] (dCI), page 65, or if [DC injection assign.] (dCI) is not set to [No] (nO), page 66.</div> <div>After 5 seconds, the injection current is limited to 0.5 [Mot. therm. current] (ItH) if set to a higher value.</div>		

- (1) Parameter can also be accessed in the **[SETTINGS] (SEt-)** menu.
- (2) In corresponds to the nominal drive current indicated in the Installation Manual and on the drive nameplate.
- (3) **Note:** These settings are not related to the "automatic standstill DC injection" function.



These parameters only appear if the corresponding function has been selected in another menu. When the parameters can also be accessed and set from within the configuration menu for the corresponding function, their description is detailed in these menus, on the pages indicated, to aid programming.

[APPLICATION FUNCT.] (FUn-) menu

Code	Name/Description	Adjustment range	Factory setting
StC-	[STOP MODES] (continued)		
tdC	<input type="checkbox"/> [DC injection time 2] (1)(3)	0.1 to 30 s	0.5 s
★	<p style="text-align: center;">CAUTION</p> <p>RISK OF DAMAGE TO MOTOR</p> <ul style="list-style-type: none"> Long periods of DC injection braking can cause overheating and damage the motor. Protect the motor by avoiding long periods of DC injection braking. <p>Failure to follow these instructions can result in equipment damage.</p> <p>Parameter can be accessed if [Type of stop] (Stt) = [DC injection] (dCl) , page 65.</p>		
nSt	<input type="checkbox"/> [Freewheel stop ass.]		[No] (nO)
no	<input type="checkbox"/> [No] (nO): Not assigned <input type="checkbox"/> [LI1] (LI1): Logic input LI1 <input type="checkbox"/> [LI2] (LI2): Logic input LI2 <input type="checkbox"/> [LI3] (LI3): Logic input LI3 <input type="checkbox"/> [LI4] (LI4): Logic input LI4 <input type="checkbox"/> [LI5] (LI5): Logic input LI5 <input type="checkbox"/> [LI6] (LI6): Logic input LI6		
L, 1	<p>The stop is activated when the logic state of the input is at 0. If the input falls back to state 1 and the run command is still active, the motor will only restart if 2-wire level control has been configured. In other cases, a new run command must be sent.</p>		
L, 2			
L, 3			
L, 4			
L, 5			
L, 6			

(1) Parameter can also be accessed in the [SETTINGS] (SEt-) menu.

(2) In corresponds to the nominal drive current indicated in the Installation Manual and on the drive nameplate.

(3) **Note:** These settings are not related to the "automatic standstill DC injection" function.

★ These parameters only appear if the corresponding function has been selected in another menu. When the parameters can also be accessed and set from within the configuration menu for the corresponding function, their description is detailed in these menus, on the pages indicated, to aid programming.

[APPLICATION FUNCT.] (FUn-) menu

REF -
SEt -
drC -
i - D -
CtL -
FUn -
FLt -
Cn -
SUP -















Code	Name/Description	Adjustment range	Factory setting
AdC -	[AUTO DC INJECTION]		
AdC	<input type="checkbox"/> [Auto DC injection] <div> <p>If set to [Continuous] (Ct), this parameter causes injection current to be generated, even when there is no run command. This is not compatible with [Auto tuning] (tUn) = [Drv running] (rUn). this parameter can be changed at any time.</p> <p>⚠ ⚠ DANGER</p> <p>HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH</p> <p>When [Auto DC injection] (AdC) = [Continuous] (Ct), the injection of current is done even if a run command has not been sent.</p> <ul style="list-style-type: none"> Check this action will not endanger personnel or equipment in any way <p>Failure to follow these instructions will result in death or serious injury.</p> <p>⚠ WARNING</p> <p>NO HOLDING TORQUE</p> <ul style="list-style-type: none"> DC injection braking does not provide any holding torque at zero speed. DC injection braking does not work when there is a loss of power or when the drive detects a fault. Where necessary, use a separate brake to maintain torque levels. <p>Failure to follow these instructions can result in death, serious injury, or equipment damage.</p> <p> <input type="checkbox"/> [No] (nO): No injection <input type="checkbox"/> [Yes] (YES): Standstill injection for adjustable period <input type="checkbox"/> [Continuous] (Ct): Continuous standstill injection </p> </div>	[Yes] (YES)	
EdC 1	<input type="checkbox"/> [Auto DC inj. time 1] (1)	0.1 to 30 s	0.5 s
★	<p>CAUTION</p> <p>RISK OF DAMAGE TO MOTOR</p> <ul style="list-style-type: none"> Long periods of DC injection braking can cause overheating and damage the motor. Protect the motor by avoiding long periods of DC injection braking. <p>Failure to follow these instructions can result in equipment damage.</p> <p>Parameter can be accessed if [Auto DC injection] (AdC) is not set to [No] (nO), page 68.</p>		
SdC 1	<input type="checkbox"/> [Auto DC inj. level 1] (1)	0 to 1.2 In (2)	0.7 In (2)
★	<p>CAUTION</p> <p>RISK OF DAMAGE TO MOTOR</p> <ul style="list-style-type: none"> Check that the motor will withstand this current without overheating. <p>Failure to follow these instructions can result in equipment damage.</p> <p>Parameter can be accessed if [Auto DC injection] (AdC) is not set to [No] (nO), page 68. Note: Check that the motor will withstand this current without overheating.</p>		

(1) Parameter can also be accessed in the **[SETTINGS] (SEt-)** menu.

(2) In corresponds to the nominal drive current indicated in the Installation Manual and on the drive nameplate.



These parameters only appear if the corresponding function has been selected in another menu. When the parameters can also be accessed and set from within the configuration menu for the corresponding function, their description is detailed in these menus, on the pages indicated, to aid programming.

Code	Name/Description	Adjustment range	Factory setting																	
AdC -	■ [AUTO DC INJECTION] (continued)																			
EdC2	<div><input type="checkbox"/> [Auto DC inj. time 2] (1)</div>	0 to 30 s	0 s																	
★	<div>CAUTION</div> <div>RISK OF DAMAGE TO MOTOR</div> <div><ul style="list-style-type: none">Long periods of DC injection braking can cause overheating and damage the motor.Protect the motor by avoiding long periods of DC injection braking.</div> <div>Failure to follow these instructions can result in equipment damage.</div> <div>Parameter can be accessed if [Auto DC injection] (AdC) is not set to [No] (nO), page 68.</div>																			
	EdC2	<div><input type="checkbox"/> [Auto DC inj. level 2] (1)</div>	0 to 1.2 In (2)	0.5 In (2)																
★	<div>CAUTION</div> <div>RISK OF DAMAGE TO MOTOR</div> <div><ul style="list-style-type: none">Check that the motor will withstand this current without overheating.</div> <div>Failure to follow these instructions can result in equipment damage.</div> <div>Parameter can be accessed if [Auto DC injection] (AdC) is not set to [No] (nO), page 68.</div>																			
	<table><tr><th>AdC</th><th>SdC2</th><th>Operation</th></tr><tr><td>YES</td><td>x</td><td></td></tr><tr><td>Ct</td><td>≠ 0</td><td></td></tr><tr><td>Ct</td><td>= 0</td><td></td></tr><tr><td colspan="2">Run command</td><td></td></tr><tr><td colspan="2">Speed</td><td></td></tr></table>			AdC	SdC2	Operation	YES	x		Ct	≠ 0		Ct	= 0		Run command			Speed	
AdC	SdC2	Operation																		
YES	x																			
Ct	≠ 0																			
Ct	= 0																			
Run command																				
Speed																				

(1) Parameter can also be accessed in the [SETTINGS] (SEt-) menu.
(2) In corresponds to the nominal drive current indicated in the Installation Manual and on the drive nameplate.


★ These parameters only appear if the corresponding function has been selected in another menu. When the parameters can also be accessed and set from within the configuration menu for the corresponding function, their description is detailed in these menus, on the pages indicated, to aid programming.

[APPLICATION FUNCT.] (FUn-) menu

REF -
SEt -
drC -
i-D -
CLL -
Fun -
FLt -
CON -
SUP -

Code	Name/Description	Adjustment range	Factory setting
SA 1 -	<div><div><div><div></div><div>[SUMMING INPUTS]</div></div><div>Can be used to sum one or two inputs to the [Ref.1 channel] (Fr1) reference only. Note: The "Summing inputs" function may be incompatible with other functions (see page 21).</div></div></div>		
SA 2	<div><div><div><div></div><div>[Summing ref. 2]</div></div><div><div><div><input type="checkbox"/> [No] (nO): Not assigned</div><div><input type="checkbox"/> [AI1] (AI1): Analog input AI1</div><div><input type="checkbox"/> [AI2] (AI2): Analog input AI2</div><div><input type="checkbox"/> [AI3] (AI3): Analog input AI3</div><div><input type="checkbox"/> [AI Virtual 1] (AIV1): Jog dial</div></div><div>If [ACCESS LEVEL] (LAC) = [Level 3] (L3), the following assignments are possible:</div><div><div><input type="checkbox"/> [HMI] (LCC): Reference via the remote display terminal, [HMI Frequency ref.] (LFr) parameter in the [SETTINGS] (SEt-) menu, page 32.</div><div><input type="checkbox"/> [Modbus] (Mdb): Reference via Modbus</div><div><input type="checkbox"/> [Com. card] (nEt): Reference via network</div></div></div></div></div>	<div><div>[AI2] (AI2)</div></div>	
SA 3	<div><div><div><div></div><div>[Summing ref. 3]</div></div><div><div><div><input type="checkbox"/> [No] (nO): Not assigned</div><div><input type="checkbox"/> [AI1] (AI1): Analog input AI1</div><div><input type="checkbox"/> [AI2] (AI2): Analog input AI2</div><div><input type="checkbox"/> [AI3] (AI3): Analog input AI3</div><div><input type="checkbox"/> [AI Virtual 1] (AIV1): Jog dial</div></div><div>If [ACCESS LEVEL] (LAC) = [Level 3] (L3), the following assignments are possible:</div><div><div><input type="checkbox"/> [HMI] (LCC): Reference via the remote display terminal, [HMI Frequency ref.] (LFr) parameter in the [SETTINGS] (SEt-) menu, page 32.</div><div><input type="checkbox"/> [Modbus] (Mdb): Reference via Modbus</div><div><input type="checkbox"/> [Com. card] (nEt): Reference via network</div></div></div></div></div>	<div><div>[No] (nO)</div></div>	

Summing inputs



Note:
AI2 is a ± 10 V input which can be used for subtraction by summing a negative signal.

See the complete block diagrams on pages 53 and 55.

Preset speeds

2, 4, 8 or 16 speeds can be preset, requiring 1, 2, 3 or 4 logic inputs respectively.

The following assignment order must be observed: [2 preset speeds] (PS2), then [4 preset speeds] (PS4), then [8 preset speeds] (PS8), then [16 preset speeds] (PS16).

Combination table for preset speed inputs

16 speeds LI (PS16)	8 speeds LI (PS8)	4 speeds LI (PS4)	2 speeds LI (PS2)	Speed reference
0	0	0	0	Reference (1)
0	0	0	1	SP2
0	0	1	0	SP3
0	0	1	1	SP4
0	1	0	0	SP5
0	1	0	1	SP6
0	1	1	0	SP7
0	1	1	1	SP8
1	0	0	0	SP9
1	0	0	1	SP10
1	0	1	0	SP11
1	0	1	1	SP12
1	1	0	0	SP13
1	1	0	1	SP14
1	1	1	0	SP15
1	1	1	1	SP16

(1) See the block diagrams on page 53 and page 55: Reference 1 = (SP1).

Note: If $Fr1 = LCC$ and $rPl = nO$, then $PI \text{ reference } (\%) = 10 * AI \text{ (Hz)} / 15$

[APPLICATION FUNCT.] (FUn-) menu

REF -
SEt -
drC -
i-D -
CtL -
Fun -
FLt -
CaN -
SuP -

Code	Name/Description	Adjustment range	Factory setting
P55 -	[PRESET SPEEDS] Note: The "Preset speeds" function may be incompatible with other functions (see page 21).		
P52	<input type="checkbox"/> [2 preset speeds] Selecting the assigned logic input activates the function. <input type="checkbox"/> [No] (nO): Not assigned <input type="checkbox"/> [LI1] (LI1): Logic input LI1 <input type="checkbox"/> [LI2] (LI2): Logic input LI2 <input type="checkbox"/> [LI3] (LI3): Logic input LI3 <input type="checkbox"/> [LI4] (LI4): Logic input LI4 <input type="checkbox"/> [LI5] (LI5): Logic input LI5 <input type="checkbox"/> [LI6] (LI6): Logic input LI6 If [ACCESS LEVEL] (LAC) = [Level 3] (L3), the following assignments are possible: <input type="checkbox"/> [CD11] (CD11): Bit 11 of the control word from a communication network <input type="checkbox"/> [CD12] (CD12): Bit 12 of the control word from a communication network <input type="checkbox"/> [CD13] (CD13): Bit 13 of the control word from a communication network <input type="checkbox"/> [CD14] (CD14): Bit 14 of the control word from a communication network <input type="checkbox"/> [CD15] (CD15): Bit 15 of the control word from a communication network		[LI3] (LI3)
P54	<input type="checkbox"/> [4 preset speeds] Selecting the assigned logic input activates the function. Ensure that [2 preset speeds] (PS2) has been assigned before assigning [4 preset speeds] (PS4). <input type="checkbox"/> [No] (nO): Not assigned <input type="checkbox"/> [LI1] (LI1): Logic input LI1 <input type="checkbox"/> [LI2] (LI2): Logic input LI2 <input type="checkbox"/> [LI3] (LI3): Logic input LI3 <input type="checkbox"/> [LI4] (LI4): Logic input LI4 <input type="checkbox"/> [LI5] (LI5): Logic input LI5 <input type="checkbox"/> [LI6] (LI6): Logic input LI6 If [ACCESS LEVEL] (LAC) = [Level 3] (L3), the following assignments are possible: <input type="checkbox"/> [CD11] (CD11): Bit 11 of the control word from a communication network <input type="checkbox"/> [CD12] (CD12): Bit 12 of the control word from a communication network <input type="checkbox"/> [CD13] (CD13): Bit 13 of the control word from a communication network <input type="checkbox"/> [CD14] (CD14): Bit 14 of the control word from a communication network <input type="checkbox"/> [CD15] (CD15): Bit 15 of the control word from a communication network		[LI4] (LI4)
P58	<input type="checkbox"/> [8 preset speeds] Selecting the assigned logic input activates the function. Ensure that [4 preset speeds] (PS4) has been assigned before assigning [8 preset speeds] (PS8). <input type="checkbox"/> [No] (nO): Not assigned <input type="checkbox"/> [LI1] (LI1): Logic input LI1 <input type="checkbox"/> [LI2] (LI2): Logic input LI2 <input type="checkbox"/> [LI3] (LI3): Logic input LI3 <input type="checkbox"/> [LI4] (LI4): Logic input LI4 <input type="checkbox"/> [LI5] (LI5): Logic input LI5 <input type="checkbox"/> [LI6] (LI6): Logic input LI6 If [ACCESS LEVEL] (LAC) = [Level 3] (L3), the following assignments are possible: <input type="checkbox"/> [CD11] (CD11): Bit 11 of the control word from a communication network <input type="checkbox"/> [CD12] (CD12): Bit 12 of the control word from a communication network <input type="checkbox"/> [CD13] (CD13): Bit 13 of the control word from a communication network <input type="checkbox"/> [CD14] (CD14): Bit 14 of the control word from a communication network <input type="checkbox"/> [CD15] (CD15): Bit 15 of the control word from a communication network		[No] (nO)

[APPLICATION FUNCT.] (FUn-) menu

REF -
SEt -
drC -
i - D -
CLL -
Fun -
FLt -
COP -
SUP -

Code	Name/Description	Adjustment range	Factory setting
P55 -	[PRESET SPEEDS] (continued)		
PS16	<input type="checkbox"/> [16 preset speeds] Selecting the assigned logic input activates the function. Ensure that [8 preset speeds] (PS8) has been assigned before assigning [16 preset speeds] (PS16). <input type="checkbox"/> [No] (nO): Not assigned <input type="checkbox"/> [LI1] (LI1): Logic input LI1 <input type="checkbox"/> [LI2] (LI2): Logic input LI2 <input type="checkbox"/> [LI3] (LI3): Logic input LI3 <input type="checkbox"/> [LI4] (LI4): Logic input LI4 <input type="checkbox"/> [LI5] (LI5): Logic input LI5 <input type="checkbox"/> [LI6] (LI6): Logic input LI6 If [ACCESS LEVEL] (LAC) = [Level 3] (L3), the following assignments are possible: <input type="checkbox"/> [CD11] (CD11): Bit 11 of the control word from a communication network <input type="checkbox"/> [CD12] (CD12): Bit 12 of the control word from a communication network <input type="checkbox"/> [CD13] (CD13): Bit 13 of the control word from a communication network <input type="checkbox"/> [CD14] (CD14): Bit 14 of the control word from a communication network <input type="checkbox"/> [CD15] (CD15): Bit 15 of the control word from a communication network	[No] (nO)	
SP2 ★	<input type="checkbox"/> [Preset speed 2]	(1)	0.0 to 500.0 Hz (2) 10 Hz
SP3 ★	<input type="checkbox"/> [Preset speed 3]	(1)	0.0 to 500.0 Hz (2) 15 Hz
SP4 ★	<input type="checkbox"/> [Preset speed 4]	(1)	0.0 to 500.0 Hz (2) 20 Hz
SP5 ★	<input type="checkbox"/> [Preset speed 5]	(1)	0.0 to 500.0 Hz (2) 25 Hz
SP6 ★	<input type="checkbox"/> [Preset speed 6]	(1)	0.0 to 500.0 Hz (2) 30 Hz
SP7 ★	<input type="checkbox"/> [Preset speed 7]	(1)	0.0 to 500.0 Hz (2) 35 Hz
SP8 ★	<input type="checkbox"/> [Preset speed 8]	(1)	0.0 to 500.0 Hz (2) 40 Hz
SP9 ★	<input type="checkbox"/> [Preset speed 9]	(1)	0.0 to 500.0 Hz (2) 45 Hz
SP10 ★	<input type="checkbox"/> [Preset speed 10]	(1)	0.0 to 500.0 Hz (2) 50 Hz

(1) Parameter can also be accessed in the [SETTINGS] (SEt-) menu. This parameter will depend on how many speeds have been configured.

(2) Reminder: The speed remains limited by the [High speed] (HSP) parameter, page 33.



These parameters only appear if the corresponding function has been selected in another menu. When the parameters can also be accessed and set from within the configuration menu for the corresponding function, their description is detailed in these menus, on the pages indicated, to aid programming.

[APPLICATION FUNCT.] (FUn-) menu

REF -
SEt -
drC -
i-D -
CLL -
Fun -
FLt -
CoN -
SuP -

Code	Name/Description	Adjustment range	Factory setting
P55 -	■ [PRESET SPEEDS] (continued)		
SP11 ★	<input type="checkbox"/> [Preset speed 11] (1)	0.0 to 500.0 Hz (2)	55 Hz
SP12 ★	<input type="checkbox"/> [Preset speed 12] (1)	0.0 to 500.0 Hz (2)	60 Hz
SP13 ★	<input type="checkbox"/> [Preset speed 13] (1)	0.0 to 500.0 Hz (2)	70 Hz
SP14 ★	<input type="checkbox"/> [Preset speed 14] (1)	0.0 to 500.0 Hz (2)	80 Hz
SP15 ★	<input type="checkbox"/> [Preset speed 15] (1)	0.0 to 500.0 Hz (2)	90 Hz
SP16 ★	<input type="checkbox"/> [Preset speed 16] (1)	0.0 to 500.0 Hz (2)	100 Hz


(1) Parameter can also be accessed in the [SETTINGS] (SEt-) menu. This parameter will depend on how many speeds have been configured.

(2) Reminder: The speed remains limited by the [High speed] (HSP) parameter, page 33.



These parameters only appear if the corresponding function has been selected in another menu. When the parameters can also be accessed and set from within the configuration menu for the corresponding function, their description is detailed in these menus, on the pages indicated, to aid programming.

[APPLICATION FUNCT.] (FUn-) menu

Code	Name/Description	Adjustment range	Factory setting
JOG -			
JOG	<div><div><div></div><div>[JOG]</div></div><div><div>Note:</div><div>The "Jog operation" function may be incompatible with other functions (see page 21).</div></div></div>		
JOG	<div><div><div></div><div>[JOG]</div></div><div><div>no</div><div>L 1</div><div>L 2</div><div>L 3</div><div>L 4</div><div>L 5</div><div>L 6</div></div><div><div><div></div><div>[No] (nO): Not assigned</div></div><div><div></div><div>[LI1] (LI1): Logic input LI1</div></div><div><div></div><div>[LI2] (LI2): Logic input LI2</div></div><div><div></div><div>[LI3] (LI3): Logic input LI3</div></div><div><div></div><div>[LI4] (LI4): Logic input LI4</div></div><div><div></div><div>[LI5] (LI5): Logic input LI5</div></div><div><div></div><div>[LI6] (LI6): Logic input LI6</div></div></div><div><div>Example: 2-wire control operation ([2/3 wire control] (tCC) = [2 wire] (2C))</div><div><div><div><div>Motor frequency</div><div>Reference</div><div>JGF reference</div><div>JGF reference</div><div>LI (JOG)</div><div>Forward</div><div>Reverse</div></div><div><div><div>Ramp DEC/DEC2</div><div>Ramp forced to 0.1 s</div></div></div></div></div></div></div>	[No] (nO)	
JGF	<div><div><div></div><div>[Jog frequency] (1)</div></div><div><div>Parameter can be accessed if [JOG] (JOG) is not set to [No] (nO), page 75.</div></div></div>	0 to 10 Hz	10 Hz

(1)Parameter can also be accessed in the [SETTINGS] (SEt-) menu.

These parameters only appear if the corresponding function has been selected in another menu. When the parameters can also be accessed and set from within the configuration menu for the corresponding function, their description is detailed in these menus, on the pages indicated, to aid programming.

[APPLICATION FUNCT.] (FUn-) menu

REF -
SEt -
drC -
r - D -
CLL -
FUn -
FLt -
CaP -
SUP -

+/- speed

Function can only be accessed if [ACCESS LEVEL] (LAC) = [Level 2] (L2) or [Level 3] (L3), page 58.
Two types of operation are available.

- Use of single action buttons:** Two logic inputs are required in addition to the direction(s) of operation.
The input assigned to the "+ speed" command increases the speed, the input assigned to the "- speed" command decreases the speed.
Note:
If the "+ speed" and "- speed" commands are activated at the same time, "- speed" will be given priority.
- Use of double action buttons:** Only one logic input assigned to "+ speed" is required.



+/- speed with double action buttons:

Description: 1 button pressed twice for each direction of rotation. Each action closes a contact.

	Released (- speed)	1st press (speed maintained)	2nd press (+ speed)
Forward button	—	a	a and b
Reverse button	—	c	c and d

Wiring example:

Ll1: Forward
Llx: Reverse
Lly: + speed



This type of +/- speed is incompatible with 3-wire control.

Whichever type of operation is selected, the max. speed is set by the [High speed] (HSP) parameter, page 33.

Note:

If the reference is switched via [Ref. 2 switching] (rFC), page 59, from one reference channel to any other reference channel with "+/- speed", the value of the [Output frequency] (rFr) reference (after ramp) is copied at the same time. This prevents the speed being incorrectly reset to zero when switching takes place.

Code	Name/Description	Adjustment range	Factory setting
uPd -	■ [+/- SPEED] (motorized jog dial) Function can only be accessed if [ACCESS LEVEL] (LAC) = [Level 2] (L2) or [Level 3] (L3), and [+/-spd HMI] (UPdH) or [+/- SPEED] (UPdt) selected, page 58. Note: The "+/- speed" function is incompatible with several functions (see page 21). It can only be configured if these functions are unassigned, in particular the summing inputs (set [Summing ref. 2] (SA2) to [No] (nO), page 70) and the preset speeds (set [2 preset speeds] (PS2) and [4 preset speeds] (PS4) to [No] (nO), page 72) which will have been assigned as part of the factory settings.		
uSP ★ nO L, 1 L, 2 L, 3 L, 4 L, 5 L, 6	□ [+ speed assignment] Parameter accessible for [+/- SPEED] (UPdt) only. Selecting the assigned logic input activates the function. <input type="checkbox"/> [No] (nO): Not assigned <input type="checkbox"/> [LI1] (LI1): Logic input LI1 <input type="checkbox"/> [LI2] (LI2): Logic input LI2 <input type="checkbox"/> [LI3] (LI3): Logic input LI3 <input type="checkbox"/> [LI4] (LI4): Logic input LI4 <input type="checkbox"/> [LI5] (LI5): Logic input LI5 <input type="checkbox"/> [LI6] (LI6): Logic input LI6		[No] (nO)
dSP ★ nO L, 1 L, 2 L, 3 L, 4 L, 5 L, 6	□ [-Speed assignment] Parameter accessible for [+/- SPEED] (UPdt) only. Selecting the assigned logic input activates the function. <input type="checkbox"/> [No] (nO): Not assigned <input type="checkbox"/> [LI1] (LI1): Logic input LI1 <input type="checkbox"/> [LI2] (LI2): Logic input LI2 <input type="checkbox"/> [LI3] (LI3): Logic input LI3 <input type="checkbox"/> [LI4] (LI4): Logic input LI4 <input type="checkbox"/> [LI5] (LI5): Logic input LI5 <input type="checkbox"/> [LI6] (LI6): Logic input LI6		[No] (nO)
St r ★ nO rAM EEP	□ [Reference saved] Associated with the "+/- speed" function, this parameter can be used to save the reference: <ul style="list-style-type: none"> When the run commands disappear (saved to RAM) When the line supply or the run commands disappear (saved to EEPROM) Therefore, the next time the drive starts up, the speed reference is the last reference saved. <input type="checkbox"/> [No] (nO): No saving <input type="checkbox"/> [RAM] (rAM): Saving in RAM <input type="checkbox"/> [EEprom] (EEP): Saving in EEPROM		[No] (nO)

★ These parameters only appear if the corresponding function has been selected in another menu. When the parameters can also be accessed and set from within the configuration menu for the corresponding function, their description is detailed in these menus, on the pages indicated, to aid programming.

[APPLICATION FUNCT.] (FUn-) menu

REF -

SEt - PI regulator

drC - Block diagram

i - D - The function is activated by assigning an analog input to the PI feedback (measurement).


CLL -

FUn -

FLt -

CaP -

SUP -



Reference B

Pages 53 and 55

PI feedback:

PI feedback must be assigned to one of these analog inputs, AI1, AI2, or AI3.

PI reference:

The PI reference can be assigned to the following parameters in order of priority:

- Preset references via logic inputs, [Preset ref. PID 2] ($rP2$), [Preset ref. PID 3] ($rP3$), and [Preset ref. PID 4] ($rP4$), page 81
- Internal reference [Internal PID ref.] (rPI), page 82
- Reference [Ref.1 channel] ($Fr1$), page 58

Combination table for preset PI references

LI (Pr4)	LI (Pr2)	Pr2 = nO	Reference
0	0		rPI or $Fr1$
0	1		rPI or $Fr1$
1	0		$rP2$
1	1		$rP3$
			$rP4$

Parameters can also be accessed in the [SETTINGS] (SEt-) menu:

- [Internal PID ref.] (rPI), page 32
- [Preset ref. PID 2] ($rP2$), [Preset ref. PID 3] ($rP3$), and [Preset ref. PID 4] ($rP4$), page 36
- [PID prop. gain] (rPG), page 36
- [PID integral gain] (rLG), page 36
- [PID fbk scale factor] (FbS), page 36:

The [PID fbk scale factor] (FbS) parameter can be used to scale the reference according to the variation range for PI feedback (sensor rating).

Example: Regulating pressure

PI reference (process) 0-5 bar (0-100%)

Rating of pressure sensor 0-10 bar

[PID fbk scale factor] (FbS) = max. sensor scaling/max. process

[PID fbk scale factor] (FbS) = $10/5 = 2$

- [PID wake up thresh.] (rSL), page 38:

Can be used to set the PI error threshold above which the PI regulator will be reactivated (wake-up) after a stop due to the max. time threshold being exceeded at low speed [Low speed time out] (tLS)

- [PID correct. reverse] (PIC), page 36: If [PID correct. reverse] (PIC) = [No] (nO), the speed of the motor will increase when the error is positive (example: pressure control with a compressor). If [PID correct. reverse] (PIC) = [Yes] (YES), the speed of the motor will decrease when the error is positive (example: temperature control using a cooling fan).


"Manual - Automatic" operation with PI

This function combines the PI regulator and [Ref. 2 switching] (rFC) reference switching, page 59. The speed reference is given by [Ref.2 channel] (Fr2) or by the PI function, depending on the state of the logic input.

Setting up the PI regulator

1. Configuration in PI mode
See the block diagram on page 78.
2. Perform a test in factory settings mode (in most cases, this will be sufficient).
To optimize the drive, adjust [PID prop. gain.] (rPG) or [PID integral gain] (rIG) gradually and independently, and observe the effect on the PI feedback in relation to the reference.
3. If the factory settings are unstable or the reference is incorrect:
Perform a test with a speed reference in manual mode (without PI regulator) and with the drive on load for the speed range of the system:
 - In steady state, the speed must be stable and comply with the reference, and the PI feedback signal must be stable.
 - In transient state, the speed must follow the ramp and stabilize quickly, and the PI feedback must follow the speed.If this is not the case, see the settings for the drive and/or sensor signal and cabling.

Switch to PI mode.
Set [Dec ramp adapt.] (brA) to no (no auto-adaptation of the ramp).
Set the [Acceleration] (ACC) and [Deceleration] (dEC) speed ramps to the minimum level permitted by the mechanics without triggering an [OVERBRAKING] (ObF) fault.
Set the integral gain [PID integral gain] (rIG) to the minimum level.
Observe the PI feedback and the reference.
Switch the drive ON/OFF repeatedly or quickly vary the load or reference a number of times.
Set the proportional gain [PID prop. gain] (rPG) in order to ascertain a good compromise between response time and stability in transient phases (slight overshoot and 1 to 2 oscillations before stabilizing).
If the reference varies from the preset value in steady state, gradually increase the integral gain [PID integral gain] (rIG), reduce the proportional gain [PID prop. gain] (rPG) in the event of instability (pump applications), and find a compromise between response time and static precision (see diagram).
Perform in-production tests over the whole reference range.



The oscillation frequency depends on the system dynamics.

Parameter	Rise time	Overshoot	Stabilization time	Static error
[PID prop. gain] (rPG)	↘	↗	=	↘
[PID integral gain] (rIG)	↘	↗	↗	↘

[APPLICATION FUNCT.] (FUn-) menu

REF -
SEt -
drC -
i-D -
CLL -
Fun -
FLt -
CoN -
SuP -

Code	Name/Description	Adjustment range	Factory setting
P, -	[PI REGULATOR] Note: The "PI regulator" function is incompatible with several functions (see page 21). It can only be configured if these functions are unassigned, in particular the summing inputs (set [Summing ref. 2] (SA2) to [No] (nO), page 70) and the preset speeds (set [2 preset speeds] (PS2) and [4 preset speeds] (PS4) to [No] (nO), page 72) which will have been assigned as part of the factory settings.		
P, F	<input type="checkbox"/> [PID feedback ass.] <input type="checkbox"/> [No] (nO): Not assigned <input type="checkbox"/> [AI1] (AI1): Analog input AI1 <input type="checkbox"/> [AI2] (AI2): Analog input AI2 <input type="checkbox"/> [AI3] (AI3): Analog input AI3		[No] (nO)
r PG ★	<input type="checkbox"/> [PID prop. gain] (1) Parameter is only visible if [PID feedback ass.] (PIF) is not set to [No] (nO), page 80. It provides dynamic performance when PI feedback is changing quickly.	0.01 to 100	1
r IG ★	<input type="checkbox"/> [PID integral gain] (1) Parameter is only visible if [PID feedback ass.] (PIF) is not set to [No] (nO), page 80. It provides static precision when PI feedback is changing slowly.	0.01 to 100	1
F b S ★	<input type="checkbox"/> [PID fbk scale factor] (1) Parameter is only visible if [PID feedback ass.] (PIF) is not set to [No] (nO), page 80. For adapting the process.	0.1 to 100	1
P, C ★ no YES	<input type="checkbox"/> [PID correct. reverse] Parameter is only visible if [PID feedback ass.] (PIF) is not set to [No] (nO), page 80. <input type="checkbox"/> [No] (nO): Normal <input type="checkbox"/> [Yes] (YES): Reverse		[No] (nO)
P r 2 ★ no L, 1 L, 2 L, 3 L, 4 L, 5 L, 6 Cd 11 Cd 12 Cd 13 Cd 14 Cd 15	<input type="checkbox"/> [2 preset PID ref.] Parameter is only visible if [PID feedback ass.] (PIF) is not set to [No] (nO), page 80. Selecting the assigned logic input activates the function. <input type="checkbox"/> [No] (nO): Not assigned <input type="checkbox"/> [LI1] (LI1): Logic input LI1 <input type="checkbox"/> [LI2] (LI2): Logic input LI2 <input type="checkbox"/> [LI3] (LI3): Logic input LI3 <input type="checkbox"/> [LI4] (LI4): Logic input LI4 <input type="checkbox"/> [LI5] (LI5): Logic input LI5 <input type="checkbox"/> [LI6] (LI6): Logic input LI6 If [ACCESS LEVEL] (LAC) = [Level 3] (L3), the following assignments are possible: <input type="checkbox"/> [CD11] (CD11): Bit 11 of the control word from a communication network <input type="checkbox"/> [CD12] (CD12): Bit 12 of the control word from a communication network <input type="checkbox"/> [CD13] (CD13): Bit 13 of the control word from a communication network <input type="checkbox"/> [CD14] (CD14): Bit 14 of the control word from a communication network <input type="checkbox"/> [CD15] (CD15): Bit 15 of the control word from a communication network		[No] (nO)

(1) Parameter(s) can also be accessed in the [SETTINGS] (SEt-) menu.



These parameters only appear if the corresponding function has been selected in another menu. When the parameters can also be accessed and set from within the configuration menu for the corresponding function, their description is detailed in these menus, on the pages indicated, to aid programming.

[APPLICATION FUNCT.] (FUn-) menu

REF -
SEt -
drC -
i - D -
CLL -
Fun -
FLt -
COP -
SUP -

Code	Name/Description	Adjustment range	Factory setting
P 1 -	[PI REGULATOR] (continued)		
Pr 4 ★ no L 11 L 12 L 13 L 14 L 15 L 16 Cd 11 Cd 12 Cd 13 Cd 14 Cd 15	[4 preset PID ref.] Parameter is only visible if [PID feedback ass.] (PIF) is not set to [No] (nO), page 80. Selecting the assigned logic input activates the function. Make sure that [2 preset PID ref.] (Pr2), page 80, has been assigned before assigning [4 preset PID ref.] (Pr4). <input type="checkbox"/> [No] (nO): Not assigned <input type="checkbox"/> [LI1] (LI1): Logic input LI1 <input type="checkbox"/> [LI2] (LI2): Logic input LI2 <input type="checkbox"/> [LI3] (LI3): Logic input LI3 <input type="checkbox"/> [LI4] (LI4): Logic input LI4 <input type="checkbox"/> [LI5] (LI5): Logic input LI5 <input type="checkbox"/> [LI6] (LI6): Logic input LI6 If [ACCESS LEVEL] (LAC) = [Level 3] (L3), the following assignments are possible: <input type="checkbox"/> [CD11] (CD11): Bit 11 of the control word from a communication network <input type="checkbox"/> [CD12] (CD12): Bit 12 of the control word from a communication network <input type="checkbox"/> [CD13] (CD13): Bit 13 of the control word from a communication network <input type="checkbox"/> [CD14] (CD14): Bit 14 of the control word from a communication network <input type="checkbox"/> [CD15] (CD15): Bit 15 of the control word from a communication network		[No] (nO)
r P 2 ★	[Preset ref. PID 2] See page 36.	(1) 0 to 100%	30%
r P 3 ★	[Preset ref. PID 3] See page 36.	(1) 0 to 100%	60%
r P 4 ★	[Preset ref. PID 4] See page 36.	(1) 0 to 100%	90%

(1) Parameter(s) can also be accessed in the [SETTINGS] (SEt-) menu.

★ These parameters only appear if the corresponding function has been selected in another menu. When the parameters can also be accessed and set from within the configuration menu for the corresponding function, their description is detailed in these menus, on the pages indicated, to aid programming.

[APPLICATION FUNCT.] (FUn-) menu

Code	Name/Description	Adjustment range	Factory setting
P , -	[PI REGULATOR] (continued)		
r SL	<input type="checkbox"/> [PID wake up thresh.] (1)	0 to 100%	0%
★	<div style="background-color: black; color: white; text-align: center; padding: 5px;">⚠ DANGER</div> <div style="background-color: #fff9c4; padding: 10px;"> UNINTENDED EQUIPMENT OPERATION <ul style="list-style-type: none"> Check that unintended restarts will not present any danger. Failure to follow these instructions will result in death or serious injury. <p>If the "PI" and "Low speed operating time" [Low speed time out] (tLS) (page 38) are configured at the same time, the PI regulator may attempt to set a speed lower than [Low speed] (LSP). This results in unsatisfactory operation, which consists of starting, operating at [Low speed] (LSP), then stopping, and so on.</p> <p>The rSL (restart error threshold) parameter can be used to set a minimum PI error threshold for restarting after a stop at prolonged [Low speed] (LSP).</p> <p>The function is inactive if [Low speed time out] (tLS) = 0.</p> </div>		
P , , ★ n o Y E S	<input type="checkbox"/> [Act. internal PID ref.]		[No] (nO)
	<input type="checkbox"/> [No] (nO) : The reference for the PI regulator is [Ref.1 channel] (Fr1) , except for [+/-spd HMI] (UPdH) and [+/- SPEED] (UPdt) (+/- speed cannot be used as a reference for the PI regulator). <input type="checkbox"/> [Yes] (YES) : The reference for the PI regulator is provided internally via the [Internal PID ref.] (rPI) parameter.		
r P , ★	<input type="checkbox"/> [Internal PID ref.] (1)	0 to 100%	0%
	Parameter is only visible if [PID feedback ass.] (PIF) is not set to [No] (nO) , page 80.		

(1) Parameter(s) can also be accessed in the [\[SETTINGS\] \(SEt-\)](#) menu.

★ These parameters only appear if the corresponding function has been selected in another menu. When the parameters can also be accessed and set from within the configuration menu for the corresponding function, their description is detailed in these menus, on the pages indicated, to aid programming.

Brake control


Function can only be accessed if [ACCESS LEVEL] (LAC) = [Level 2] (L2) or [Level 3] (L3) (page 53).

This function, which can be assigned to relay R2 or logic output AOC, enables the drive to manage an electromagnetic brake.

Principle

Synchronize brake release with the build-up of torque during startup and brake engage at zero speed on stopping, to help prevent jolting.

Brake sequence



Settings which can be accessed in the application functions [APPLICATION FUNCT.] (FUn-) menu:

- Brake release frequency [Brake release freq] (brL)
- Brake release current [Brake release I FW] (lbr)
- Brake release time delay [Brake Release time] (brt)
- Brake engage frequency [Brake engage freq] (bEn)
- Brake engage time delay [Brake engage time] (bEt)
- Brake release pulse [Brake impulse] (bIP)

Recommended brake control settings:


1. [Brake release freq] (brL), page 84:
 - Horizontal movement: Set to 0.
 - Vertical movement: Set to a frequency equal to the nominal motor slip in Hz.
2. [Brake release I FW] (lbr), page 84:
 - Horizontal movement: Set to 0.
 - Vertical movement: Preset the nominal current of the motor then adjust it in order to help prevent jolting on start-up, making sure that the maximum load is held when the brake is released.
3. [Brake Release time] (brt), page 84:

Adjust according to the type of brake. It is the time required for the mechanical brake to release.
4. [Brake engage freq] (bEn), page 84:
 - Horizontal movement: Set to 0.
 - Vertical movement: Set to a frequency equal to the nominal motor slip in Hz. **Note:** Max. [Brake engage freq] (bEn) = [Low speed] (LSP); this means an appropriate value must be set in advance for [Low speed] (LSP).
5. [Brake engage time] (bEt), page 85:

Adjust according to the type of brake. It is the time required for the mechanical brake to engage.
6. [Brake impulse] (bIP), page 85:
 - Horizontal movement: Set to [No] (nO).
 - Vertical movement: Set to [Yes] (YES) and check that the motor torque direction for "run forward" control corresponds to the upward direction of the load. If necessary, reverse two motor phases. This parameter generates motor torque in an upward direction regardless of the direction of operation commanded in order to maintain the load whilst the brake is releasing.

[APPLICATION FUNCT.] (FUn-) menu

REF -
SEt -
drC -
rD -
CLL -
FUn -
FLt -
CoN -
SuP -

Code	Name/Description	Adjustment range	Factory setting
bLC -	[BRAKE LOGIC CONTROL] Function can only be accessed if [ACCESS LEVEL] (LAC) = [Level 2] (L2) or [Level 3] (L3), page 58. Note: This function may be incompatible with other functions (see page 21).		
bLC	<input type="checkbox"/> [Brake assignment] <input type="checkbox"/> [No] (nO): Not assigned <input type="checkbox"/> [R2] (r2): Relay R2 <input type="checkbox"/> [DO] (dO): Logic output AOC If [Brake assignment] (bLC) is assigned, the [Catch on the fly] (FLr) parameter, page 93, and the [Dec ramp adapt.] (brA) parameter, page 64, are forced to [No] (nO), and the [Output Phase Loss] (OPL) parameter, page 94, is forced to [Yes] (YES). [Brake assignment] (bLC) is forced to [No] (nO) if [Output Phase Loss] (OPL) = [Output cut] (OAC), page 94.		[No] (nO)
brL	<input type="checkbox"/> [Brake release freq] Brake release frequency.	0.0 to 10.0 Hz	In accordance with the drive rating
ibr	<input type="checkbox"/> [Brake release I FW] Brake release current threshold for ascending or forward movement. If the value of the current [brake release I FW] (ibr) is lower than that the fluxing current of the motor, an output phase disconnection may not be detected before releasing the brake and the load may drop.	0 to 1.36 In (1)	In accordance with the drive rating
	<div style="text-align: center;">  WARNING </div> <p>UNEXPECTED EQUIPMENT OPERATION</p> <p>In applications involving vertical movement, the value of the current [brake release I FW] (ibr) must be set above the value of the fluxing current of the motor.</p> <p>If this condition is not satisfied, a drive with encoder feedback must be used.</p> <p>Failure to follow these instructions can result in death, serious injury, or equipment damage.</p> <p>The fluxing current of a motor is equal to $I_n \cdot \sqrt{1 - \cos^2 \varphi}$ with $\cos \varphi$ indicated on the nameplate of the motor.</p>		
brt	<input type="checkbox"/> [Brake Release time] Brake release time delay.	0 to 5 s	0.5 s
LSP	<input type="checkbox"/> [Low speed] Motor frequency at min. reference. This parameter can also be changed in the [SETTINGS] (SEt-) menu, page 33.	0 to HSP (page 33)	0 LSP
bEn	<input type="checkbox"/> [Brake engage freq] <input type="checkbox"/> Not set <input type="checkbox"/> Adjustment range in Hz If [Brake assignment] (bLC) is assigned and [Brake engage freq] (bEn) remains set to [No] (nO), the drive will lock in [BRAKE CONTROL FAULT] (bLF) mode on the first run command.	nO - 0 to LSP	[No] (nO)

(1) In corresponds to the nominal drive current indicated in the Installation Manual and on the drive nameplate.

★ These parameters only appear if the corresponding function has been selected in another menu. When the parameters can also be accessed and set from within the configuration menu for the corresponding function, their description is detailed in these menus, on the pages indicated, to aid programming.

[APPLICATION FUNCT.] (FUn-) menu

Code	Name/Description	Adjustment range	Factory setting
b L C -	■ [BRAKE LOGIC CONTROL] (continued)		
b E t ★	<input type="checkbox"/> [Brake engage time] Brake engage time (brake response time).	0 to 5 s	0.5 s
b , P no YES ★	<input type="checkbox"/> [Brake impulse] <input type="checkbox"/> [No] (nO): Whilst the brake is releasing, the motor torque direction corresponds to the direction of rotation commanded. <input type="checkbox"/> [Yes] (YES): Whilst the brake is releasing, the motor torque direction is forward, regardless of the direction of operation commanded. Note: Check that the motor torque direction for "run forward" control corresponds to the upward direction of the load. If necessary, reverse two motor phases.		[No] (nO)

★

These parameters only appear if the corresponding function has been selected in another menu. When the parameters can also be accessed and set from within the configuration menu for the corresponding function, their description is detailed in these menus, on the pages indicated, to aid programming.

[APPLICATION FUNCT.] (FUn-) menu

REF -
SEt -
drC -
i - 0 -
CLL -
FUn -
FLt -
CaN -
SuP -

Code	Name/Description	Adjustment range	Factory setting
LC2 -	[CURRENT LIMITATION 2] Function can only be accessed if [ACCESS LEVEL] (LAC) = [Level 2] (L2) or [Level 3] (L3), page 58.		
LC2	<input type="checkbox"/> [Current limit 2] Selecting the assigned logic input activates the function. <input type="checkbox"/> [No] (nO): Not assigned <input type="checkbox"/> [LI1] (LI1): Logic input LI1 <input type="checkbox"/> [LI2] (LI2): Logic input LI2 <input type="checkbox"/> [LI3] (LI3): Logic input LI3 <input type="checkbox"/> [LI4] (LI4): Logic input LI4 <input type="checkbox"/> [LI5] (LI5): Logic input LI5 <input type="checkbox"/> [LI6] (LI6): Logic input LI6 If [ACCESS LEVEL] (LAC) = [Level 3] (L3), the following assignments are possible: <input type="checkbox"/> [CD11] (CD11): Bit 11 of the control word from a communication network <input type="checkbox"/> [CD12] (CD12): Bit 12 of the control word from a communication network <input type="checkbox"/> [CD13] (CD13): Bit 13 of the control word from a communication network <input type="checkbox"/> [CD14] (CD14): Bit 14 of the control word from a communication network <input type="checkbox"/> [CD15] (CD15): Bit 15 of the control word from a communication network [Current Limitation] (CLI) is enabled when the logic input or control word bit is at state 0 ([SETTINGS] (SEt-) menu, page 38). [I Limit. 2 value] (CL2) is enabled when the logic input or control word bit is at state 1.	[No] (nO)	
CL2	<input type="checkbox"/> [I Limit. 2 value] (1) See page 38.	0.25 to 1.5 In (2)	1.5 In (2)

(1) Parameter can also be accessed in the [SETTINGS] (SEt-) menu.

(2) In corresponds to the nominal drive current indicated in the Installation Manual and on the drive nameplate.

★ These parameters only appear if the corresponding function has been selected in another menu. When the parameters can also be accessed and set from within the configuration menu for the corresponding function, their description is detailed in these menus, on the pages indicated, to aid programming.

[APPLICATION FUNCT.] (FUn-) menu

Code	Name/Description	Adjustment range	Factory setting
CHP -	[SWITCHING MOTOR] Function can only be accessed if [ACCESS LEVEL] (LAC) = [Level 2] (L2) or [Level 3] (L3), page 58.		
CHP no L11 L12 L13 L14 L15 L16 CD11 CD12 CD13 CD14 CD15	<input type="checkbox"/> [Motor switching] <input type="checkbox"/> [No] (nO): Not assigned <input type="checkbox"/> [LI1] (LI1): Logic input LI1 <input type="checkbox"/> [LI2] (LI2): Logic input LI2 <input type="checkbox"/> [LI3] (LI3): Logic input LI3 <input type="checkbox"/> [LI4] (LI4): Logic input LI4 <input type="checkbox"/> [LI5] (LI5): Logic input LI5 <input type="checkbox"/> [LI6] (LI6): Logic input LI6 If [ACCESS LEVEL] (LAC) = [Level 3] (L3), the following assignments are possible: <input type="checkbox"/> [CD11] (CD11): Bit 11 of the control word from a communication network <input type="checkbox"/> [CD12] (CD12): Bit 12 of the control word from a communication network <input type="checkbox"/> [CD13] (CD13): Bit 13 of the control word from a communication network <input type="checkbox"/> [CD14] (CD14): Bit 14 of the control word from a communication network <input type="checkbox"/> [CD15] (CD15): Bit 15 of the control word from a communication network LI or bit = 0: Motor 1 LI or bit = 1: Motor 2 Note: <ul style="list-style-type: none"> • If this function is used, the auto-tuning function, page 43, is not active on motor 2. • Changes to parameters are only taken into account when the drive is locked. 		[No] (nO)
CAUTION RISK OF DAMAGE TO MOTOR The motor switching function disables motor thermal protection. The use of external overload protection is required when using motor switching. Failure to follow these instructions can result in equipment damage.			
un52 ★	<input type="checkbox"/> [Nom. mot. 2 volt.] ATV312...M2: 100 to 240 V ATV312...M3: 100 to 240 V ATV312...N4: 100 to 500 V ATV312...S6: 100 to 600 V	In accordance with the drive rating	In accordance with the drive rating
Fr52 ★	<input type="checkbox"/> [Nom. motor 2 freq.] Note: The ratio $\frac{[\text{Rated motor volt.}] (\text{UnS}) (\text{in volts})}{[\text{Rated motor freq.}] (\text{FrS}) (\text{in Hz})}$ must not exceed the following values: ATV312...M2: 7 max. ATV312...M3: 7 max. ATV312...N4: 14 max. ATV312...S6: 17 max. The factory setting is 50 Hz, or preset to 60 Hz if [Standard mot. freq.] (bFr) is set to 60 Hz.	10 to 500 Hz	50 Hz



These parameters only appear if the corresponding function has been selected in another menu. When the parameters can also be accessed and set from within the configuration menu for the corresponding function, their description is detailed in these menus, on the pages indicated, to aid programming.

[APPLICATION FUNCT.] (FUn-) menu

REF -
SEt -
drC -
r-D -
CLL -
FUn -
FLt -
CaP -
SuP -

Code	Name/Description	Adjustment range	Factory setting
CHP -	[SWITCHING MOTOR] (continued)		
nCr2 ★	<input type="checkbox"/> [Nom. mot. 2 current] Nominal motor 2 current given on the rating plate.	0.25 to 1.5 In (2)	In accordance with the drive rating
nSP2 ★	<input type="checkbox"/> [Nom. mot. 2 speed] 0 to 9,999 rpm then 10.00 to 32.76 krpm If, rather than the nominal speed, the nameplate indicates the synchronous speed and the slip in Hz or as a %, calculate the nominal speed as follows: <ul style="list-style-type: none"> Nominal speed = synchronous speed x $\frac{100 - \text{slip as a \%}}{100}$ or Nominal speed = synchronous speed x $\frac{50 - \text{slip in Hz}}{50}$ (50 Hz motors) or Nominal speed = synchronous speed x $\frac{60 - \text{slip in Hz}}{60}$ (60 Hz motors) 	0 to 32,760 rpm	In accordance with the drive rating
CaS2 ★	<input type="checkbox"/> [Motor 2 Cosinus Phi] Cos Phi given on the rating plate of motor 2.	0.5 to 1	In accordance with the drive rating
uFt2 ★ L P n nLd	<input type="checkbox"/> [U/F mot.2 selected] <input type="checkbox"/> [Cst. torque] (L): Constant torque for motors connected in parallel or special motors <input type="checkbox"/> [Var. torque] (P): Variable torque for pump and fan applications <input type="checkbox"/> [SVC] (n): Sensorless flux vector control for constant torque applications <input type="checkbox"/> [Energy sav.] (nLd): Energy saving, for variable torque applications not requiring high dynamics (behaves in a similar way to the P ratio at no load and the n ratio on load)		[SVC] (n)
uFr2 ★	<input type="checkbox"/> [IR compensation 2] (1) See page 39.	0 to 100%	20%
FLG2 ★	<input type="checkbox"/> [FreqLoopGain 2] (1) See page 39.	1 to 100%	20%
SLA2 ★	<input type="checkbox"/> [Freq. loop stability 2] (1) See page 39.	1 to 100%	20%
SLP2 ★	<input type="checkbox"/> [Slip compensation 2] (1) See page 39.	0 to 150%	100%

(1) Parameter can also be accessed in the [SETTINGS] (SEt-) menu.

(2) In corresponds to the nominal drive current indicated in the Installation Manual and on the drive nameplate.

★ These parameters only appear if the corresponding function has been selected in another menu. When the parameters can also be accessed and set from within the configuration menu for the corresponding function, their description is detailed in these menus, on the pages indicated, to aid programming.

Management of limit switches

Function can only be accessed if [ACCESS LEVEL] (LAC) = [Level 2] (L2) or [Level 3] (L3), page 58.

This function can be used to manage the operation of one or two series limit switches (non-reversing or reversing).

- Assignment of one or two logic inputs (forward limit switch, reverse limit switch)
- Selection of the stop type (on ramp, fast or freewheel)
Following a stop, the motor is permitted to restart in the opposite direction only.
- The stop is performed when the input is in state 0. The direction of operation is authorized in state 1.

Restarting after stop caused by a limit switch

- Send a run command in the other direction (when control is via the terminals, if [2/3 wire control] (tCC) = [2 wire] (2C) and [2 wire type] (tCt) = [Transition] (trn), first remove all the run commands).

or

- Invert the reference sign, remove all the run commands then send a run command in the same direction as before the stop caused by a limit switch.




Code	Name/Description	Adjustment range	Factory setting
L5t -	[LIMIT SWITCHES] Function can only be accessed if [ACCESS LEVEL] (LAC) = [Level 2] (L2) or [Level 3] (L3), page 58. Note: This function is incompatible with the "PI regulator" function (see page 21).		
LAF no L, 1 L, 2 L, 3 L, 4 L, 5 L, 6	<input type="checkbox"/> [Stop FW limit sw.] <input type="checkbox"/> [No] (nO): Not assigned <input type="checkbox"/> [LI1] (LI1): Logic input LI1 <input type="checkbox"/> [LI2] (LI2): Logic input LI2 <input type="checkbox"/> [LI3] (LI3): Logic input LI3 <input type="checkbox"/> [LI4] (LI4): Logic input LI4 <input type="checkbox"/> [LI5] (LI5): Logic input LI5 <input type="checkbox"/> [LI6] (LI6): Logic input LI6		[No] (nO)
LAr ★ no L, 1 L, 2 L, 3 L, 4 L, 5 L, 6	<input type="checkbox"/> [Stop RV limit sw.] <input type="checkbox"/> [No] (nO): Not assigned <input type="checkbox"/> [LI1] (LI1): Logic input LI1 <input type="checkbox"/> [LI2] (LI2): Logic input LI2 <input type="checkbox"/> [LI3] (LI3): Logic input LI3 <input type="checkbox"/> [LI4] (LI4): Logic input LI4 <input type="checkbox"/> [LI5] (LI5): Logic input LI5 <input type="checkbox"/> [LI6] (LI6): Logic input LI6		[No] (nO)
LAS ★ rPP FSt nSt	<input type="checkbox"/> [Stop type] Parameter can be accessed if [Stop FW limit sw.] (LAF), page 89, or [Stop RV limit sw.] (LAR), page 89, is assigned. <input type="checkbox"/> [Ramp stop] (rMP): On ramp <input type="checkbox"/> [Fast stop] (FSt): Fast stop <input type="checkbox"/> [Freewheel] (nSt): Freewheel stop		[Freewheel] (nSt)



These parameters only appear if the corresponding function has been selected in another menu. When the parameters can also be accessed and set from within the configuration menu for the corresponding function, their description is detailed in these menus, on the pages indicated, to aid programming.

[APPLICATION FUNCT.] (FUn-) menu

REF -
SEL -
drC -
i - 0 -
CLL -
FUn -
FLt -
CoN -
SuP -

Code	Name/Description	Adjustment range	Factory setting
ArE	<input type="checkbox"/> [Select ATV31 conf.] This parameter is invisible if a communication option is present. It is only used to transfer a configuration via a loader tool or an ATV31 remote terminal. [Select ATV31 conf.] (ArE) can be used during a transfer between an ATV31 and ATV312 to specify the type of ATV31 (ATV31 or ATV31●●●●●A). See page 105 Configuration transfer between an ATV31 and an ATV312 for more details about compatible loader tools. Note : The transfer can't be done from an ATV31 to an ATV312 with a communication option board		[No] (nO)
nO	<input type="checkbox"/> [No] (nO) : Transfer between two ATV312 Note1 : PC Software is only compatible with ATV312 using the standard input/output control board. Note2 : Transfer between 2 drives is only possible if they have the same communication board.		
31E	<input type="checkbox"/> [ATV31 std] (31E) : Transfer from an ATV31 to an ATV312. Set ARE = 31E to download a configuration from a European ATV31.		
31A	<input type="checkbox"/> [ATV31...A] (31A) : Transfer from an ATV31●●●●●A to an ATV312. Set ARE = 31A to download a configuration from an Asian ATV31. Procedure for transferring a configuration: <ul style="list-style-type: none"> • Set [Select ATV31 conf.] (ArE) to the required value. • Perform the configuration transfer. • Once the transfer is complete, turn the drive off. • Power the drive up again to initialize the configuration. • The parameter is restored to its factory setting. 		
SCS  2 s	<input type="checkbox"/> [Saving config.] See page 45 .	(1)	[No] (nO)
CFG  2 s	<input type="checkbox"/> [Macro configuration] See page 45 .	(1)	[Factory set.] (Std)
FCS  2 s	<input type="checkbox"/> [Restore config.] See page 46 .	(1)	[No] (nO)

(1) **[Saving config.] (SCS)**, **[Macro configuration] (CFG)**, and **[Restore config.] (FCS)** can be accessed from several configuration menus, but they apply to all menus and parameters.



The jog dial (ENT) needs to be pressed and held down (for 2 s) to change the assignment for this parameter.

[FAULT MANAGEMENT] (FLt-) menu

REF -
SEt -
drC -
i - 0 -
CLL -
Fun -
FLt -
CoP -
SuP -

Code	Description	Adjustment range	Factory setting
FLt ★ 5 10 30 1h 2h 3h Ct	<input type="checkbox"/> [Max. restart time] Parameter is only visible if [Automatic restart] (Atr) = [Yes] (YES). It can be used to limit the number of consecutive restarts in the event of a recurrent detected fault. <input type="checkbox"/> [5 min] (5): 5 minutes <input type="checkbox"/> [10 min] (10): 10 minutes <input type="checkbox"/> [30 min] (30): 30 minutes <input type="checkbox"/> [1 hour] (1h): 1 hour <input type="checkbox"/> [2 hours] (2h): 2 hours <input type="checkbox"/> [3 hours] (3h): 3 hours <input type="checkbox"/> [Unlimited] (Ct): Unlimited (except for [MOTOR PHASE LOSS] (OPF) and [INPUT PHASE LOSS] (PHF); the max. duration of the restart process is limited to 3 hours)		[5 min] (5)
rSF no L , 1 L , 2 L , 3 L , 4 L , 5 L , 6	<input type="checkbox"/> [Fault reset] <input type="checkbox"/> [No] (nO): Not assigned <input type="checkbox"/> [LI1] (LI1): Logic input LI1 <input type="checkbox"/> [LI2] (LI2): Logic input LI2 <input type="checkbox"/> [LI3] (LI3): Logic input LI3 <input type="checkbox"/> [LI4] (LI4): Logic input LI4 <input type="checkbox"/> [LI5] (LI5): Logic input LI5 <input type="checkbox"/> [LI6] (LI6): Logic input LI6		[No] (nO)



These parameters only appear if the corresponding function has been selected in another menu. When the parameters can also be accessed and set from within the configuration menu for the corresponding function, their description is detailed in these menus, on the pages indicated, to aid programming.

[FAULT MANAGEMENT] (FLt-) menu

Code	Description	Adjustment range	Factory setting
FLr nO YES	<input type="checkbox"/> [Catch on the fly] Used to enable a smooth restart if the run command is maintained after the following events: <ul style="list-style-type: none"> - Loss of line supply or simple power off - Reset of current drive or automatic restart - Freewheel stop The speed given by the drive resumes from the estimated speed of the motor at the time of the restart, then follows the ramp to the reference speed. This function requires 2-wire control ([2/3 wire control] (tCC) = [2 wire] (2C)) with [2 wire type] (tCt) = [Level] (LEL) or [Fwd priority] (PFO). <input type="checkbox"/> [No] (nO): Function inactive <input type="checkbox"/> [Yes] (YES): Function active When the function is operational, it activates at each run command, resulting in a slight delay (1 second max.). [Catch on the fly] (FLr) is forced to [No] (nO) if brake control [Brake assignment] (bLC) is assigned, page 84.		[No] (nO)
EtF nO L11 L12 L13 L14 L15 L16 CD11 CD12 CD13 CD14 CD15	<input type="checkbox"/> [External fault ass.] <input type="checkbox"/> [No] (nO): Not assigned <input type="checkbox"/> [LI1] (LI1): Logic input LI1 <input type="checkbox"/> [LI2] (LI2): Logic input LI2 <input type="checkbox"/> [LI3] (LI3): Logic input LI3 <input type="checkbox"/> [LI4] (LI4): Logic input LI4 <input type="checkbox"/> [LI5] (LI5): Logic input LI5 <input type="checkbox"/> [LI6] (LI6): Logic input LI6 If [ACCESS LEVEL] (LAC) = [Level 3] (L3), the following assignments are possible: <input type="checkbox"/> [CD11] (CD11): Bit 11 of the control word from a communication network <input type="checkbox"/> [CD12] (CD12): Bit 12 of the control word from a communication network <input type="checkbox"/> [CD13] (CD13): Bit 13 of the control word from a communication network <input type="checkbox"/> [CD14] (CD14): Bit 14 of the control word from a communication network <input type="checkbox"/> [CD15] (CD15): Bit 15 of the control word from a communication network		[No] (nO)
LEt LO HIG	<input type="checkbox"/> [External fault config] <input type="checkbox"/> [Active low] (LO): The external fault is detected when the logic input assigned to [External fault ass.] (EtF) changes to state 0. Note: In this case, [External fault ass.] (EtF) cannot be assigned to a control word bit from a communication network. <input type="checkbox"/> [Active high] (HIG): The external fault is detected when the logic input or the bit assigned to [External fault ass.] (EtF) changes to state 1. Note: Where [External fault config] (LEt) = [Active high] (HIG), [External fault ass.] (EtF) is assigned to a control word bit from a communication network, and where there is no [External fault ass.] (EtF) fault detection, switching to [External fault config] (LEt) = [Active low] (LO) triggers [External fault ass.] (EtF) fault detection. In this case, it is necessary to turn the drive off and then back on again.		[Active high] (HIG)
EPL nO YES rMP FSt	<input type="checkbox"/> [External fault mgt] <input type="checkbox"/> [Ignore] (nO): Ignore <input type="checkbox"/> [Freewheel] (YES): Detected fault management with freewheel stop <input type="checkbox"/> [Ramp stop] (rMP): Detected fault management with stop on ramp <input type="checkbox"/> [Fast stop] (FSt): Detected fault management with fast stop		[Freewheel] (YES)

REF -
SEt -
drC -
I - D -
CLL -
Fun -
FLt -
Con -
SUP -




REF -
SEt -
drC -
I - D -
CLL -
Fun -
FLt -
Con -
SUP -

— *EEF -*

SEt -
drC -
,-D -
CtL -
Fun -
FLt -
CoN -
SuP -

[FAULT MANAGEMENT] (FLt-) menu


REF -
SEt -
drC -
i - 0 -
CLL -
Fun -
FLt -
CaP -
SUP -

Code	Description	Adjustment range	Factory setting
drn  2 s no YES	<input type="checkbox"/> [Derated operation] Lowers the tripping threshold of [Undervoltage] (USF) : in order to operate on line supplies with 50% voltage drops. <input type="checkbox"/> [No] (nO) : Function inactive <input type="checkbox"/> [Yes] (YES) : Function active In this case, drive performance is derated. <div style="border: 1px solid black; padding: 5px; text-align: center;"> CAUTION RISK OF DAMAGE TO DRIVE When [Derated operation] (drn) = [Yes] (YES), use a line choke (see catalog). Failure to follow these instructions can result in equipment damage. </div>		[No] (nO)
StP no nnS rPP FSt	<input type="checkbox"/> [UnderV. prevention] This function can be used to control the type of stop where there is a loss of line supply. <input type="checkbox"/> [No] (nO) : Locking of the drive and freewheel stopping of the motor <input type="checkbox"/> [DC Maintain] (MMS) : This stop mode uses the inertia to maintain the drive power supply as long as possible. <input type="checkbox"/> [Ramp stop] (rMP) : Stop according to the valid ramp ([Deceleration] (dEC) or [Deceleration 2] (dE2)) <input type="checkbox"/> [Fast stop] (FSt) : Fast stop, the stopping time depends on the inertia and the braking ability of the drive.		[No] (nO)
inH  2 s no L , 1 L , 2 L , 3 L , 4 L , 5 L , 6	<input type="checkbox"/> [Fault inhibit assign.] <div style="background-color: black; color: white; text-align: center; padding: 5px;">  DANGER </div> LOSS OF PERSONNEL AND EQUIPMENT PROTECTION <ul style="list-style-type: none"> Enabling the fault inhibition parameter [Fault inhibit assign.] (inH) will disable the drive controller protection features. InH should not be enabled for typical applications of this equipment. InH should be enabled only in extraordinary situations where a thorough risk analysis demonstrates that the presence of adjustable speed drive protection poses a greater risk than personnel injury or equipment damage. Failure to follow these instructions will result in death or serious injury. This function disables drive protection for the following detected faults: SLF, CnF, EPF, CrF, LFF, OHF, OBF, OLF, OSF, OPF, PHF, SOF, tnF, COF, bLF <input type="checkbox"/> [No] (nO) : Not assigned <input type="checkbox"/> [LI1] (LI1) : Logic input LI1 <input type="checkbox"/> [LI2] (LI2) : Logic input LI2 <input type="checkbox"/> [LI3] (LI3) : Logic input LI3 <input type="checkbox"/> [LI4] (LI4) : Logic input LI4 <input type="checkbox"/> [LI5] (LI5) : Logic input LI5 <input type="checkbox"/> [LI6] (LI6) : Logic input LI6 The logic inputs are active in the high state.		[No] (nO)



The jog dial (ENT) needs to be pressed and held down (for 2 s) to change the assignment for this parameter.

[FAULT MANAGEMENT] (FLt-) menu


Code	Description	Adjustment range	Factory setting
<div> <div>rPr</div> <div>no</div> <div>rtH</div> </div>	<div> <input type="checkbox"/> [Operating t. reset] </div> <div> <input type="checkbox"/> [No] (nO): No <input type="checkbox"/> [rst. runtime] (rtH): Operating time reset to zero The [Operating t. reset] (rPr) parameter automatically returns to [No] (nO) after resetting to 0. </div>		[No] (nO)
<div> <div>rP</div> <div>2 s</div> <div>no</div> <div>YES</div> </div>	<div> <input type="checkbox"/> [Product reset] </div> <div> <div>  DANGER </div> <div> UNINTENDED EQUIPMENT OPERATION You are going to reset the drive. • Check this action will not endanger personnel or equipment in any way. Failure to follow these instructions will result in death or serious injury. </div> </div> <div> <input type="checkbox"/> [No] (nO): No <input type="checkbox"/> [Yes] (YES): Yes </div>		[No] (nO)



The jog dial (ENT) needs to be pressed and held down (for 2 s) to change the assignment for this parameter.

[COMMUNICATION] (COM-) menu

REF -
SEt -
drC -
i-D -
CLtL -
Fun -
FLt -
CAN -
SuP -



The parameters can only be modified when the drive is stopped and no run command is present. Modifications to the [Modbus Address] (Add), [Modbus baud rate] (tbr), [Modbus format] (tFO), [CANopen address] (AdCO), and [CANopen bit rate] (bdCO) parameters are not taken into account until the drive has been switched off and back on again.
On the optional ATV31 remote display terminal, this menu can be accessed with the switch in the position.

Code	Description	Adjustment range	Factory setting
Add	<input type="checkbox"/> [Modbus Address] Modbus address for the drive.	1 to 247	1
tbr 4.8 9.6 19.2	<input type="checkbox"/> [Modbus baud rate] Modbus transmission speed <input type="checkbox"/> [4.8 Kbps] (4.8): 4,800 bits/second <input type="checkbox"/> [9.6 Kbps] (9.6): 9,600 bits/second <input type="checkbox"/> [19.2 Kbps] (19.2): 19,200 bits/second (Note: This is the only value which supports the use of the remote display terminal.)		19,200 bps
tFO Bo1 BE1 Bn1 Bn2	<input type="checkbox"/> [Modbus format] <input type="checkbox"/> [8-O-1] (8O1): 8 data bits, odd parity, 1 stop bit <input type="checkbox"/> [8-E-1] (8E1): 8 data bits, even parity, 1 stop bit (Note: This is the only value which supports the use of the remote display terminal.) <input type="checkbox"/> [8-N-1] (8n2): 8 data bits, no parity, 1 stop bit <input type="checkbox"/> [8-N-2] (8n2): 8 data bits, no parity, 2 stop bits		[8-E-1] (8E1)
tto	<input type="checkbox"/> [Modbus time out]	0.1 to 30 s	10 s
AdCo	<input type="checkbox"/> [CANopen address] CANopen address for the drive.	0 to 127	0
bdCo 10.0 20.0 50.0 125.0 250.0 500.0 1000	<input type="checkbox"/> [CANopen bit rate] Modbus transmission speed <input type="checkbox"/> [10 kbps] (10.0): 10 kbps <input type="checkbox"/> [20 kbps] (20.0): 20 kbps <input type="checkbox"/> [50 kbps] (50.0): 50 kbps <input type="checkbox"/> [125 kbps] (125.0): 125 kbps <input type="checkbox"/> [250 kbps] (250.0): 250 kbps <input type="checkbox"/> [500 kbps] (500.0): 500 kbps <input type="checkbox"/> [1 Mbps] (1000): 1000 kbps		125 bps
ErCo 0 1 2 3 4	<input type="checkbox"/> [Error code] <input type="checkbox"/> No error <input type="checkbox"/> Bus off <input type="checkbox"/> Life time <input type="checkbox"/> CAN overrun <input type="checkbox"/> Heartbeat		-

[COMMUNICATION] (COM-) menu


REF -
SEt -
drC -
I - D -
CLt -
Fun -
FLt -
COP -
SUP -

Code	Description	Adjustment range	Factory setting
FLa no L , 1 L , 2 L , 3 L , 4 L , 5 L , 6	<input type="checkbox"/> [Forced local assign.] <input type="checkbox"/> [No] (nO): Not assigned <input type="checkbox"/> [LI1] (LI1): Logic input LI1 <input type="checkbox"/> [LI2] (LI2): Logic input LI2 <input type="checkbox"/> [LI3] (LI3): Logic input LI3 <input type="checkbox"/> [LI4] (LI4): Logic input LI4 <input type="checkbox"/> [LI5] (LI5): Logic input LI5 <input type="checkbox"/> [LI6] (LI6): Logic input LI6 In forced local mode, the terminals and the display terminal regain control of the drive.		[No] (nO)
FLaC ★ A , 1 A , 2 A , 3 A i v 1 L C C	<input type="checkbox"/> [Forced local Ref.] Parameter can only be accessed if [ACCESS LEVEL] (LAC) = [Level 3] (L3), page 58. In forced local mode, only the speed reference is taken into account. PI functions, summing inputs, etc. are not active. See the diagrams on pages 55 to 57. <input type="checkbox"/> [AI1] (AI1): Analog input AI1, logic inputs LI <input type="checkbox"/> [AI2] (AI2): Analog input AI2, logic inputs LI <input type="checkbox"/> [AI3] (AI3): Analog input AI3, logic inputs LI <input type="checkbox"/> [AI Virtual 1] (AIV1): Jog dial, RUN/STOP buttons <input type="checkbox"/> [HMI] (HMI): Remote display terminal: [HMI Frequency ref.] (LFr) reference, page 32, RUN/STOP/FWD/REV buttons		[AI1] (AI1)



These parameters only appear if the corresponding function has been selected in another menu. When the parameters can also be accessed and set from within the configuration menu for the corresponding function, their description is detailed in these menus, on the pages indicated, to aid programming.

[MONITORING] (SUP-) menu



The parameters can be accessed with the drive running or stopped.

On the optional remote display terminal, this menu can be accessed with the switch in any position.

Some functions have numerous parameters. In order to clarify programming and avoid having to scroll through endless parameters, these functions have been grouped in submenus.

Like menus, submenus are identified by a dash after their code: **LrA-** for example.

When the drive is running, the value displayed is that of one of the monitoring parameters. By default, the value displayed is the output frequency applied to the motor ([Output frequency] (rFr) parameter).

While the value of the new monitoring parameter required is being displayed, press and hold down the jog dial (ENT) again (for 2 seconds) to confirm the change of monitoring parameter and store it. From then on, it is the value of this parameter that will be displayed during operation (even after powering down).

Unless the new choice is confirmed by pressing and holding down ENT again, the display will revert to the previous parameter after powering down.

Note: After the drive has been turned off or following a loss of line supply, the parameter displayed is the drive status ([Ready] (rdY), for example).

The selected parameter is displayed following a run command.

[MONITORING] (SUP-) menu

rEF -
SEt -
drC -
i - D -
CLL -
Fun -
FLt -
CaP -
SUP -

Code	Description	Variation range
LFr ★	<input type="checkbox"/> [HMI Frequency ref.] Frequency reference for control via built-in display terminal or remote display terminal.	0 to 500 Hz
rPi ★	<input type="checkbox"/> [Internal PID ref.] Internal PID reference Parameter is only visible if [PID feedback ass.] (PIF) is not set to [No] (nO), page 80.	0 to 100%
FrH	<input type="checkbox"/> [Frequency ref.] Frequency reference before ramp (absolute value).	0 to 500 Hz
rFr	<input type="checkbox"/> [Output frequency] This parameter is also used for the +/- speed function using the jog dial on the keypad or display terminal. It displays and validates operation (see page 58). In the event of a loss of line supply, [Output frequency] (rFr) is not stored and the +/- speed function must be re-enabled in [MONITORING] (SUP-) and [Output frequency] (rFr).	- 500 Hz to + 500 Hz
SPd1 or SPd2 or SPd3	<input type="checkbox"/> [Cust. output value] [Cust. output value] (SPd1), [Cust. output value] (SPd2) or [Cust. output value] (SPd3) depending on the [Scale factor display] (SdS) parameter, page 40 ([Cust. output value] (SPd3) in the factory setting)	
LCr	<input type="checkbox"/> [Motor current] Estimation of current in the motor	
oPr	<input type="checkbox"/> [Motor power] 100% = nominal motor power, calculated using the parameters entered in the [MOTOR CONTROL] (drC-) menu	
uLn	<input type="checkbox"/> [Mains voltage] This parameter gives the line voltage via the DC bus, both in motor mode or when the motor is stopped.	
tHr	<input type="checkbox"/> [Motor thermal state] 100% = nominal thermal state 118% = "OLF" threshold (drive overload)	
tHd	<input type="checkbox"/> [Drv. Therm att.] 100% = nominal thermal state 118% = "OHF" threshold (drive overheating)	



These parameters only appear if the corresponding function has been selected in another menu. When the parameters can also be accessed and set from within the configuration menu for the corresponding function, their description is detailed in these menus, on the pages indicated, to aid programming.

[MONITORING] (SUP-) menu



rEF -
 SEt -
 drC -
 i - D -
 CLtL -
 Fun -
 FLt -
 CLt -
 SUP -

Code	Description	Variation range
L F t	[Last fault occurred] <ul style="list-style-type: none"> <input type="checkbox"/> [Brake control] (bLF): Brake control detected fault <input type="checkbox"/> [Incorrect config.] (CFF): Incorrect configuration (parameters) <input type="checkbox"/> [Invalid config.] (CFI): Invalid configuration (parameters) <input type="checkbox"/> [NETWORK FAULT] (CnF): Communication detected fault on the communication card <input type="checkbox"/> [CANopen com.] (COF): Communication detected fault line 2 (CANopen) <input type="checkbox"/> [Capa.charg] (CrF): Capacitor precharge detected fault <input type="checkbox"/> [EEPROM] (EEF): EEPROM memory detected fault <input type="checkbox"/> [External] (EPF): External fault <input type="checkbox"/> [internal com. link] (ILF): Option internal link detected fault <input type="checkbox"/> [INTERNAL FAULT] (IF1): Unknown rating <input type="checkbox"/> [INTERNAL FAULT] (IF2): HMI card not recognized or incompatible/display absent <input type="checkbox"/> [INTERNAL FAULT] (IF3): EEPROM detected fault <input type="checkbox"/> [INTERNAL FAULT] (IF4): Industrial EEPROM detected fault <input type="checkbox"/> [4-20mA] (LFF): 4-20 mA loss <input type="checkbox"/> [No fault] (nOF): No fault code saved <input type="checkbox"/> [Overbraking] (ObF): DC bus overvoltage <input type="checkbox"/> [Overcurrent] (OCF): Overcurrent <input type="checkbox"/> [Drive overheat] (OHF): Drive overheating <input type="checkbox"/> [Motor overload] (OLF): Motor overload <input type="checkbox"/> [Mot. phase] (OPF): Motor phase loss <input type="checkbox"/> [Mains overvoltage] (OSF): Line supply overvoltage <input type="checkbox"/> [Mains phase loss] (PHF): Line phase loss <input type="checkbox"/> [Mot. short circuit] (SCF): Motor short-circuit (phase, ground) <input type="checkbox"/> [Modbus] (SLF): Modbus communication detected fault <input type="checkbox"/> [Overspeed] (SOF): Motor overspeed <input type="checkbox"/> [Auto-tuning] (tnF): Auto-tuning detected fault <input type="checkbox"/> [Undervoltage] (USF): Line supply undervoltage 	
o t r	[Motor torque] <p>100% = nominal motor torque, calculated using the parameters entered in the [MOTOR CONTROL] (drC-) menu.</p>	
r t H	[Run time] <p>Total time the motor has been powered up: 0 to 9,999 (hours), then 10.00 to 65.53 (kilo-hours). Can be reset to zero by the [Operating t. reset] (rPr) parameter in the [FAULT MANAGEMENT] (FLt-) menu, page 97.</p>	0 to 65,530 hours

Code	Description	Variation range
<p>Cod</p> <p>OFF</p> <p>on</p> <p>BBBB</p>	<p>[PIN code 1]</p> <p>Enables the drive configuration to be protected using an access code. When access is locked by means of a code, only the parameters in the [MONITORING] (SUP-) and [SPEED REFERENCE] (rEF-) menus can be accessed. The MODE button can be used to switch between menus.</p> <p>Note: Before entering a code, do not forget to make a careful note of it.</p> <p>[OFF] (OFF): No access locking codes</p> <ul style="list-style-type: none"> To lock access, enter a code (2 to 9,999). The display can be incremented using the jog dial. Then press ENT. [ON] (On) appears on the screen to indicate that access has been locked. <p>[ON] (On): A code is locking access (2 to 9,999).</p> <ul style="list-style-type: none"> To unlock access, enter the code (incrementing the display using the jog dial) and press ENT. The code remains on the display and access is unlocked until the next time the drive is turned off. Access will be locked again the next time the drive is turned on. If an incorrect code is entered, the display changes to [ON] (On), and access remains locked. <p>Access is unlocked (the code remains on the screen).</p> <ul style="list-style-type: none"> To reactivate locking with the same code when access has been unlocked, return to [ON] (On) using the jog dial and then press ENT. [ON] (On) remains on the screen to indicate that access has been locked. To lock access with a new code when access has been unlocked, enter the new code (increment the display using the jog dial) and then press ENT. On appears on the screen to indicate that access has been locked. To clear locking when access has been unlocked, return to [OFF] (OFF) using the jog dial and then press ENT. [OFF] (OFF) remains on the display. Access is unlocked and will remain so until the next restart. 	
<p>tUs</p> <p>tAb</p> <p>PEnd</p> <p>PrOG</p> <p>FAiL</p> <p>dOnE</p> <p>Strd</p> <p>CuS</p>	<p>[Auto tuning state]</p> <p>[Not done] (tAb): The default stator resistance value is used to control the motor.</p> <p>[Pending] (PEnd): Auto-tuning has been requested but not yet performed.</p> <p>[In Progress] (PrOG): Auto-tuning in progress.</p> <p>[Failed] (FAiL): Auto-tuning was unsuccessful.</p> <p>[Done] (dOnE): The stator resistance measured by the auto-tuning function is used to control the motor.</p> <p>[Entered R1] (Strd): The cold state stator resistance ([Cold stator resist.] (rSC) which is not set to [No] (nO)) is used to control the motor.</p> <p>[Customized] (CuS): The value of [Cold stator resist.] (rSC), page 43 is set manually.</p>	
uDP	<p>[Drv.Soft.Ver]</p> <p>This parameter gives the software version for the drive. Example: 1102 = V1.1 IE02</p>	
<p>oICt</p> <p>no</p> <p>dnb</p> <p>PbS</p>	<p>[OPT1 card type]</p> <p>This parameter is only visible if an option card is present. It is used to visualize the name of the option currently present.</p> <p>No card, CANopen card or DaisyChain card (these cards are unable to send their names to the ATV312)</p> <p>DeviceNet card</p> <p>Profibus card</p>	
CnF	<p>[Network fault]</p> <p>Option card fault code</p> <p>This parameter is read-only and is only visible if an option card is present.</p> <p>The fault code remains saved in the parameter, even if the cause disappears. The parameter is reset after the drive is disconnected and then reconnected. The values of this parameter depend on the network card. Consult the manual for the corresponding card.</p>	

[MONITORING] (SUP-) menu

REF -
SEt -
drC -
i - 0 -
CLtL -
Fun -
FLt -
C o n -
SUP -

Code	Name/Description	Adjustment range	Factory setting
L , A -	■ [LOGIC INPUT CONF.]		
L , 1A L , 2A L , 3A L , 4A L , 5A L , 6A	Can be used to display the functions assigned to each input. If no functions have been assigned, [No] (nO) is displayed. The jog dial can be used to scroll through all the functions. If a number of functions have been assigned to the same input, check that they are compatible.		
L , 5	Can be used to display the state of logic inputs (display segment assignment: high = 1, low = 0) State 1  State 0  LI1 LI2 LI3 LI4 LI5 LI6 Example above: LI1 and LI6 are at 1; LI2 to LI5 are at 0.		
A , A -	■ [ANALOG INPUTS IMAGE]		
A , 1A A , 2A A , 3A	Can be used to display the functions assigned to each input. If no functions have been assigned, [No] (nO) is displayed. The jog dial can be used to scroll through all the functions. If a number of functions have been assigned to the same input, check that they are compatible.		

Migration ATV31 - ATV312

The ATV312 is compatible with the ATV31.

To retrieve the configuration of the ATV31, simply transfer the configuration from the ATV31 to the ATV312. See below **Configuration transfer between an ATV31 and an ATV312**

Dimensions

For all sizes, the ATV312 is 6 mm less deep than the ATV31●●●●●●A.

Replacing an ATV31●●●●●●A with an ATV312

Note: Position of the logic input switch

On the ATV31●●●●●●A, the logic input switch was set to "Sink" in the factory setting.

On the ATV312, it is set to "Source" in the factory setting.

Set the switch to match the setting on the product being replaced. For more information, see the "Control terminals" chapter in the Installation Manual.

Note: Position of the IT jumper

There was no integrated EMC filter on the ATV31●●●●●●A. For details on how to deactivate the integrated EMC filter on the ATV312, see the "Operation with IT connection" chapter in the Installation Manual.

ATV312 used in LOCAL configuration (see page 27) uses the Jog Dial as a potentiometer and RUN button is activated. This is a similar way of working than ATV31●●●●●●A. When the drive is powered up for the first time, the two parameters shown below appear after [Standard mot. freq] (bFr). They need to be set as follows:

[Ref.1 channel] (Fr1), page 29, to [AI Virtual 1] (AIV1)

[2/3 wire control] (tCC), page 30, to [Local] (LOC)

The following parameters can be used subsequently to return to the other HMI version:

[Ref.1 channel] (Fr1) in the [COMMAND] (CtL-) menu

[2/3 wire control] (tCC) in the [INPUTS / OUTPUTS CFG] (I-O-) menu

Factory settings

As well as the differences in terms of control by potentiometer, the following differences apply between the factory settings for the ATV31●●●●●●A and those of the ATV312:

Parameter	ATV31●●●●●●A	ATV312
[2/3 wire control] (tCC)	Local control LOC	[2 wire] (2C)
[Ref.1 channel] (Fr1)	Analog input AIP	AI1
[Cmd channel 1] (Cd1)	Local control LOC	tEr
[Reverse assign.] (rrS)	[No] (nO) (if [2/3 wire control] (tCC) = [Local] (LOC))	LI2
[Forced local Ref.] (FLOC)	AIP jog dial	AIU1
[Select ATV31 conf.] (ArE)	Parameter does not exist on the ATV31	[No] (nO)

Configuration transfer between an ATV31 and an ATV312 (using the ATV31 remote terminal or a loader tool)

Compatible loader tools are :

- Multi-Loader V1.10 and higher,
- Simple-Loader V1.3 and higher,
- SoMove V1.1.11.1 and higher,
- SoMove Mobile V2.0 and higher,
- PC software.

Note: The transfer can't be done from an ATV31 to an ATV312 with a communication option board.

A new [Select ATV31 conf.] (ArE) parameter has been added to the [APPLICATION FUNCT.] (FUn-) menu.

It can be used to specify the ATV31 type (ATV31 or ATV31●●●●●●A) during transfers between an ATV31 and ATV312.

Values of the [Select ATV31 conf.] (ArE) parameter:

- [No] (nO), factory setting, transfer between two ATV312
- [ATV31...A] (31A), transfer from ATV31●●●●●●A to ATV312
- [ATV31 std] (31E), transfer from ATV31 to ATV312

To perform a configuration transfer, see the procedure on page 90.

Drive does not start, no code displayed

- If the display does not light up, check the power supply to the drive and check the wiring of inputs AI1 and AI2 and the connection to the RJ45 connector.
- The assignment of the "Fast stop" or "Freewheel stop" functions will prevent the drive from starting if the corresponding logic inputs are not powered up. The ATV312 then displays [Freewheel stop] (nSt) or [Fast stop] (FSt). This is normal since these functions are active at zero so that the drive will be stopped if there is a wire break.
- Check that the run command input(s) have been actuated in accordance with the chosen control mode (the [2/3 wire control] (tCC) parameter in the [INPUTS / OUTPUTS CFG] (I-O-) menu, page 47).
- If an input is assigned to the limit switch function and this input is at zero, the drive can only be started up by sending a command for the opposite direction (see page 89).
- If the reference channel (page 53) or the control channel (page 54) is assigned to a communication network, when the power supply is connected, the drive will display [Freewheel stop] (nSt) and remain in stop mode until the communication bus sends a command.
- If the LED on the DC bus is lit and nothing appears on the display, check that there is no short-circuit on the 10 V power supply.
- If the drive displays [Ready] (rdy) and refuses to start, check that there is no short-circuit on the 10 V power supply and check the wiring of inputs AI1 and AI2 and the connection to the RJ45 connector.
- In the factory setting, the "RUN" button is inactive. Set the [Ref.1 channel] (Fr1) parameter, page 29, and the [Cmd channel 1] (Cd1) parameter, page 59, to control the drive locally.

Fault detection codes which require a power reset after the fault is cleared

The cause of the fault must be removed before resetting by cycling power to the drive.

[PRECHARGE FAULT] (CrF), [OVERSPEED] (SOF), [AUTO-TUNING FAULT] (tnF), and [BRAKE CONTROL FAULT] (bLF) can also be reset remotely using a logic input (the [Fault reset] (rSF) parameter in the [FAULT MANAGEMENT] (FLt-) menu, page 92).

Code	Name	Probable cause	Remedy
b L F	[BRAKE CONTROL FAULT]	<ul style="list-style-type: none"> • Brake release current not reached • Brake engage frequency threshold [Brake engage freq] (bEn) = [No] (nO) (not set) whereas the brake control [Brake assignment] (bLC) is assigned • Loss of one phase at drive output • Output contactor open 	<ul style="list-style-type: none"> • Check the drive/motor connection. • Check the motor windings. • Check the [Brake release I FW] (lbr) setting in the [APPLICATION FUNCT.] (FUn-) menu, page 84. • Apply the recommended settings for [Brake engage freq] (bEn), pages 83 and 84.
C r F	[PRECHARGE FAULT]	<ul style="list-style-type: none"> • Precharge relay control or damaged precharge resistor 	<ul style="list-style-type: none"> • Replace the drive.
E E F	[EEPROM FAULT]	<ul style="list-style-type: none"> • Internal memory 	<ul style="list-style-type: none"> • Check the environment (electromagnetic compatibility) • Replace the drive.
I F 1	[INTERNAL FAULT]	<ul style="list-style-type: none"> • Unknown rating 	<ul style="list-style-type: none"> • Replace the drive. • Restart the drive. • Contact a Schneider Electric representative.
I F 2	[INTERNAL FAULT]	<ul style="list-style-type: none"> • HMI card not recognized • HMI card incompatible • No display present 	
I F 3	[INTERNAL FAULT]	<ul style="list-style-type: none"> • EEPROM 	
I F 4	[INTERNAL FAULT]	<ul style="list-style-type: none"> • Industrial EEPROM 	

Diagnostics and troubleshooting (continued)

Fault detection codes which require a power reset after the fault is cleared (continued)

Code	Name	Probable cause	Remedy
o C F o C F o C F	[OVERCURRENT]	<ul style="list-style-type: none"> Parameters in the [SETTINGS] (SEt-) and [MOTOR CONTROL] (drC-) menus are incorrect. Inertia or load too high Mechanical locking Phase/Ground Motor short-circuit Impedant short-circuit 	<ul style="list-style-type: none"> Check the parameters in [SETTINGS] (SEt-), page 32, and [MOTOR CONTROL] (drC-) page 41 Check the size of the motor/drive/load Check the state of the mechanism
S C F	[MOTOR SHORT CIRCUIT]	<ul style="list-style-type: none"> Short-circuit at the drive output Significant ground leakage current at the drive output if several motors are connected in parallel Grounding at the drive output 	<ul style="list-style-type: none"> Check the cables connecting the drive to the motor, and the motor insulation. Reduce the switching frequency Connect chokes in series with the motor
S o F	[OVERSPEED]	<ul style="list-style-type: none"> Instability or Driving load too high 	<ul style="list-style-type: none"> Check the motor, gain and stability parameters Add a braking resistor Check the size of the motor/drive/load

Fault detection codes that can be reset with the automatic restart function after the cause has disappeared

See the [Automatic restart] (Atr) function, page 91.

These detected faults can also be reset by turning the drive off then on again or by means of a logic input (the [Fault reset] (rSF) parameter, page 92, in the [FAULT MANAGEMENT] (FLt-) menu, page 91).

Code	Name	Probable cause	Remedy
C n F	[NETWORK FAULT]	<ul style="list-style-type: none"> Communication detected fault on the communication card 	<ul style="list-style-type: none"> Check the environment (electromagnetic compatibility) Check the wiring. Check the time out. Replace the option card. See the [CANopen fault mgt] (COL) parameter page 95 to define the stop mode with a (CnF).
C o F	[CANopen FAULT]	<ul style="list-style-type: none"> Interruption in communication on the CANopen bus 	<ul style="list-style-type: none"> Check the communication bus Refer to the relevant product documentation.
E P F	[EXTERNAL FAULT]	<ul style="list-style-type: none"> Depending on user 	<ul style="list-style-type: none"> Depending on user
, L F	[INTERNAL LINK FAULT]	<ul style="list-style-type: none"> Identification detected fault of the communication card by the drive 	<ul style="list-style-type: none"> Check that the option card is compatible with the drive Replace the option card.
L F F	[4-20mA LOSS]	<ul style="list-style-type: none"> Loss of the 4-20 mA reference on input AI3 	<ul style="list-style-type: none"> Check the connection on input AI3.
o b F	[OVERBRAKING]	<ul style="list-style-type: none"> Braking too sudden or driving load 	<ul style="list-style-type: none"> Increase the deceleration time Install a braking resistor if necessary. Activate the [Dec ramp adapt.] (bra) function, page 64, if it is compatible with the application.
o H F	[DRIVE OVERHEAT]	<ul style="list-style-type: none"> Drive temperature too high 	<ul style="list-style-type: none"> Check the motor load, the drive ventilation and the environment. Wait for the drive to cool before restarting.

Diagnostics and troubleshooting (continued)

Fault detection codes that can be reset with the automatic restart function after the cause has disappeared (continued)

Code	Name	Probable cause	Remedy
OLF	[MOTOR OVERLOAD]	<ul style="list-style-type: none"> Triggered by excessive motor current [Cold stator resist.] (rSC) parameter value incorrect 	<ul style="list-style-type: none"> Check the [Mot. therm. current] (ItH) setting, page 33, of the motor thermal protection, check the motor load. Wait for the drive to cool before restarting. Remeasure [Cold stator resist.] (rSC), page 42.
OPF	[MOTOR PHASE LOSS]	<ul style="list-style-type: none"> Loss of one phase at drive output Output contactor open Motor not connected or motor power too low Instantaneous instability in the motor current 	<ul style="list-style-type: none"> Check the connections from the drive to the motor. If an output contactor is being used, set [Output Phase Loss] (OPL) to [Output cut] (OAC) ([FAULT MANAGEMENT] (FLt-) menu, page 94). Test on a low-power motor or without a motor: In factory settings mode, motor output phase loss detection is active ([Output Phase Loss] (OPL) = [Yes] (YES)). To check the drive in a test or maintenance environment without having to switch to a motor with the same rating as the drive (particularly useful in the case of high-power drives), deactivate motor phase loss detection ([Output Phase Loss] (OPL) = [No] (nO)). Check and optimize the [IR compensation] (UFR), [Rated motor volt.] (UnS), and [Rated mot. current] (nCr) parameters, and perform an [Auto tuning] (tUn) operation, page 43.
OSF	[MAINS OVERVOLTAGE]	<ul style="list-style-type: none"> Line voltage is too high. Disturbed line supply 	<ul style="list-style-type: none"> Check the line voltage.
PHF	[INPUT PHASE LOSS]	<ul style="list-style-type: none"> Drive incorrectly supplied or a fuse blown Failure of one phase Three-phase ATV312 used on a single-phase line supply Unbalanced load <p>This protection only operates with the drive on load</p>	<ul style="list-style-type: none"> Check the power connection and the fuses. Reset Use a three-phase line supply. Disable the detection by setting [Input phase loss] (IPL) = [No] (nO) ([FAULT MANAGEMENT] (FLt-) menu, page 94).
SLF	[MODBUS FAULT]	<ul style="list-style-type: none"> Interruption in communication on the Modbus bus Remote display terminal enabled ([HMI command] (LCC) = [Yes] (YES), page 61) and terminal disconnected. 	<ul style="list-style-type: none"> Check the communication bus Refer to the relevant product documentation. Check the link with the remote display terminal.
EnF	[AUTO TUNING FAULT]	<ul style="list-style-type: none"> Special motor or motor whose power is not suitable for the drive Motor not connected to the drive 	<ul style="list-style-type: none"> Use the L ratio or the [Var. torque] (P) ratio (see [U/F mot 1 selected] (Uft), page 44). Check that the motor is present during auto-tuning. If an output contactor is being used, close it during auto-tuning.

Diagnostics and troubleshooting (continued)

Fault detection codes that are reset as soon as their cause disappears

Code	Name	Probable cause	Remedy
CFF	[INCORRECT CONFIG.]	<ul style="list-style-type: none">The current configuration is inconsistent.Addition or removal of an option	<ul style="list-style-type: none">Return to factory settings or retrieve the backup configuration, if it is valid. See the [Restore config.] (FCS) parameter, page 46.
CFI	[INVALID CONFIG]	<ul style="list-style-type: none">Invalid configuration The configuration loaded in the drive via the serial link is inconsistent	<ul style="list-style-type: none">Check the configuration loaded previously.Load a consistent configuration.
USF	[UNDERVOLTAGE]	<ul style="list-style-type: none">Insufficient line supplyTransient voltage dipDamaged precharge resistor	<ul style="list-style-type: none">Check the voltage and the voltage parameter. Tripping threshold in [UNDERVOLTAGE] (USF) ATV312●●●●M2: 160 V ATV312●●●●M3: 160 V ATV312●●●●N4: 300 V ATV312●●●●S6: 430 VReplace the drive.

Diagnostics and troubleshooting (continued)

Fault detection codes displayed on the ATV12 remote display terminal

Code	Name	Description
in i t: (1)	Initialization in progress	<ul style="list-style-type: none"> The microcontroller is initializing. Search underway for communication configuration
C o n . E (1)	Communication error	<ul style="list-style-type: none"> Time out detected fault (50 ms) This message is displayed after 20 attempts at communication.
A - 1 7 (1)	Alarm button	<ul style="list-style-type: none"> A button has been held down for more than 10 seconds. The keypad is disconnected. The "keypad" wakes up when a button is pressed.
c L r (1)	Confirmation of detected fault reset	<ul style="list-style-type: none"> This is displayed when the STOP button is pressed once during a remote terminal detected fault.
d E u . E (1)	Drive disparity	<ul style="list-style-type: none"> The drive brand does not match that of the remote terminal.
r o m . E (1)	ROM anomaly	<ul style="list-style-type: none"> The remote terminal detects a ROM anomaly on the basis of checksum calculation.
r a m . E (1)	RAM anomaly	<ul style="list-style-type: none"> The remote terminal detects a RAM anomaly.
C P u . E (1)	Other detected faults	<ul style="list-style-type: none"> Other detected faults

(1) Flashing

Index of functions

[+/- SPEED]	76
[2/3 wire control]	47
[ACCESS LEVEL]	58
[Analog./logic output]	48
[Auto DC injection]	68
[Automatic restart]	91
[Auto tuning]	43
Brake control	83
[CANopen address]	98
[Catch on the fly]	93
[Cmd switching]	60
Control and reference channels	50
[Current limit 2]	86
[Current Limitation]	38
[DC injection assign.]	66
[Dec ramp adapt.]	64
Drive thermal protection	12
Drive ventilation	12
[Fast stop]	65
[Fault reset]	92
[Forced local assign.]	99
[Freewheel stop ass.]	67
[JOG]	75
Management of limit switches	89
[Modbus Address]	98
[Mot. therm. current]	33
Motor thermal protection	13
PI regulator	78
Preset speeds	71
[R1 Assignment]	49
[R2 Assignment]	49
[RAMPS]	62
[Ramp switch ass.]	64
[Ref. 2 switching]	59
Return to factory settings/Restore configuration	46
Saving the configuration	45
[Skip Frequency]	36
[STOP MODES](continued)	65
[SUMMING INPUTS]	70
[Switching freq.]	40
[SWITCHING MOTOR]	87
[U/F mot 1 selected]	44

Index of parameter codes and customer settings

Code	Page	Name	Unit	Value/Possible function		Factory setting	Customer setting
A C 2	32 64	[Acceleration 2]	s	In accordance with 1 n r	-	5	
A C C	32 63	[Acceleration]	s	In accordance with 1 n r	-	3	
A d C	68	[Auto DC injection]	-	n o y e s C t	[No]: No injection [Yes]: Standstill injection for adjustable period [Continuous]: Continuous standstill injection	y e s	
A d C o	98	[CANopen address]	-	0 to 1 2 7	-	0	
A d d	98	[Modbus Address]	-	1 to 2 4 7	-	1	
A , 1 A	104	[AI1 assignment]	-	-	-	-	
A , 2 A	104	[AI2 assignment]	-	-	-	-	
A , 3 A	104	[AI3 assignment]	-	-	-	-	
A , u I	31	[Image input AIV1]	%	0 to 1 0 0	-	-	
A o I t	48	[AO1 Type]	-	0 A 4 A 1 0 V	[Current]: Configuration 0 - 20 mA [Cur. 4-20]: Configuration 4 - 20 mA [Voltage]: Configuration 0 - 10 V	0	
A r E	90	[Select ATV31 conf.]		n o 3 1 A 3 1 E	[No]: Transfer between two ATV312 [ATV31...A]: Transfer from an ATV31 to an ATV312 [ATV31 std]: Transfer from an ATV31 to an ATV312	n o	
A t r	91	[Automatic restart]	-	n o y e s	[No]: Function inactive [Yes]: Automatic restart	n o	
b d C o	98	[CANopen bit rate]	kbps	1 0 . 0 2 0 . 0 5 0 . 0 1 2 5 . 0 2 5 0 . 0 5 0 0 . 0 1 0 0 0	[10 kbps]: 10 kbps [20 kbps]: 20 kbps [50 kbps]: 50 kbps [125 kbps]: 125 kbps [250 kbps]: 250 kbps [500 kbps]: 500 kbps [1 Mbps]: 1000 kbps	1 2 5 . 0	
b E n	84	[Brake engage freq]	-	n o 0 to L 5 P	Not set Adjustment range in Hz	n o	
b E t	85	[Brake engage time]	s	0 to 5	-	0 . 5	
b F r	29 41	[Standard mot. freq]	Hz	5 0 6 0	[50Hz IEC] [60Hz NEMA]	5 0	
b , P	85	[Brake impulse]	-	n o y e s	[No]: Motor torque during brake release in the direction of rotation requested [Yes]: Motor torque during brake release in forward rotation	n o	
b L C	84	[Brake assignment]	-	n o r 2 d o	[No]: Not assigned [R2]: Relay R2 [DO]: Logic output AOC	n o	
b r A	64	[Dec ramp adapt.]	-	n o y e s	[No]: Function inactive [Yes]: Function active	y e s	
b r L	84	[Brake release freq]	Hz	0 . 0 to 1 0 . 0	-	In accordance with the drive rating	
b r t	84	[Brake Release time]	s	0 to 5	-	0 . 5	

Index of parameter codes and customer settings

Code	Page	Name	Unit	Value/Possible function		Factory setting	Customer setting
C C S	<u>60</u>	[Cmd switching]	-	C d 1 C d 2 L , 1 L , 2 L , 3 L , 4 L , 5 L , 6 C 1 1 1 C 1 1 2 C 1 1 3 C 1 1 4 C 1 1 5 C 2 1 1 C 2 1 2 C 2 1 3 C 2 1 4 C 2 1 5	[Ch1 active] : Control channel = channel 1 [Ch2 active] : Control channel = channel 2 [L11]: Logic input LI1 [L12]: Logic input LI2 [L13]: Logic input LI3 [L14]: Logic input LI4 [L15]: Logic input LI5 [L16]: Logic input LI6 [C111]: Bit 11 of Modbus control word [C112]: Bit 12 of Modbus control word [C113]: Bit 13 of Modbus control word [C114]: Bit 14 of Modbus control word [C115]: Bit 15 of Modbus control word [C211]: Bit 11 of network control word [C212]: Bit 12 of network control word [C213]: Bit 13 of network control word [C214]: Bit 14 of network control word [C215]: Bit 15 of network control word	C d 1	
C d 1	<u>59</u>	[Cmd channel 1]	-	t E r L o c L C C n d b n E t	[Terminal]: Control via terminals [Local]: Control via keypad [Remot. HMI]: Control via remote display terminal [Modbus]: Control via Modbus [Network]: Control via the network	t E r	
C d 2	<u>60</u>	[Cmd channel 2]	-	t E r L o c L C C n d b n E t	[Terminal]: Control via terminals [Local]: Control via keypad [Remot. HMI]: Control via remote display terminal [Modbus]: Control via Modbus [Network]: Control via the network	n d b	
C F G	<u>45</u> <u>49</u> <u>61</u> <u>90</u>	[Macro configuration]	-	S t S S t d	[Start/Stop]: Start/stop configuration [Factory set.]: Factory configuration	S t d	
C H C F	<u>59</u>	[Profile]	-	S , n S E P	[Not separ.]: Combined [Separate]: Separate	S , n	
C H P	<u>87</u>	[Motor switching]	-	n o L , 1 L , 2 L , 3 L , 4 L , 5 L , 6 C d 1 1 C d 1 2 C d 1 3 C d 1 4 C d 1 5	[No]: Not assigned [L11]: Logic input LI1 [L12]: Logic input LI2 [L13]: Logic input LI3 [L14]: Logic input LI4 [L15]: Logic input LI5 [L16]: Logic input LI6 [CD11]: Bit 11 of the control word from a communication network [CD12]: Bit 12 of the control word from a communication network [CD13]: Bit 13 of the control word from a communication network [CD14]: Bit 14 of the control word from a communication network [CD15]: Bit 15 of the control word from a communication network	n o	
C L 1	<u>38</u>	[Current Limitation]	In	0.25 to 1.5	-	1.5	
C L 2	<u>38</u> <u>86</u>	[I Limit. 2 value]	In	0.25 to 1.5	-	1.5	
C n F	<u>103</u>	[Network fault]	-	-	-	-	
C o d	<u>103</u>	[PIN code 1]	-	O F F o n B B B B	[OFF]: No code is locking access [ON]: A code is locking access. Access is unlocked.	-	

Index of parameter codes and customer settings

Code	Page	Name	Unit	Value/Possible function		Factory setting	Customer setting
C o L	95	[CANopen fault mgt]	-	n o Y E S r n P F S t	[Ignore]: Ignore [Freewheel]: Detected fault management with freewheel stop [Ramp stop]: Detected fault management with stop on ramp [Fast stop]: Detected fault management with fast stop	Y E S	
C o P	60	[Copy channel 1<>2]	-	n o S P C d R L L	[No]: No copy [Reference]: Copy reference [Command]: Copy command [Cmd + ref.]: Copy command and reference	n o	
C o S	42	[Motor 1 Cosinus Phi]	-	0.5 to 1	-	In accordance with the drive rating	
C o S 2	88	[Motor 2 Cosinus Phi]	-	0.5 to 1	-	In accordance with the drive rating	
C r H 3	48	[AI3 max. value]	mA	4 to 20	-	20	
C r L 3	48	[AI3 min. value]	mA	0 to 20	-	4	
C t d	39	[Current threshold]	In	0 to 1.5	-	1	
d C F	65	[Differential current fault]	-	0 to 10	-	4	
d C ,	66	[DC injection assign.]	-	n o L 1 1 L 1 2 L 1 3 L 1 4 L 1 5 L 1 6 C d 1 1 C d 1 2 C d 1 3 C d 1 4 C d 1 5	[No]: Not assigned [LI1]: Logic input LI1 [LI2]: Logic input LI2 [LI3]: Logic input LI3 [LI4]: Logic input LI4 [LI5]: Logic input LI5 [LI6]: Logic input LI6 [CD11]: Bit 11 of the control word from a communication network [CD12]: Bit 12 of the control word from a communication network [CD13]: Bit 13 of the control word from a communication network [CD14]: Bit 14 of the control word from a communication network [CD15]: Bit 15 of the control word from a communication network	n o	
d E 2	32 64	[Deceleration 2]	s	In accordance with 100	-	5	
d E C	32 63	[[Deceleration]	s	In accordance with 100	-	3	
d o	48	[Analog./logic output]	-	n o a C r a F r a t r a P r F L t r u n F t A F L A C t A S r A t S A b L C R P L	[No]: Not assigned [I motor]: Motor current [Motor freq.]: Motor frequency [Motor torq.]: Motor torque [P. supplied]: Power supplied by the drive [Drive fault]: Detected fault. [Drv running]: Drive running [Freq. limit]: Frequency threshold reached [HSP limit]: High speed reached [Brake seq.]: Current threshold reached [Freq. ref.]: Frequency reference reached [Drv thermal]: Motor thermal threshold reached [Brake seq.]: Brake sequence [No 4-20mA]: Loss of 4-20 mA signal	n o	
d r n	96	[Derated operation]	-	n o Y E S	[No]: Function inactive [Yes]: Function active	n o	

Index of parameter codes and customer settings

Code	Page	Name	Unit	Value/Possible function		Factory setting	Customer setting
dSP	<u>77</u>	[Speed assignment]	-	no L11 L12 L13 L14 L15 L16	[No]: Not assigned [L11]: Logic input LI1 [L12]: Logic input LI2 [L13]: Logic input LI3 [L14]: Logic input LI4 [L15]: Logic input LI5 [L16]: Logic input LI6	no	
EPL	<u>93</u>	[External fault mgt]	-	no YES runP FSt	[Ignore]: Ignore [Freewheel]: Detected fault management with freewheel stop [Ramp stop]: Detected fault management with stop on ramp [Fast stop]: Detected fault management with fast stop	YES	
ErrCo	<u>98</u>	[Error code]	-	0 1 2 3 4	No error Bus off Life time CAN overrun Heartbeat	-	
ELF	<u>93</u>	[External fault ass.]	-	no L11 L12 L13 L14 L15 L16 CD11 CD12 CD13 CD14 CD15	[No]: Not assigned [L11]: Logic input LI1 [L12]: Logic input LI2 [L13]: Logic input LI3 [L14]: Logic input LI4 [L15]: Logic input LI5 [L16]: Logic input LI6 [CD11]: Bit 11 of the control word from a communication network [CD12]: Bit 12 of the control word from a communication network [CD13]: Bit 13 of the control word from a communication network [CD14]: Bit 14 of the control word from a communication network [CD15]: Bit 15 of the control word from a communication network	no	
fbS	<u>36</u> <u>80</u>	[PID fbk scale factor]	-	0.1 to 100	-	1	
FLS	<u>46</u> <u>49</u> <u>61</u> <u>90</u>	[Restore config.]	-	no reCt in	[NO]: Function inactive [Internal]: The current configuration becomes identical to the backup configuration previously saved by SCS = Setr . [Factory Set.]: Current configuration replaced by the configuration selected by the CFG parameter.	no	
FLG	<u>33</u>	[FreqLoopGain]	%	1 to 100	-	20	
FLG2	<u>39</u> <u>88</u>	[FreqLoopGain 2]	%	1 to 100	-	20	
FLo	<u>99</u>	[Forced local assign.]	-	no L11 L12 L13 L14 L15 L16	[No]: Not assigned [L11]: Logic input LI1 [L12]: Logic input LI2 [L13]: Logic input LI3 [L14]: Logic input LI4 [L15]: Logic input LI5 [L16]: Logic input LI6	no	
FLoC	<u>99</u>	[Forced local Ref.]	-	A11 A12 A13 A10 LCC	[A11]: Analog input AI1, logic inputs LI [A12]: Analog input AI2, logic inputs LI [A13]: Analog input AI3, logic inputs LI [Network AI]: Jog dial, RUN/STOP buttons [HMI]: Remote display terminal, RUN/STOP/FWD/REV buttons	A11	
FLr	<u>93</u>	[Catch on the fly]	-	no YES	[No]: Function inactive [Yes]: Function active	no	

Index of parameter codes and customer settings

Code	Page	Name	Unit	Value/Possible function		Factory setting	Customer setting
Fr 1	<u>29</u> <u>58</u>	[Ref.1 channel]	-	A 1 1 A 1 2 A 1 3 A 1 u 1 u P d t u P d H L C C n d b n E t	[A11]: Analog input AI1 [A12]: Analog input AI2 [A13]: Analog input AI3 [Network AI]: Jog dial [+/-Speed]: +/- speed reference via L 1 [+/-spd HMI]: +/- speed reference using the jog dial on the ATV312 keypad [HMI]: Reference via the remote display terminal [Modbus]: Reference via Modbus [Network]: Reference via network	A 1 1	
Fr 2	<u>58</u>	[Ref.2 channel]	-	n o A 1 1 A 1 2 A 1 3 A 1 u 1 u P d t u P d H L C C n d b n E t	[No]: Not assigned [A11]: Analog input AI1 [A12]: Analog input AI2 [A13]: Analog input AI3 [Network AI]: Jog dial [+/-Speed]: +/- speed reference via L 1 [+/-spd HMI]: +/- speed reference using the jog dial on the ATV312 keypad [HMI]: Reference via the remote display terminal [Modbus]: Reference via Modbus [Network]: Reference via network	n o	
Fr H	<u>101</u>	[Frequency ref.]	Hz	0 to 500	-	-	
Fr 5	<u>41</u>	[Rated motor freq.]	Hz	10 to 500	-	50	
Fr 5 2	<u>87</u>	[Nom. motor 2 freq.]	Hz	10 to 500	-	50	
Fr t	<u>64</u>	[Ramp 2 threshold]	Hz	0 to 500	-	0	
F 5 t	<u>65</u>	[Fast stop]	-	n o L 1 1 L 1 2 L 1 3 L 1 4 L 1 5 L 1 6 C d 1 1 C d 1 2 C d 1 3 C d 1 4 C d 1 5	[No]: Not assigned [L11]: Logic input LI1 [L12]: Logic input LI2 [L13]: Logic input LI3 [L14]: Logic input LI4 [L15]: Logic input LI5 [L16]: Logic input LI6 [CD11]: Bit 11 of the control word from a communication network [CD12]: Bit 12 of the control word from a communication network [CD13]: Bit 13 of the control word from a communication network [CD14]: Bit 14 of the control word from a communication network [CD15]: Bit 15 of the control word from a communication network	n o	
F t d	<u>39</u>	[Freq. threshold]	Hz	0 to 500	-	b F r	
H 5 P	<u>33</u>	[High speed]	Hz	L 5 P to t F r	-	b F r	
i b r	<u>84</u>	[Brake release I FW]	In	0 to 1.36	-	In accordance with the drive rating	
i d C	<u>34</u> <u>66</u>	[DC inject. level 1]	In	0 to In	-	0.7	
i n H	<u>96</u>	[Fault inhibit assign.]	-	n o L 1 1 L 1 2 L 1 3 L 1 4 L 1 5 L 1 6	[No]: Not assigned [L11]: Logic input LI1 [L12]: Logic input LI2 [L13]: Logic input LI3 [L14]: Logic input LI4 [L15]: Logic input LI5 [L16]: Logic input LI6	n o	

Index of parameter codes and customer settings

Code	Page	Name	Unit	Value/Possible function		Factory setting	Customer setting
rnc	63	[Ramp increment]	-	0.01 0.1 1	[0.01]: Ramp can be set between 0.05 s and 327.6 s. [0.1]: Ramp can be set between 0.1 s and 3,276 s. [1]: Ramp can be set between 1 s and 32,760 s.	0.1	
rPL	94	[Input phase loss]	-	no YES	[No]: Ignore [Yes]: Detected fault management with freewheel stop	YES	
rTH	33	[Mot. therm. current]	In	0.2 to 1.5	-	In accordance with the drive rating	
JF2	36	[Skip Frequency 2]	Hz	1 to 500	-	0	
JGF	36 75	[Jog frequency]	Hz	0 to 10	-	10	
JOG	75	[JOG]	-	no L11 L12 L13 L14 L15 L16	[No]: Not assigned [L11]: Logic input LI1 [L12]: Logic input LI2 [L13]: Logic input LI3 [L14]: Logic input LI4 [L15]: Logic input LI5 [L16]: Logic input LI6	no	
JPF	36	[Skip Frequency]	Hz	0 to 500	-	0	
LAC	58	[ACCESS LEVEL]	-	L1 L2 L3	[Level 1]: Access to standard functions [Level 2]: Access to advanced functions in the Fun -menu [Level 3]: Access to advanced functions and management of mixed control modes	L1	
LAF	89	[Stop FW limit sw.]	-	no L11 L12 L13 L14 L15 L16	[No]: Not assigned [L11]: Logic input LI1 [L12]: Logic input LI2 [L13]: Logic input LI3 [L14]: Logic input LI4 [L15]: Logic input LI5 [L16]: Logic input LI6	no	
LAR	89	[Stop RV limit sw.]	-	no L11 L12 L13 L14 L15 L16	[No]: Not assigned [L11]: Logic input LI1 [L12]: Logic input LI2 [L13]: Logic input LI3 [L14]: Logic input LI4 [L15]: Logic input LI5 [L16]: Logic input LI6	no	
LAS	89	[Stop type]	-	rPP FSt nSt	[Ramp stop]: On ramp [Fast stop]: Fast stop [Freewheel]: Freewheel stop	nSt	
LCL	86	[Current limit 2]	-	no L11 L12 L13 L14 L15 L16 CD11 CD12 CD13 CD14 CD15	[No]: Not assigned [L11]: Logic input LI1 [L12]: Logic input LI2 [L13]: Logic input LI3 [L14]: Logic input LI4 [L15]: Logic input LI5 [L16]: Logic input LI6 [CD11]: Bit 11 of the control word from a communication network [CD12]: Bit 12 of the control word from a communication network [CD13]: Bit 13 of the control word from a communication network [CD14]: Bit 14 of the control word from a communication network [CD15]: Bit 15 of the control word from a communication network	no	
LCC	61	[HMI command]	-	no YES	[No]: Function inactive [Yes]: Enables control of the drive using the STOP/RESET, RUN and FWD/REV buttons on the display terminal	no	
LCL	101	[Motor current]	A	-	-	-	

Index of parameter codes and customer settings

Code	Page	Name	Unit	Value/Possible function		Factory setting	Customer setting
L E L	<u>93</u>	[External fault config]	-	L o H i G	[Active low]: The external fault is detected when the logic input assigned to E L F changes to state 0. [Active high]: The external fault is detected when the logic input or bit assigned to E L F changes to state 1.	H i G	
L F F	<u>95</u>	[Fallback speed]	Hz	0 to 500	-	10	
L F L	<u>95</u>	[4-20mA loss]	-	n o Y E S L F F r L S r n P F S L	[Ignore]: Ignore [Freewheel]: Detected fault management with freewheel stop [fallback spd]: The drive switches to the fallback speed. [Spd maint.]: The drive maintains the speed at which it was operating when the fault occurred. [Ramp stop]: Detected fault management with stop on ramp [Fast stop]: Detected fault management with fast stop	Y E S	
L F r	<u>32</u> <u>101</u>	[HMI Frequency ref.]	-	0 to H S P	-	-	
L F L	<u>102</u>	[Last fault occurred]	-	b L F C F F C F I C n F C o F C r F E E F E P F I F 1 I F 2 I F 3 I F 4 L F F n o F o b F o C F o H F o L F o P F o S F P H F S C F S L F S o F t n F u S F	[Brake control]: Brake control detected fault [Incorrect config.]: Incorrect configuration [Invalid config.]: Invalid configuration [NETWORK FAULT]: Communication detected fault on the communication card [CANopen com.]: Communication detected fault line 2 (CANopen) [Capa.charg]: Capacitor precharge detected fault [EEPROM]: EEPROM memory detected fault [External]: External fault [INTERNAL FAULT]: Unknown rating [INTERNAL FAULT]: HMI card not recognized or incompatible/display absent [INTERNAL FAULT]: EEPROM detected fault [INTERNAL FAULT]: Industrial EEPROM detected fault [4-20mA]: 4-20 mA loss [No fault]: No fault code saved [Overbraking]: DC bus overvoltage [Overcurrent]: Overcurrent [Drive overheat]: Drive overheating [Motor overload]: Motor overload [Mot. phase]: Motor phase loss [Mains overvoltage]: Line supply overvoltage [Mains phase loss]: Line phase loss [Mot. short circuit]: Motor short-circuit (phase, ground) [Modbus]: Modbus communication detected fault [Overspeed]: Motor overspeed [Auto-tuning]: Auto-tuning detected fault [Undervoltage]: Line supply undervoltage		
L I 1 A	<u>104</u>	[Config.LI1]	-	-			
L I 2 A	<u>104</u>	[Config.LI2]	-	-			
L I 3 A	<u>104</u>	[Config.LI3]	-	-			
L I 4 A	<u>104</u>	[Config.LI4]	-	-			
L I 5 A	<u>104</u>	[Config.LI5]	-	-			
L I 6 A	<u>104</u>	[Config.LI6]	-	-			
L S P	<u>33</u> <u>84</u>	[Low speed]	Hz	0 to H S P	-	0	
n C r	<u>41</u>	[Rated mot. current]	In	0.25 to 1.5	-	In accordance with the drive rating	
n C r 2	<u>88</u>	[Nom. mot. 2 current]	In	0.25 to 1.5	-	In accordance with the drive rating	
n r d	<u>44</u>	[Noise reduction]	-	Y E S n o	[Yes]: Frequency with random modulation [No]: Fixed frequency	YES	

Index of parameter codes and customer settings

Code	Page	Name	Unit	Value/Possible function		Factory setting	Customer setting
nSP	<u>42</u>	[Rated motor speed]	rpm	0 to 32,760	-	In accordance with the drive rating	
nSP2	<u>88</u>	[Nom. mot. 2 speed]	rpm	0 to 32,760	-	In accordance with the drive rating	
nSt	<u>67</u>	[Freewheel stop ass.]	-	no L11 L12 L13 L14 L15 L16	[No]: Not assigned [LI1]: Logic input LI1 [LI2]: Logic input LI2 [LI3]: Logic input LI3 [LI4]: Logic input LI4 [LI5]: Logic input LI5 [LI6]: Logic input LI6	no	
oICt	<u>103</u>	[OPT1 card type]	-			YES	
oHL	<u>94</u>	[Overtemp fault mgt]	-	no YES rnP FSt	[Ignore]: Ignore [Freewheel]: Detected fault management with freewheel stop [Ramp stop]: Detected fault management with stop on ramp [Fast stop]: Detected fault management with fast stop	YES	
oLL	<u>94</u>	[Overload fault mgt]	-	no YES rnP FSt	[Ignore]: Ignore [Freewheel]: Detected fault management with freewheel stop [Ramp stop]: Detected fault management with stop on ramp [Fast stop]: Detected fault management with fast stop	YES	
oPL	<u>94</u>	[Output Phase Loss]	-	no YES oAC	[No]: Function inactive [Yes]: Tripping on oPF [Output cut]: No tripping on [MOTOR PHASE LOSS] (OPF), but output voltage is managed	YES	
oPr	<u>101</u>	[Motor power]	%	-	-	-	
oTr	<u>102</u>	[Motor torque]	%	-	-	-	
PiC	<u>36</u> <u>80</u>	[PID correct. reverse]	-	no YES	[No]: Normal [Yes]: Reverse	no	
PiF	<u>80</u>	[PID feedback ass.]	-	no A11 A12 A13	[No]: Not assigned [AI1]: Analog input AI1 [AI2]: Analog input AI2 [AI3]: Analog input AI3	no	
Pir	<u>82</u>	[Act. internal PID ref.]	-	no YES	[No]: The reference for the PI regulator is Fri , except for uPdH and uPdt . [Yes]: The reference for the PI regulator is provided internally via the rPi parameter.	no	
Pr2	<u>80</u>	[2 preset PID ref.]	-	no L11 L12 L13 L14 L15 L16 CD11 CD12 CD13 CD14 CD15	[No]: Not assigned [LI1]: Logic input LI1 [LI2]: Logic input LI2 [LI3]: Logic input LI3 [LI4]: Logic input LI4 [LI5]: Logic input LI5 [LI6]: Logic input LI6 [CD11]: Bit 11 of the control word from a communication network [CD12]: Bit 12 of the control word from a communication network [CD13]: Bit 13 of the control word from a communication network [CD14]: Bit 14 of the control word from a communication network [CD15]: Bit 15 of the control word from a communication network	no	

Index of parameter codes and customer settings

Code	Page	Name	Unit	Value/Possible function		Factory setting	Customer setting
P r 4	81	[4 preset PID ref.]	-	n o L , 1 L , 2 L , 3 L , 4 L , 5 L , 6 C d 1 1 C d 1 2 C d 1 3 C d 1 4 C d 1 5	[No]: Not assigned [LI1]: Logic input LI1 [LI2]: Logic input LI2 [LI3]: Logic input LI3 [LI4]: Logic input LI4 [LI5]: Logic input LI5 [LI6]: Logic input LI6 [CD11]: Bit 11 of the control word from a communication network [CD12]: Bit 12 of the control word from a communication network [CD13]: Bit 13 of the control word from a communication network [CD14]: Bit 14 of the control word from a communication network [CD15]: Bit 15 of the control word from a communication network	n o	
P S 1 6	73	[16 preset speeds]	-	n o L , 1 L , 2 L , 3 L , 4 L , 5 L , 6 C d 1 1 C d 1 2 C d 1 3 C d 1 4 C d 1 5	[No]: Not assigned [LI1]: Logic input LI1 [LI2]: Logic input LI2 [LI3]: Logic input LI3 [LI4]: Logic input LI4 [LI5]: Logic input LI5 [LI6]: Logic input LI6 [CD11]: Bit 11 of the control word from a communication network [CD12]: Bit 12 of the control word from a communication network [CD13]: Bit 13 of the control word from a communication network [CD14]: Bit 14 of the control word from a communication network [CD15]: Bit 15 of the control word from a communication network	n o	
P S 2	72	[2 preset speeds]	-	n o L , 1 L , 2 L , 3 L , 4 L , 5 L , 6 C d 1 1 C d 1 2 C d 1 3 C d 1 4 C d 1 5	[No]: Not assigned [LI1]: Logic input LI1 [LI2]: Logic input LI2 [LI3]: Logic input LI3 [LI4]: Logic input LI4 [LI5]: Logic input LI5 [LI6]: Logic input LI6 [CD11]: Bit 11 of the control word from a communication network [CD12]: Bit 12 of the control word from a communication network [CD13]: Bit 13 of the control word from a communication network [CD14]: Bit 14 of the control word from a communication network [CD15]: Bit 15 of the control word from a communication network	L , 3	
P S 4	72	[4 preset speeds]	-	n o L , 1 L , 2 L , 3 L , 4 L , 5 L , 6 C d 1 1 C d 1 2 C d 1 3 C d 1 4 C d 1 5	[No]: Not assigned [LI1]: Logic input LI1 [LI2]: Logic input LI2 [LI3]: Logic input LI3 [LI4]: Logic input LI4 [LI5]: Logic input LI5 [LI6]: Logic input LI6 [CD11]: Bit 11 of the control word from a communication network [CD12]: Bit 12 of the control word from a communication network [CD13]: Bit 13 of the control word from a communication network [CD14]: Bit 14 of the control word from a communication network [CD15]: Bit 15 of the control word from a communication network	L , 4	
P S 8	72	[8 preset speeds]	-	n o L , 1 L , 2 L , 3 L , 4 L , 5 L , 6 C d 1 1 C d 1 2 C d 1 3 C d 1 4 C d 1 5	[No]: Not assigned [LI1]: Logic input LI1 [LI2]: Logic input LI2 [LI3]: Logic input LI3 [LI4]: Logic input LI4 [LI5]: Logic input LI5 [LI6]: Logic input LI6 [CD11]: Bit 11 of the control word from a communication network [CD12]: Bit 12 of the control word from a communication network [CD13]: Bit 13 of the control word from a communication network [CD14]: Bit 14 of the control word from a communication network [CD15]: Bit 15 of the control word from a communication network	n o	
P S t	61	[[Stop Key priority]]	-	n o y e s	[No]: Function inactive [Yes]: STOP key priority	y e s	

Index of parameter codes and customer settings

Code	Page	Name	Unit	Value/Possible function	Factory setting	Customer setting
<i>r 1</i>	<u>49</u>	[R1 Assignment]	-	<i>no</i> <i>FLt</i> <i>run</i> <i>FtR</i> <i>FLR</i> <i>CtR</i> <i>SrR</i> <i>tSR</i> <i>APL</i> <i>L 1 1</i> to <i>L 1 6</i>	[No]: Not assigned [No drive flt]: No drive detected fault [Drv running]: Drive running [Freq.Th.att]: Frequency threshold reached [HSP attain.]: High speed reached [I attained]: Current threshold reached [Freq.ref.att]: Frequency reference reached [Th.mot. att.]: Motor thermal threshold reached [4-20mA]: Loss of 4-20 mA signal [LI1] to [LI6]: Returns the value of the selected logic input	<i>FLt</i>
<i>r 2</i>	<u>49</u>	[R2 Assignment]	-	<i>no</i> <i>FLt</i> <i>run</i> <i>FtR</i> <i>FLR</i> <i>CtR</i> <i>SrR</i> <i>tSR</i> <i>APL</i> <i>L 1 1</i> to <i>L 1 6</i>	[No]: Not assigned [No drive flt]: No drive detected fault [Drv running]: Drive running [Freq.Th.att]: Frequency threshold reached [HSP attain.]: High speed reached [I attained]: Current threshold reached [Freq.ref.att]: Frequency reference reached [Th.mot. att.]: Motor thermal threshold reached [Brk control]: Brake sequence [4-20mA]: Loss of 4-20 mA signal [LI1] to [LI6]: Returns the value of the selected logic input	<i>no</i>
<i>r F C</i>	<u>59</u>	[Ref. 2 switching]	-	<i>F r 1</i> <i>F r 2</i> <i>L 1 1</i> <i>L 1 2</i> <i>L 1 3</i> <i>L 1 4</i> <i>L 1 5</i> <i>L 1 6</i> <i>C 1 1 1</i> <i>C 1 1 2</i> <i>C 1 1 3</i> <i>C 1 1 4</i> <i>C 1 1 5</i> <i>C 2 1 1</i> <i>C 2 1 2</i> <i>C 2 1 3</i> <i>C 2 1 4</i> <i>C 2 1 5</i>	[ch1 active]: Reference 1 [ch2 active]: Reference 2 [LI1]: Logic input LI1 [LI2]: Logic input LI2 [LI3]: Logic input LI3 [LI4]: Logic input LI4 [LI5]: Logic input LI5 [LI6]: Logic input LI6 [C111]: Bit 11 of Modbus control word [C112]: Bit 12 of Modbus control word [C113]: Bit 13 of Modbus control word [C114]: Bit 14 of Modbus control word [C115]: Bit 15 of Modbus control word [C211]: Bit 11 of network control word [C212]: Bit 12 of network control word [C213]: Bit 13 of network control word [C214]: Bit 14 of network control word [C215]: Bit 15 of network control word	<i>F r 1</i>
<i>r F r</i>	<u>101</u>	[Output frequency]	Hz	- <i>500</i> to + <i>500</i>	-	-
<i>r 1 G</i>	<u>36</u> <u>80</u>	[PID integral gain]	-	<i>0.0 1</i> to <i>100</i>	-	<i>1</i>
<i>r o t</i>	<u>61</u>	[Rotating direction]	-	<i>d F r</i> <i>d r S</i> <i>b o t</i>	[Forward]: Forward [Reverse]: Reverse [Both]: Both directions are authorized.	<i>d F r</i>
<i>r P</i>	<u>97</u>	[Product reset]	-	<i>no</i> <i>y e s</i>	[No]: No [Yes]: Yes	<i>no</i>
<i>r P 2</i>	<u>36</u> <u>81</u>	[Preset ref. PID 2]	%	<i>0</i> to <i>100</i>	-	<i>30</i>
<i>r P 3</i>	<u>36</u> <u>81</u>	[Preset ref. PID 3]	%	<i>0</i> to <i>100</i>	-	<i>60</i>
<i>r P 4</i>	<u>36</u> <u>81</u>	[Preset ref. PID 4]	%	<i>0</i> to <i>100</i>	-	<i>90</i>
<i>r P G</i>	<u>36</u> <u>80</u>	[PID prop. gain]	-	<i>0.0 1</i> to <i>100</i>	-	<i>1</i>
<i>r P 1</i>	<u>32</u> <u>82</u> <u>101</u>	[Internal PID ref.]	%	<i>0</i> to <i>100</i>	-	<i>0</i>
<i>r P r</i>	<u>97</u>	[Operating t. reset]	-	<i>no</i> <i>r t H</i>	[No]: No [rst. runtime]: Operating time reset to zero	<i>no</i>

Index of parameter codes and customer settings

Code	Page	Name	Unit	Value/Possible function		Factory setting	Customer setting
r P 5	64	[Ramp switch ass.]	-	n o L 1 1 L 1 2 L 1 3 L 1 4 L 1 5 L 1 6 C d 1 1 C d 1 2 C d 1 3 C d 1 4 C d 1 5	[No]: Not assigned [LI1]: Logic input LI1 [LI2]: Logic input LI2 [LI3]: Logic input LI3 [LI4]: Logic input LI4 [LI5]: Logic input LI5 [LI6]: Logic input LI6 [CD11]: Bit 11 of the control word from a communication network [CD12]: Bit 12 of the control word from a communication network [CD13]: Bit 13 of the control word from a communication network [CD14]: Bit 14 of the control word from a communication network [CD15]: Bit 15 of the control word from a communication network	n o	
r P t	62	[Ramp type]	-	L i n S u C u S	[Linear]: Linear [S ramp]: S ramp [U ramp]: U ramp [Customized]: Customized	L i n	
r r 5	48	[Reverse assign.]	-	n o L 1 1 L 1 2 L 1 3 L 1 4 L 1 5 L 1 6	[No]: Not assigned [LI1]: Logic input LI1 [LI2]: Logic input LI2 can be accessed if t C C = 2 C . [LI3]: Logic input LI3 [LI4]: Logic input LI4 [LI5]: Logic input LI5 [LI6]: Logic input LI6	L 1 2	
r S C	42	[Cold stator resist.]	-	n o i n i t B B B B	[NO]: Function inactive [Init]: Activates the function Value of cold state stator resistance used	n o	
r S F	92	[Fault reset]	-	n o L 1 1 L 1 2 L 1 3 L 1 4 L 1 5 L 1 6	[No]: Not assigned [LI1]: Logic input LI1 [LI2]: Logic input LI2 [LI3]: Logic input LI3 [LI4]: Logic input LI4 [LI5]: Logic input LI5 [LI6]: Logic input LI6	n o	
r S L	38 82	[PID wake up thresh.]	%	0 to 100	-	0	
r t H	102	[Run time]	Time	-	-	-	
S R 2	70	[Summing ref. 2]	-	n o A 1 1 A 1 2 A 1 3 A i u 1 L C C n d b n E t	[No]: Not assigned [AI1]: Analog input AI1 [AI2]: Analog input AI2 [AI3]: Analog input AI3 [Network AI]: Jog dial [HMI]: Reference via the remote display terminal [Modbus]: Reference via Modbus [Network]: Reference via network	A 1 2	
S R 3	70	[Summing ref. 3]	-	n o A 1 1 A 1 2 A 1 3 A i u 1 L C C n d b n E t	[No]: Not assigned [AI1]: Analog input AI1 [AI2]: Analog input AI2 [AI3]: Analog input AI3 [Network AI]: Jog dial [HMI]: Reference via the remote display terminal [Modbus]: Reference via Modbus [Network]: Reference via network	n o	
S C S	45 49 61 90	[Saving config.]	-	n o S t r 1	[No]: Function inactive [Config 1]: Saves the current configuration to EEPROM	n o	
S d C 1	35 68	[Auto DC inj. level 1]	In	0 to 1.2	-	0.7	
S d C 2	35 69	[Auto DC inj. level 2]	In	0 to 1.2	-	0.5	
S d 5	40	[Scale factor display]	-	0.1 to 200	-	30	

Index of parameter codes and customer settings

Code	Page	Name	Unit	Value/Possible function		Factory setting	Customer setting
S F r	40 44	[Switching freq.]	kHz	2.0 to 16	-	4	
S L L	95	[Modbus fault mgt]	-	n o y e s r a m p f s t	[Ignore]: Ignore [Freewheel]: Detected fault management with freewheel stop. [Ramp stop]: Detected fault management with stop on ramp [Fast stop]: Detected fault management with fast stop	y e s	
S L P	34	[Slip compensation]	%	0 to 150	-	100	
S L P 2	39 88	[Slip compensation 2]	%	0 to 150	-	100	
S P 10	37 73	[Preset speed 10]	Hz	0 to 500	-	50	
S P 11	37 74	[Preset speed 11]	Hz	0 to 500	-	55	
S P 12	37 74	[Preset speed 12]	Hz	0 to 500	-	60	
S P 13	37 74	[Preset speed 13]	Hz	0 to 500	-	70	
S P 14	37 74	[Preset speed 14]	Hz	0 to 500	-	80	
S P 15	37 74	[Preset speed 15]	Hz	0 to 500	-	90	
S P 16	37 74	[Preset speed 16]	Hz	0 to 500	-	100	
S P 2	36 73	[Preset speed 2]	Hz	0 to 500	-	10	
S P 3	37 73	[Preset speed 3]	Hz	0 to 500	-	15	
S P 4	37 73	[Preset speed 4]	Hz	0 to 500	-	20	
S P 5	37 73	[Preset speed 5]	Hz	0 to 500	-	25	
S P 6	37 73	[Preset speed 6]	Hz	0 to 500	-	30	
S P 7	37 73	[Preset speed 7]	Hz	0 to 500	-	35	
S P 8	37 73	[Preset speed 8]	Hz	0 to 500	-	40	
S P 9	37 73	[Preset speed 9]	Hz	0 to 500	-	45	
S P d 1	101	[Cust. output value]	-	-	-	-	
S P d 2	101	[Cust. output value]	-	-	-	-	
S P d 3	101	[Cust. output value]	-	-	-	-	
S r F	44	[Speed loop filter]	-	n o y e s	[No]: Filter remains active [Yes]: Filter suppressed	n o	
S t A	34	[Fr.Loop.Stab]	%	1 to 100	-	20	
S t A 2	39 88	[Freq. loop stability 2]	%	0 to 100	-	20	

Index of parameter codes and customer settings

Code	Page	Name	Unit	Value/Possible function		Factory setting	Customer setting
StP	96	[UnderV. prevention]	-	no ns rNP FSt	[No]: Locking of the drive and freewheel stopping of the motor [DC Maintain]: Stop mode using inertia to maintain the drive power supply as long as possible [Ramp stop]: Stop according to the valid ramp [Fast stop]: Fast stop	no	
St r	77	[Reference saved]	-	no rRn EEP	[No]: No saving [RAM]: Saving in RAM [EEprom]: Saving in EEPROM	no	
St t	65	[Type of stop]	-	rNP FSt ns t dC i	[Ramp stop]: On ramp [Fast stop]: Fast stop [Freewheel]: Freewheel stop [DC injection]: DC injection stop	rNP	
tR1	33 63	[Begin Acc round]	%	0 to 100	-	10	
tR2	33 63	[End Acc round]	%	0 to (100 - tR1)	-	10	
tR3	33 63	[Begin Dec round]	%	0 to 100	-	10	
tR4	33 63	[End Dec round]	%	0 to (100 - tR3)	-	10	
tRr	92	[Max. restart time]	-	5 10 30 1h 2h 3h Ct	[5 minutes]: 5 minutes [10 minutes]: 10 minutes [30 minutes]: 30 minutes [1 hour]: 1 hour [2 hours]: 2 hours [3 hours]: 3 hours [Unlimited]: Unlimited	5	
tbr	98	[Modbus baud rate]	bps	4.8 9.6 19.2	[4.8 Kbps]: 4,800 bits/second [9.6 Kbps]: 9600 bits/second [19.2 Kbps]: 19,200 bits/second	19.2	
tCC	30 47	[2/3 wire control]	-	2C 3C LoC	[2 wire]: 2-wire control [3 wire]: 3-wire control [Local]: Local control (drive RUN/STOP/RESET)	2C	
tCt	47	[2 wire type]	-	LEL trn PFO	[Level]: State 0 or 1 [Transition]: Change of state (transition or edge) [Fwd priority]: State 0 or 1, "forward" input takes priority over the "reverse" input	trn	
t dC	34 67	[DC injection time 2]	s	0.1 to 30	-	0.5	
t dC 1	34 68	[Auto DC inj. time 1]	s	0.1 to 30	-	0.5	
t dC 2	35 69	[Auto DC inj. time 2]	s	0 to 30	-	0	
tFo	98	[Modbus format]	-	Bo1 BE1 Bn1 Bn2	[8-O-1]: 8 data bits, odd parity, 1 stop bit [8-E-1]: 8 data bits, even parity, 1 stop bit [8-N-1]: 8 data bits, no parity, 1 stop bit [8-N-2]: 8 data bits, no parity, 2 stop bits	BE1	
tFr	44	[Max frequency]	Hz	10 to 500	-	60	
tHd	101	[Drv. Therm att.]	-	-	-	-	
tHr	101	[Motor thermal state]	-	-	-	-	
tLS	38	[Low speed time out]	s	0 to 999.9	-	0	

Index of parameter codes and customer settings

Code	Page	Name	Unit	Value/Possible function		Factory setting	Customer setting
t n L	95	[Autotune fault mgt]	-	n o y e s	[No]: Ignore [Yes]: Detected fault management with drive locked	y e s	
t t d	39	[Motor therm. level]	%	1 to 118	-	100	
t t o	98	[Modbus time out]	s	0.1 to 30	-	10	
t u n	43	[Auto tuning]	-	n o y e s d o n e r u n P o n L 1 to L 16	[No]: Auto-tuning not performed [Yes]: Auto-tuning performed as soon as possible [Done]: Use of the values given the last time auto-tuning was performed [Drv running]: Auto-tuning performed every time a run command is sent [Power on]: Auto-tuning performed on every power-up [L1] to [L16]: Auto-tuning performed on the transition from 0 → 1 of a logic input assigned to this function	n o	
t u S	43 103	[Auto tuning state]	-	t R b P E n d P r o g F A i L d o n e S t e r d C u S	[Not done]: Default stator resistance value used to control the motor [Pending]: Auto-tuning requested but not yet performed [In progress]: Auto-tuning in progress [Failed]: Auto-tuning failed [Done]: Stator resistance measured by the auto-tuning function used to control the motor [Entered R1]: Cold state stator resistance used to control the motor The value of [Cold stator resist.] (rSC) is set manually	t R b	
u d P	103	[Drv.Soft.Ver]	-	-	-	-	
u F r	33	[IR compensation]	%	0 to 100	-	20	
u F r 2	39 88	[IR compensation 2]	%	0 to 100	-	20	
u F t	44	[U/F mot 1 selected]	-	L P n n L d	[Cst. torque]: Constant torque [Var. torque]: Variable torque [SVC]: Flux vector control [Energy sav.]: Energy saving	n	
u F t 2	88	[U/F mot.2 selected]	-	L P n n L d	[Cst. torque]: Constant torque [Var. torque]: Variable torque [SVC]: Flux vector control [Energy sav.]: Energy saving	n	
u L n	101	[Mains voltage]	V	-	-	-	
u n S	41	[Rated motor volt.]	V	-	-	In accordance with the drive rating	
u n S 2	87	[Nom. mot. 2 volt.]	V	-	-	In accordance with the drive rating	



Main

Range of product	Modicon M221
Product or component type	Logic controller
[Us] rated supply voltage	100...240 V AC
Discrete input number	9 discrete input conforming to IEC 61131-2 Type 1
Analogue input number	2 at input range: 0...10 V
Discrete output type	Relay normally open
Discrete output number	7 relay
Discrete output voltage	5...125 V DC 5...250 V AC
Discrete output current	2 A

Complementary

Discrete I/O number	16
Number of I/O expansion module	<= 4 for transistor output <= 4 for relay output
Supply voltage limits	85...264 V
Network frequency	50/60 Hz
Inrush current	<= 40 A
Power consumption in VA	<= 46 VA at 100...240 V with max number of I/O expansion module <= 31 VA at 100...240 V without I/O expansion module
Power supply output current	0.325 A at 5 V for expansion bus 0.12 A at 24 V for expansion bus
Discrete input logic	Sink or source (positive/negative)
Discrete input voltage	24 V
Discrete input voltage type	DC
Analogue input resolution	10 bits
LSB value	10 mV
Conversion time	1 ms per channel + 1 controller cycle time for analog input
Permitted overload on inputs	+/- 30 V DC for analog input with 5 min maximum +/- 13 V DC for analog input permanent

Voltage state1 guaranteed	>= 15 V for input
Voltage state 0 guaranteed	<= 5 V for input
Discrete input current	7 mA for discrete input 5 mA for fast input
Input impedance	4.9 kOhm for fast input 3.4 kOhm for discrete input 100 kOhm for analog input
Response time	10 ms turn-on operation for output 35 µs turn-off operation for input; I2...I5 terminal 10 ms turn-off operation for output 5 µs turn-on operation for fast input; I0, I1, I6, I7 terminal 35 µs turn-on operation for input; other terminals terminal 5 µs turn-off operation for fast input; I0, I1, I6, I7 terminal 100 µs turn-off operation for input; other terminals terminal
Configurable filtering time	0 ms for input 12 ms for input 3 ms for input
Output voltage limits	125 V DC 277 V AC
Current per output common	6 A at COM 1 terminal 7 A at COM 0 terminal
Absolute accuracy error	+/- 1 % of full scale for analog input
Electrical durability	Inductive AC-15, (cos phi = 0.35) 240 V / 120 VA : 100000 cycles Resistive DC-12, 24 V / 48 W : 100000 cycles Resistive AC-12, 120 V / 240 VA : 100000 cycles Inductive AC-15, (cos phi = 0.35) 240 V / 36 VA : 300000 cycles Resistive AC-12, 120 V / 80 VA : 300000 cycles Inductive (L/R = 7 ms) DC-13, 24 V / 24 W : 100000 cycles Resistive DC-12, 24 V / 16 W : 300000 cycles Inductive (L/R = 7 ms) DC-13, 24 V / 7.2 W : 300000 cycles Inductive AC-14, (cos phi = 0.7) 240 V / 240 VA : 100000 cycles Inductive AC-15, (cos phi = 0.35) 120 V / 60 VA : 100000 cycles Inductive AC-14, (cos phi = 0.7) 240 V / 72 VA : 300000 cycles Inductive AC-15, (cos phi = 0.35) 120 V / 18 VA : 300000 cycles Resistive AC-12, 240 V / 480 VA : 100000 cycles Inductive AC-14, (cos phi = 0.7) 120 V / 120 VA : 100000 cycles Resistive AC-12, 240 V / 160 VA : 300000 cycles Inductive AC-14, (cos phi = 0.7) 120 V / 36 VA : 300000 cycles
Switching frequency	20 switching operations/minute with maximum load
Mechanical durability	>= 20000000 cycles for relay output
Minimum load	1 mA at 5 V DC for relay output
Protection type	Without protection at 5 A
Reset time	1 s
Memory capacity	256 kB for user application and data RAM with 10000 instructions 256 kB for internal variables RAM
Data backed up	256 kB built-in flash memory for backup of application and data
Data storage equipment	2 GB SD card optional
Battery type	BR2032 lithium non-rechargeable, battery life: 4 yr
Backup time	1 year at 25 °C by interruption of power supply
Execution time for 1 KInstruction	0.3 ms for event and periodic task
Execution time per instruction	0.2 µs Boolean
Exct time for event task	60 µs response time
Maximum size of object areas	8000 %MW memory words 512 %KW constant words 255 %TM timers 512 %M memory bits 255 %C counters
Realtime clock	With
Clock drift	<= 30 s/month at 25 °C
Regulation loop	Adjustable PID regulator up to 14 simultaneous loops
Counting input number	4 fast input (HSC mode) (counting frequency: 100 kHz), counting capacity: 32 bits
Control signal type	Dual phase (quadrature) Frequency meter




	Single phase Dual phase (pulse/direction)
Integrated connection type	USB port with connector mini B USB 2.0 Non isolated serial link "serial 1" with connector RJ45 and interface RS485 Non isolated serial link "serial 2" with connector RJ45 and interface RS232/RS485
Supply	Serial serial link supply at 5 V 200 mA
Transmission rate	1.2...115.2 kbit/s (115.2 kbit/s by default) for bus length of 15 m - communication protocol: RS485 1.2...115.2 kbit/s (115.2 kbit/s by default) for bus length of 3 m - communication protocol: RS232 480 Mbit/s - communication protocol: USB
Communication port protocol	USB port : USB protocol - SoMachine-Network Non isolated serial link : Modbus protocol master/slave - RTU/ASCII or SoMachine-Network
Local signalling	1 LED green for SD card access (SD) 1 LED red for BAT 1 LED green for SL1 1 LED green for SL2 1 LED per channel green for I/O state 1 LED red for module error (ERR) 1 LED green for PWR 1 LED green for RUN
Electrical connection	Mini B USB 2.0 connector for a programming terminal Terminal block, 3 terminal(s) for connecting the 24 V DC power supply Connector, 4 terminal(s) for analogue inputs Removable screw terminal block for inputs Removable screw terminal block for outputs
Cable length	<= 10 m shielded cable for fast input <= 30 m unshielded cable for output <= 30 m unshielded cable for digital input <= 1 m unshielded cable for analog input
Insulation	2300 V AC between output and internal logic Non-insulated between analogue inputs 500 V AC between input and internal logic Non-insulated between analogue input and internal logic 1500 V AC between supply and ground 500 V AC between sensor power supply and ground 500 V AC between input and ground 1500 V AC between output and ground 2300 V AC between supply and internal logic 500 V AC between sensor power supply and internal logic 500 V AC between Ethernet terminal and internal logic 2300 V AC between supply and sensor power supply
Marking	CE
Sensor power supply	24 V DC at 250 mA supplied by the controller
Mounting support	Top hat type TH35-15 rail conforming to IEC 60715 Top hat type TH35-7.5 rail conforming to IEC 60715 Plate or panel with fixing kit
Height	90 mm
Depth	70 mm
Width	95 mm
Product weight	0.346 kg

Environment

Standards	EN/IEC 61010-2-201 EN/IEC 60664-1 EN/IEC 61131-2
Product certifications	DNV-GL EAC ABS IACS E10 CSA LR cULus RCM
Environmental characteristic	Ordinary and hazardous location
Resistance to electrostatic discharge	4 kV on contact conforming to EN/IEC 61000-4-2 8 kV in air conforming to EN/IEC 61000-4-2
Resistance to electromagnetic fields	10 V/m (80 MHz...1 GHz) conforming to EN/IEC 61000-4-3


	3 V/m (1.4 GHz...2 GHz) conforming to EN/IEC 61000-4-3 1 V/m (2...2.7 GHz) conforming to EN/IEC 61000-4-3
Resistance to magnetic fields	30 A/m at 50...60 Hz conforming to EN/IEC 61000-4-8
Resistance to fast transients	2 kV for power lines conforming to EN/IEC 61000-4-4 2 kV for relay output conforming to EN/IEC 61000-4-4 1 kV for Ethernet line conforming to EN/IEC 61000-4-4 1 kV for serial link conforming to EN/IEC 61000-4-4 1 kV for I/O conforming to EN/IEC 61000-4-4
Surge withstand	2 kV for power lines (AC) in common mode conforming to EN/IEC 61000-4-5 2 kV for relay output in common mode conforming to EN/IEC 61000-4-5 1 kV for I/O in common mode conforming to EN/IEC 61000-4-5 1 kV for shielded cable in common mode conforming to EN/IEC 61000-4-5 0.5 kV for power lines (DC) in differential mode conforming to EN/IEC 61000-4-5 1 kV for power lines (AC) in differential mode conforming to EN/IEC 61000-4-5 1 kV for relay output in differential mode conforming to EN/IEC 61000-4-5 0.5 kV for power lines (DC) in common mode conforming to EN/IEC 61000-4-5
Resistance to conducted disturbances, induced by radio frequency fields	10 Vrms (0.15...80 MHz) conforming to EN/IEC 61000-4-6 3 Vrms (0.1...80 MHz) conforming to Marine specification (LR, ABS, DNV, GL) 10 Vrms (spot frequency (2, 3, 4, 6.2, 8.2, 12.6, 16.5, 18.8, 22, 25 MHz)) conforming to Marine specification (LR, ABS, DNV, GL)
Electromagnetic emission	Conducted emissions conforming to EN/IEC 55011 power lines (AC), 0.15...0.5 MHz : 79 dBµV/m QP/66 dBµV/m AV Conducted emissions conforming to EN/IEC 55011 power lines (AC), 0.5...300 MHz : 73 dBµV/m QP/60 dBµV/m AV Conducted emissions conforming to EN/IEC 55011 power lines, 10...150 kHz : 120...69 dBµV/m QP Conducted emissions conforming to EN/IEC 55011 power lines, 150 kHz...1.5 MHz : 79...63 dBµV/m QP Conducted emissions conforming to EN/IEC 55011 power lines, 1.5...30 MHz : 63 dBµV/m QP Radiated emissions conforming to EN/IEC 55011 class A 10 m, 30...230 MHz : 40 dBµV/m QP Radiated emissions conforming to EN/IEC 55011 class A 10 m, 200 MHz...1 GHz : 47 dBµV/m QP
Immunity to microbreaks	10 ms
Ambient air temperature for operation	-10...55 °C for horizontal installation -10...35 °C for vertical installation
Ambient air temperature for storage	-25...70 °C
Relative humidity	10...95 % without condensation in operation 10...95 % without condensation in storage
IP degree of protection	IP20 with protective cover in place
Pollution degree	<= 2
Operating altitude	0...2000 m
Storage altitude	0...3000 m
Vibration resistance	3.5 mm (vibration frequency: 5...8.4 Hz) on symmetrical rail 1 gn (vibration frequency: 8.4...150 Hz) on symmetrical rail 3.5 mm (vibration frequency: 5...8.4 Hz) on panel mounting 1 gn (vibration frequency: 8.4...150 Hz) on panel mounting
Shock resistance	98 m/s ² (test wave duration:11 ms)

Offer Sustainability


Sustainable offer status	Green Premium product
RoHS (date code: YYWW)	Compliant - since 1415 - Schneider Electric declaration of conformity  Schneider Electric declaration of conformity
REACH	Reference not containing SVHC above the threshold Reference not containing SVHC above the threshold
Product environmental profile	Available  Product environmental
Product end of life instructions	Available  End of life manual

Dimensions

Mounting on a Rail




Direct Mounting on a Panel Surface



(1) Install a mounting strip


Mounting Hole Layout




Mounting

Correct Mounting Position

Acceptable Mounting Position




Incorrect Mounting Position



Clearance


Digital Inputs

Wiring Diagram (Positive Logic)



(*) Type T fuse

Wiring Diagram (Negative Logic)




(*) Type T fuse

Connection of the Fast Inputs

I0, I1, I6, I7

Relay Outputs

Negative Logic (Sink)



(*) Type T fuse

(1) The COM1 and COM2 terminals are not connected internally.

(2) To improve the life time of the contacts, and to protect from potential inductive load damage, you must connect a free wheeling diode in parallel to each i

B Sink wiring (negative logic)

Positive Logic (Source)


(*) Type T fuse

(1) The COM1 and COM2 terminals are not connected internally.

(2) To improve the life time of the contacts, and to protect from potential inductive load damage, you must connect a free wheeling diode in parallel to each i

A Source wiring (positive logic)


Analog Inputs



The (-) poles are connected internally.

Pin	Wire Color
0 V	Black
AN1	Red
0 V	Black
AN0	Red

USB Mini-B Connection




SL1 Connection

SL1

N °	RS 232	RS 485
1	RxD	N.C.
2	TxD	N.C.
3	RTS	N.C.
4	N.C.	D1
5	N.C.	D0
6	CTS	N.C.
7	N.C.*	5 Vdc
8	Common	Common

N.C.: not connected

* : 5 Vdc delivered by the controller. Do not connect.



SL2 Connection

N °	RS 485
1	N.C.
2	N.C.
3	N.C.
4	D1
5	D0
6	N.C.
7	N.C.
8	Common


N.C.: not connected

Derating Curves

Embedded Digital Inputs (No Cartridge)

X : Ambient temperature
Y : Input simultaneous ON ratio

Embedded Digital Inputs (with Cartridge)



X : Ambient temperature
Y : Input simultaneous ON ratio



Price* : 179.00 USD



Main

Range of product	Modicon TM3
Product or component type	Analog input module
Range compatibility	Modicon M251 Modicon M221 Modicon M241
Analogue input number	2
Analogue input type	Current, analogue input range: 4...20 mA Current, analogue input range: 0...20 mA Voltage, analogue input range: 0...10 V Voltage, analogue input range: - 10...10 V

Complementary

Analogue input resolution	15 bits + sign 16 bits
Permissible continuous overload	13 V voltage 40 mA current
Input impedance	<= 50 Ohm current >= 1 MOhm voltage
LSB value	2.44 mV, analogue input: 0...10 V voltage 4.88 mV, analogue input: - 10...10 V voltage 4.88 µA, analogue input: 0...20 mA current 3.91 µA, analogue input: 4...20 mA current
Conversion time	1 ms + 1 ms per channel + 1 controller cycle time
Sampling duration	<= 1 ms
Absolute accuracy error	+/- 0.1 % of full scale at 77 °F (25 °C) +/- 1 % of full scale
Temperature drift	+/- 0.006 %FS/°C
Repeat accuracy	+/-0.5 %FS
Non-linearity	+/- 0.01 %FS
Cross talk	<= 1 LSB
[Us] rated supply voltage	24 V DC

Supply voltage limits	20.4...28.8 V
Type of cable	<= 98.43 ft (30 m) twisted shielded pairs cable for input circuit
Current consumption	30 mA at 5 V DC (no load) via bus connector 40 mA at 5 V DC (full load) via bus connector 25 mA at 24 V DC via external supply
Local signalling	1 LED green PWR
Electrical connection	11 x 2.5 mm ² removable screw terminal block with pitch 5.08 mm adjustment for inputs and supply
Insulation	500 V AC between input and internal logic 1500 V AC between input and supply
Marking	CE
Surge withstand	1 kV for power supply with common mode protection conforming to EN/IEC 61000-4-5 0.5 kV for power supply with differential mode protection conforming to EN/IEC 61000-4-5 1 kV for input with common mode protection conforming to EN/IEC 61000-4-5
Mounting support	Top hat type TH35-15 rail conforming to IEC 60715 Top hat type TH35-7.5 rail conforming to IEC 60715 Plate or panel with fixing kit
Height	3.54 in (90 mm)
Depth	2.76 in (70 mm)
Width	0.93 in (23.6 mm)
Product weight	0.25 lb(US) (0.115 kg)

Environment

Standards	EN/IEC 61010-2-201 EN/IEC 61131-2
Resistance to electrostatic discharge	4 kV on contact conforming to EN/IEC 61000-4-2 8 kV in air conforming to EN/IEC 61000-4-2
Resistance to electromagnetic fields	9.14 V/yd (10 V/m) at 80 MHz...1 GHz conforming to EN/IEC 61000-4-3 2.74 V/yd (3 V/m) at 1.4 GHz...2 GHz conforming to EN/IEC 61000-4-3 0.91 V/yd (1 V/m) at 2 GHz...3 GHz conforming to EN/IEC 61000-4-3
Resistance to magnetic fields	9.14 A/ft (30 A/m) at 50...60 Hz conforming to EN/IEC 61000-4-8
Resistance to fast transients	1 kV I/O conforming to EN/IEC 61000-4-4
Resistance to conducted disturbances, induced by radio frequency fields	10 V at 0.15...80 MHz conforming to EN/IEC 61000-4-6 3 V at spot frequency (2, 3, 4, 6.2, 8.2, 12.6, 16.5, 18.8, 22, 25 MHz) conforming to Marine specification (LR, ABS, DNV, GL)
Electromagnetic emission	Radiated emissions, test level: 40 dBμV/m QP class A (10 m at 30...230 MHz) conforming to EN/IEC 55011 Radiated emissions, test level: 47 dBμV/m QP class A (10 m at 230 MHz...1 GHz) conforming to EN/IEC 55011
Immunity to microbreaks	10 ms
Ambient air temperature for operation	14...131 °F (-10...55 °C) (horizontal installation) -10...35 °C (vertical installation)
Ambient air temperature for storage	-13...158 °F (-25...70 °C)
Relative humidity	10...95 % without condensation in operation 10...95 % without condensation in storage
IP degree of protection	IP20
Pollution degree	2
Operating altitude	0...6561.68 ft (0...2000 m)
Storage altitude	0...9842.52 ft (0...3000 m)
Vibration resistance	3.5 mm at 5...8.4 Hz with DIN rail mounting support 3 gn at 8.4...150 Hz with DIN rail mounting support
Shock resistance	15 gn during 11 ms

Ordering and shipping details

Category	22533 - M2XX PLC & ACCESSORIES
Discount Schedule	MSX
GTIN	00785901278511
Nbr. of units in pkg.	1
Package weight(Lbs)	0.47999999999999998

Returnability	Y
Country of origin	JP

Offer Sustainability

Sustainable offer status	Green Premium product
RoHS (date code: YYWW)	Compliant - since 1415 - Schneider Electric declaration of conformity Schneider Electric declaration of conformity
REACH	Reference not containing SVHC above the threshold Reference not containing SVHC above the threshold
Product environmental profile	Available
Product end of life instructions	Available



Technical Characteristics

Marketing Trade Name	Magelis
For Use With	Twido, Modicon TSX Micro, Modicon Premium, Modicon 340
Depth	37mm
Width	132mm
Height	74mm
Application	Ideal for performing diagnostics, adding control and adjusting system settings on simple or compact applications
Display	Matrix Screen - Back-lit LCD
Display Size/Resolution	2 Lines - 20 Characters (Green)
Data Entry	Keypad - 8 keys (4 customizable)
Representation	Alphanumeric
Alarm Log	No
Serial Link Communication	1 RJ45 (RS 232 - RS 485)
Software Type	Vijeo Designer Lite
Download Protocols	Uni-TE, Modbus Master
Supply Voltage	5VDC (or PLC power supply)
Type	XBTN

Shipping and Ordering

Category	22570 - Message Displays and Operator Terminals
Discount Schedule	MC2
Article Number	785901485049
Package Quantity	1
Weight	0.83 lbs.
Availability Code	Non-Stock Item: This item is not normally stocked in our distribution facility.
Returnability	Y

As standards, specifications, and designs change from time to time, please ask for confirmation of the information given in this document.



► Models LP3P, LP3S, LP3T

StreamLine® Low Profile Strobe Light

Model LP3 is offered in three mounting configurations. LP3P features an integrated 1/2-inch NPT pipe mount. LP3S features a three-hole surface mount — ideal for control panels and other flat or flush surfaces. The “T-mount” LP3T has a popular 2-hole design for wall or flush mounting.

Both the LP3S and LP3T include a surface gasket to complete the Type 4X installation. An optional dome guard is available for use with the LP3S and LP3T. All LP3 units feature a threaded screw-on lens that allows tool-free wiring and strobe tube replacement.

StreamLine® strobes feature high-quality, long-life strobe lamps which are designed to reduce tungsten build-up for longer lamp maintenance cycles. Careful consideration is given to the relationship between lamp shape and lens design for maximum light output. StreamLine products make use of surface mount technology, which provides a more powerful light in a much smaller package. The dry-electrolyte capacitor used in StreamLine products runs cooler than those used in many competitive strobes, resulting in a more reliable product that won't fail due to overheating.

FEATURES

- Available in 12-48VDC, 120VAC and 240VAC
- Surface mount, T-mount, or integrated 1/2-inch NPT pipe mount
- Five dome colors: Amber, Blue, Clear, Green and Red
- Screw-on lens
- Type 4X, IP66 enclosure
- PLC and triac compatible
- Optional dome guard for LP3S and LP3T
- UL and cUL Listed, and CSA Certified

MODEL	VOLTAGE	OPERATING CURRENT	FLASH RATE/ MINUTE	CANDELA	
				PEAK ¹	ECP ²
LP3 * -012-048 **	12-48VDC	0.44-0.10 amps	65-95	175,000	51.5
LP3 * -120 **	120VAC	0.10 amps	65-95	175,000	51.5
LP3 * -240 **	240VAC	0.07 amps	65-95	175,000	51.5


*Indicates Mounting Style: (S) Surface Mount, (P) Pipe Mount, (T) T-Mount

** Indicates color: (A) Amber, (B) Blue, (C) Clear, (G) Green or (R) Red

¹ Peak candela is the maximum light intensity generated by a flashing light during its light pulse

² ECP (Effective Candela) is the intensity that would appear to an observer if the light were burning steadily

StreamLine® Low Profile Strobe Light (LP3S/LP3P/LP3T)



SPECIFICATIONS

Lamp Life:	4,000 Hours
Light Source:	Strobe tube
Operating Temperature:	-31°F to 151°F -35°C to 66°C
Net Weight:	0.23 lbs 0.1 kg
Shipping Weight:	0.6 lbs 0.27 kg
Height:	2.61" 66.3 mm
Width:	2.33" 59.2 mm
Length:	5.05" 128.3 mm

REPLACEMENT PARTS

Description	Part Number
Dome, Amber	K8589063A
Dome, Blue	K8589063A-01
Dome, Clear	K8589063A-02
Dome, Green	K8589063A-03
Dome, Red	K8589063A-04
Strobe Tube	K149130A
Gasket Kit ¹	K858900353A

¹ Includes gasket for LP3S and LP3T

HOW TO ORDER

LP3	S	- 120	A
TYPE LP3	MOUNT S Surface P Pipe T T-Mount	VOLTAGE 012-048 (12-48VDC) 120 (120VAC) 240 (240VAC)	COLOR A Amber B Blue C Clear G Green R Red

OPTIONAL ACCESSORIES

Description	Part Number
Wire/Dome Guard for LP3S and LP3T	LP3G





HIGH ACCURACY SUBMERSIBLE LEVEL TRANSMITTER

ACCULEVEL

THERMALLY-COMPENSATED, CUSTOM RANGES, DUAL OUTPUT SUBMERSIBLE

The Acculevel by Keller America provides standard features that far exceed those of comparably priced transmitters, including standard $\pm 0.25\%$ FS or optional $\pm 0.1\%$ Total Error Band (TEB)₃ accuracy.

The ability of the Acculevel to provide this level of sustained performance over a wide range of operating conditions makes it ideally suited to environmental monitoring applications such as surface water, streams, and reservoirs.

Keller America's guaranteed lightning protection makes this transmitter ideal for installation in areas prone to chronic damage due to transients caused by lightning.

For more information on the Acculevel, or any other Keller product, please contact Keller America, or view the entire Keller catalog at <http://www.kelleramerica.com/datasheets.html>.

FEATURES

4...20mA models include guaranteed lightning protection at no additional cost.

16-bit internal digital error correction for cost-effective low Total Error Band (TEB)₃

316L stainless construction standard - Optional Titanium for severe applications.

2-year warranty covers defects in materials and workmanship.


User-rangeable analog output ensures compatibility as requirements change.

RS485 modified-MODBUS compatible interface allows up to 128 transmitters on a single bus.

Standard dual (analog & RS485) outputs simplify interface to controls, data collection, and telemetry systems.

Built in the U.S.A. ARRA Section 1605 Compliant.

Standard 3-day lead time



Output	White	Black	Red	Blue	Yellow
2-wire (mA)	OUT / GND	+Vcc	N/A	RS485A	RS485B
3-wire (VDC)	GND	+VCC	+OUT	RS485A	RS485B

Braided shield wire connected to transmitter housing



Pressure Ranges_{1,2}

Relative	Infinite between 0...3 thru 0...900 ft W.C.
Absolute	Infinite between 0...2 thru 0...11 bar

1. The Acculevel can be provided with custom calibration at no extra cost. For fluids other than water, the specific gravity must be given at the time the order is placed.

2. Intermediate ranges are realized by deranging the analog output from the next highest basic range: 1, 3, 10, and 30 bar (relative) 2, 4, and 11 bar (absolute). Level range may be specified in units of lb/in²(psi), inches WC or feet WC. Keller America uses the International Standard conversion of 2.3067 feet WC/psi.

Accuracy₃

Static	Standard ±0.1% FS, Optional ±0.05% FS
Total Error Band	Standard ±0.25% BR, Optional ±0.1% BR

3. Static accuracy includes the combined effects of non-linearity, hysteresis, and non-repeatability at room temperature (25°C). Total Error Band (TEB) includes the combined effects of non-linearity, hysteresis, and non-repeatability as well as thermal dependencies, over the compensated temperature range, expressed as a percentage of the basic range (BR).

The calculation for maximum TEB on intermediate ranges (IR) is: $TEB_{IR} = (BR/IR) \times TEB_{BR}$

Output

Current	4...20mA + RS485
Voltage ₄	0...5, 0-10VDC + RS485
Resolution ₅	0.002%

4. Other voltage output options available on request.

5. Resolution applies to digital output only. Analog resolution is continuous and limited by the process meter and not the instrument.

Certifications

CE	EN50081-1, EN50082-2
----	----------------------

Electrical₆

Supply (4-20mA)	11-28 VDC
Supply (0-5VDC)	8...28 VDC
Supply (0-10VDC)	13...28 VDC
Load Resistance (mA)	<(Supply-11V)/0.022A
Load Resistance (VDC)	>4k ohm

6. Nominal values may be higher depending upon cable length. Internal lightning protection increases the minimum-required supply voltage from 8VDC to 11VDC, due to internal resistance of the surge protectors. In addition, cable resistance (~70Ω / 1000ft) adds to the supply requirement. In order to insure proper system operation, calculate the minimum required supply voltage (at the source) as follows:

For two-part (internal+external) system (recommended):
MINIMUM SUPPLY VOLTAGE = 11.6 + 0.022 (CABLE LENGTH x 0.07) VDC

For internal only protector (standard with 4-20mA output):
MINIMUM SUPPLY VOLTAGE = 11 + 0.022 (CABLE LENGTH x 0.07) VDC

Environmental

Protection Rating	IP68
Operating Temp.	-10...60° C
Compensated Temp.	-10...80° C
Wetted Materials	316 L Stainless Steel Titanium Optional Polyamide Fluorocarbon
Cable Options	Polyethylene for general purpose Hytril for hydrocarbon Tefzel for chemical interaction

Optional Accessories



1/2" NPT Conduit Fitting



Drying Tube Assembly



Bellows Assembly



Cable Hanger



Termination Enclosure



Pressure Test Adapter



Stabilizing Weight



Interface Converter



Process Meter



Open-faced Nose Cap




Signal Line Surge Protector

(908 190)


- Prewired complete unit without the need for additional overcurrent protection devices
- High discharge capacity due to heavy-duty zinc oxide varistors (I_{max} 50 kA 8x20µs)
- Short circuit current rating (SCCR) 200 kA
- ANSI/UL 1449 – 4th Ed. Open-Type 1 SPD



Figure without obligation



Basic circuit diagram DG MU SP 240 3W+G



Dimension drawing DG MU SP 240 3W+G

DIN rail mount, pluggable surge arrester consisting of a base part and plug-in protection modules for application in Split Phase systems

Type	908 190
Part No.	
SPD classification acc. to ANSI/UL 1449 4 th Ed.	Open-Type 1 SPD
SPD classification acc. to CSA - C22.2 No. 269.1-14	Type 4-1 Component Assembly
Nominal System Voltage [L-G] / [L-L] (U_N)	127 V a.c. / 254 V a.c.
Nominal Power System Frequency	50 / 60 Hz
Max. Continuous Operating Voltage [L-G] / [L-L] (MCOV)	230 V a.c. / 460 V a.c.
Nominal discharge current (8x20µs) (I_n)	20 kA
Maximal discharge current (8x20µs) (I_{max})	50 kA
Voltage Protection Rating [L-G] / [L-L] (VPR)	700 V _{pk} / 1500 V _{pk}
Additional Overcurrent Protection	Not needed
Short Circuit Current Rating (SCCR)	200 kA
System Type	Split Phase
Operating Temperature Range (T_U)	-35°C...+85°C
Visual Arrester Status (non power consuming design)	Green = Good ; Red = Replace Module
Minimum Wire Size	14 AWG / 2.5 mm ²
Maximum Wire Size	4 AWG / 25 mm ²
Terminal Torque Ratings	35-45 Lbs-in
Mounting	35 mm DIN rails acc. to EN 60715
Enclosure material	thermoplastic, red, UL 94 V-0
Degree of protection	IP 20
Capacity	2 module(s), DIN 43880
Approvals	UL, CSA
Weight	NaN
PU	

We reserve the right to introduce changes in performance, configuration and technology, dimensions, weights and materials in the course of technical progress. The figures are shown without obligation.


BLITZDUCTOR® XTU – Protection Modules with LifeCheck®
Accessories

BXT BAS



Base part as a very space-saving and universal four-pole feed-through terminal for the insertion of a protection module without signal disconnection if the protection module is removed.

Type	BXT BAS
Part No.	920 300
Colour	yellow
Weight	34 g
Customs tariff number	85369010
GTIN	4013364109179
PU	1 pc(s)




BSP M2 BD 24 (926 244)


- High degree of protection for one pair
- For installation in conformity with the lightning protection zone concept at the boundaries from $0_B - 2$ and higher



Figure without obligation



Basic circuit diagram BSP M2 BD 24



Dimension drawing BSP M2 BD 24

Space-saving surge arrester module for protecting one pair of balanced interfaces with galvanic isolation.

Type	BSP M2 BD 24
Part No.	926 244
SPD class	TYPE 2 PD
Nominal voltage (U_N)	24 V
Max. continuous operating voltage (d.c.) (U_C)	33 V
Max. continuous operating voltage (a.c.) (U_C)	23.3 V
Nominal current at 45 °C (I_L)	1.0 A
D1 Lightning impulse current (10/350 μ s) per line (I_{imp})	1 kA
C2 Total nominal discharge current (8/20 μ s) (I_n)	20 kA
C2 Nominal discharge current (8/20 μ s) per line (I_n)	10 kA
Voltage protection level line-line for I_n C2 (U_p)	≤ 55 V
Voltage protection level line-PG for I_n C2 (U_p)	≤ 600 V
Voltage protection level line-line at 1 kV/ μ s C3 (U_p)	≤ 45 V
Voltage protection level line-PG at 1 kV/ μ s C3 (U_p)	≤ 550 V
Series impedance per line	1.0 ohm(s)
Cut-off frequency line-line (f_c)	7.8 MHz
Capacitance line-line (C)	≤ 1.0 nF
Capacitance line-PG (C)	≤ 16 pF
Operating temperature range (T_U)	-40 °C ... +80 °C
Degree of protection (with plugged-in protection module)	IP 20
Pluggable into	BXT BAS / BSP BAS 4 base part
Earthing via	BXT BAS / BSP BAS 4 base part
Enclosure material	polyamide PA 6.6
Colour	yellow
Test standards	IEC 61643-21, UL 497B
Approvals	UL, CSA, SIL, EAC
SIL classification	up to SIL3 ^{*)}
Weight	21 g
Customs tariff number	85363010
GTIN	4013364127098
PU	1 pc(s)

^{*)} For more detailed information, please visit www.dehn-international.com.

We reserve the right to introduce changes in performance, configuration and technology, dimensions, weights and materials in the course of technical progress. The figures are shown without obligation.

MODEL 112 Control Panel

Single phase, simplex motor contactor control.

The Model 112 control panel provides a reliable means of controlling one 120, 208, or 240 VAC single phase pump in pump chambers, sump pump basins, irrigation systems and lift stations. Two control switches activate a magnetic motor contactor to turn the pump on and off. If an alarm condition occurs, an additional alarm switch activates the audio/visual alarm system.


PANEL COMPONENTS

1. Enclosure measures 8 x 8 x 4 inches (20.32 X 20.32 X 10.16 cm). Choice of NEMA 1 (steel for indoor use), or NEMA 4X (ultraviolet stabilized thermoplastic with removable flanges for outdoor or indoor use).
* Options selected may increase enclosure size and change component layout.
2. Magnetic Motor Contactor controls pump by switching electrical lines.
3. HOA Switch for manual pump control (mounted on circuit board).
4. Green Pump Run Indicator Light (mounted on circuit board).
5. Float Switch Terminal Block (mounted on circuit board).
6. Alarm and Control Fuses (mounted on circuit board).
7. Alarm and Control Power Indicators (mounted on circuit board).
8. Pump Input Power and Pump Connection Terminal Block
9. Ground Lug
10. Terminal Block Installation Label
11. Circuit Breaker (optional) provides pump disconnect and branch circuit protection.

STANDARD ALARM PACKAGE

12. Red Alarm Beacon provides 360° visual check of alarm condition.
Note: NEMA 1 style utilizes a door mounted indicator in lieu of a beacon.
13. Alarm Horn provides audio warning of alarm condition (83 to 85 decibel rating).
Note: NEMA 1 style utilizes an internally mounted buzzer in lieu of horn.
14. Exterior Alarm Test/Normal/Silence Switch allows horn and light to be tested and horn to be silenced in an alarm condition. Alarm automatically resets once alarm condition has been cleared.
15. Horn Silence Relay (mounted on circuit board).

NOTE: other options available.



Model Shown 1121W914X

FEATURES

-  Entire control system (panel and switches) is UL Listed to meet and/or exceed industry safety standards
-  Dual safety certification for the United States and Canada
-  Standard package includes three 20' Sensor Float® control switches
-  Complete with step-by-step installation instructions
-  Three-year limited warranty



SJE
Rhombus
CONTROLS

SAMPLE • Mechanically-activated ▲ Mercury-activated


MODEL 112 1 W 9 1 4 H 3A 8A

Alarm Package — 1
Enclosure Rating — W
Starting Device — 9
Pump Full Load Amps — 1
Pump Disconnect — 4
Float Switch Application — H
Options: Flasher, Elapsed Time Meter — 3A 8A

Single Phase Simplex

SJE-Rhombus® Type 112

Installation Instructions and Operation/Troubleshooting Manual



Warranty void if panel is modified.

Call factory with servicing questions:

1-800-RHOMBUS
(1-800-746-6287)

Manufactured by:

**SJE
Rhombus®**

22650 County Highway 6 ■ P.O. Box 1708
Detroit Lakes, Minnesota 56502 USA
1-888-DIAL-SJE (1-888-342-5753)
Phone: 218-847-1317 ■ Fax: 218-847-4617
E-mail: customer.service@sjerhombus.com
Website: www.sjerhombus.com

©SJE-Rhombus
PN1008704E • Rev 11/14

This control panel must be installed and serviced by a licensed electrician in accordance with the National Electric Code NFPA-70, state and local electrical codes.

All conduit running from the sump or tank to the control panel must be sealed with conduit sealant to prevent moisture or gases from entering the panel. **NEMA 1 enclosures are for indoor use only**, primarily to provide a degree of protection against contact with enclosed equipment. Cable connectors are not required to be liquid-tight in NEMA 1 enclosures. **Do not use NEMA 1 enclosures if subjected to rain, splashing water or hose-directed water.** **NEMA 4X enclosures are for indoor or outdoor use**, primarily to provide a degree of protection against corrosion, windblown dust and rain, splashing water and hose-directed water. **Cable connectors must be liquid-tight in NEMA 4X enclosures.**

Installation

A standard Type 112 panel is designed to operate with three floats. These floats operate pump stop, pump start, and high level alarm functions.

NOTE: Options ordered may affect the number of floats and their functions. Please reference the schematic provided with the control panel for proper installation.

Installation of Floats

CAUTION: If control switch cables are not wired and mounted in the correct order, the pump system will not function properly.

WARNING: Turn off all power before installing floats in pump chamber. Failure to do so could result in serious or fatal electrical shock.

1. Use float label kit to label floats for specific operation (stop, start, alarm, etc.). See schematic for float options.
2. Determine your normal operating level, as illustrated in **Figure 1**.
3. Mount float switches at appropriate levels as illustrated in **Figures 2-4**. Be sure that floats have free range of motion without touching each other or other equipment in the basin.

If using the mounting clamp; follow steps 4-6.

4. Place the cord into the clamp as shown in **Figure 2**.
5. Locate the clamp at the desired activation level and secure the clamp to the discharge pipe as shown in **Figure 2**.

NOTE: Do not install cord under hose clamp.

6. Tighten the hose clamp using a screwdriver. Over tightening may result in damage to the plastic clamp. Make sure the float cable is not allowed to touch the excess hose clamp band during operation.

NOTE: All hose clamp components are made of 18-8 stainless steel material. See your SJE-Rhombus® supplier for replacements.

Installation Instructions

Mounting the Control Panel

1. Determine mounting location for panel. If distance exceeds the length of either the float switch cables or the pump power cables, splicing will be required. For outdoor or wet installation, we recommend the use of an SJE-Rhombus® liquid-tight junction box with liquid-tight connectors to make required connections. **You must use conduit sealant to prevent moisture or gases from entering the panel.**
2. Mount control panel (mounting flanges are furnished with control panel).
3. Determine conduit entrance locations on control panel. Check local codes and schematic for the number of power circuits required.

NOTE: Be sure the proper power supply voltage, and phase are the same as the pump motor being installed. If in doubt, see the pump identification plate for electrical requirements.

4. Drill proper size holes for type of connectors being used.

NOTE: If using conduit, be sure that it is of adequate size to pull the pump and switch cables through. **You must use conduit sealant to prevent moisture or gases from entering the panel.**

5. Attach cable connectors and/or conduit connectors to control panel.


**FOR INSTALLATION WITHOUT A SPLICE,
GO TO STEP 11;
FOR INSTALLATION REQUIRING
A SPLICE, FOLLOW STEPS 6-10.**

6. Determine location for mounting junction box according to local code requirements. **Do not** mount the junction box inside the sump or basin.
7. Mount junction box to proper support.
8. Run conduit to junction box. Drill proper size holes for the type of conduit used. Attach liquid-tight connectors to junction box.

9. Identify and label each wire before pulling through conduit into control panel and junction box. Pull pump power cables and control switch cables through connectors into junction box. Make wire splice connections at junction box.
10. Firmly tighten all fittings on junction box. Insure all cable connectors are liquid-tight and sealed.
11. If a junction box is not required, identify and label cables on both float and stripped ends.
12. Connect pump and float wires to proper position on terminals. See schematic inside control panel for terminal layouts.
13. Connect control, alarm and pump power conductors to proper position on terminals. See schematic inside control panel for terminal connections.

NOTE: It is the recommendation of the factory to use separate pump and control/alarm power sources.

**VERIFY CORRECT OPERATION OF CONTROL
PANEL AFTER INSTALLATION IS COMPLETE.**




**FIGURE 1-
Three float simplex - pump down installation**


SINGLE PHASE SIMPLEX - 112

Standard Field Wiring Diagram

Identify panel configuration before wiring. Use wiring diagram in conjunction with schematic for panel installation.

NOTE: It is the recommendation of the factory to use separate pump and alarm power sources.

**WARNING!**

**ELECTRICAL SHOCK HAZARD**
Disconnect all power sources before servicing.
Failure to do so could result in serious injury or death. Must be installed by a licensed electrician and in accordance with the National Electric Code NFPA-70, state and local electrical codes.

1 Wire Floats

- Connect float switches to TB1 (on circuit board) as shown.
(Pump down application is shown)

2 Wire pump power cable

- Connect pump power cable to motor contactor.
- Connect pump ground wire to ground lug.

3 Wire incoming control & alarm power

Control and Alarm on circuit board

- Connect L1 (alarm) to TB1-1.
- Connect L1 (control) to TB1-2.
- Connect Neutral to TB1-3.
- Connect incoming ground line to ground lug.

Figure A

No Breaker - 120/208/240V








Figure B

1 Pole Breaker - 120V







OPTIONAL - WIRE DIFFERENTIAL PUMP SWITCHES OR PRESSURE SWITCHES TO TERMINALS (4, 7), AND (8, 9)



THE USE OF SEPARATE POWER SOURCES FOR PUMP AND ALARM ARE RECOMMENDED



OVERLOAD PROTECTION, MAIN DISCONNECT AND OVERCURRENT PROTECTION OF INCOMING FEEDER CIRCUIT PROVIDED BY OTHERS AND MUST BE SIZED ACCORDING TO PUMP/MOTOR MANUFACTURING SPECIFICATIONS


BRANCH CIRCUIT PROTECTION FOR THE CONTROL AND ALARM CIRCUITS MUST BE PROVIDED BY THE INSTALLER. AN INVERSE TIME CIRCUIT BREAKER NOT TO EXCEED 20 AMPS IS REQUIRED.

TEMPERATURE RATING OF FIELD INSTALLED CONDUCTORS MUST BE AT LEAST 140 DEG. F. (60 DEG. C.). TERMINAL STRIPS AND GROUND LUG USE COPPER CONDUCTORS ONLY.

CONNECT GROUND LUG IN PANEL TO A SECURE EARTH GROUND

DASHED LINES REPRESENT FIELD WIRING

FIELD WIRING SECTION



Project Name:

Project Number: 2721-218-01

Date: 06/23/2017

<u>Supplier</u>	
Company Name:	Advanced Fluid Technologies
Street Address:	7801 Warden Road
City/State/Zip:	Sherwood, AR 72120
Phone:	501-835-3200
Fax:	

Manufacturer

Company Name: Fiberglass Tank Solutions

Street Address: 278 Nomore Lane


City/State/Zip: Montreal, MO 65591

Phone: 573-317-9620


Fax:

Tank Drawings


ITEM	QTY	DESCRIPTION	SERVICE	ELEV.	DEG./RAD
A	1	18" SIDE MANWAY W/ COVER, EPDM GASKET & SS 316 BOLTS	MANWAY	3'-0" CL	270°
B	1	4" FLANGE NOZZLE W/ CONICAL GUSSETS	CONN. TANK 2	1'-8" CL	90°
C	1	4" FLANGE NOZZLE W/ CONICAL GUSSETS	CONN. TANK 3	1'-8" CL	0°
D	1	6" FLANGE NOZZLE	CLEAN OUT	1'-0" CL	135°
E	1	10" FIBERGLASS GOOSENECK VENT W/ BIRD SCREEN	VENT	TOP	CENTER
F	4	STEEL LIFTING LUGS	LIFTING LUG	SEE DWG	SEE DWG
G	6	STEEL HOLD DOWN LUGS	HOLD DOWN	SEE DWG	SEE DWG
H	3	2" FLANGE NOZZLE W/ CONICAL GUSSETS & FRP DOWN PIPES	FILL LINES	TOP	5'-0" RAD
I	6	FIBERGLASS PIPE SUPPORT BRACKETS	PIPE SUPPORT	SEE DWG	180°



ANALYSIS

00	0000000000	TAN	LAN	CLOSURE OF INACTIVE NABORS LANDFILLS MOUNT HOME, AR	MATT	06/21/2017	10:00 AM		
									
278 Norme Lane, Montreal, MO 65591 (573-317-9820)									

ITEM	QTY	DESCRIPTION	SERVICE	ELEV.	DEG./RAD
A	1	18" SIDE MANWAY W/ COVER, EPDM GASKET & SS 316 BOLTS	MANWAY	3'-0" CL	270°
B	1	4" FLANGE NOZZLE W/ CONICAL GUSSETS	CONN. TANK 2	1'-8" CL	90°
C	1	4" FLANGE NOZZLE W/ CONICAL GUSSETS	CONN. TANK 3	1'-8" CL	0°
D	1	6" FLANGE NOZZLE	CLEAN OUT	1'-0" CL	135°
E	1	10" FIBERGLASS GOOSENECK VENT W/ BIRD SCREEN	VENT	TOP	CENTER
F	4	STEEL LIFTING LUGS	LIFTING LUG	SEE DWG	SEE DWG
G	6	STEEL HOLD DOWN LUGS	HOLD DOWN	SEE DWG	SEE DWG
H	3	2" FLANGE NOZZLE W/ CONICAL GUSSETS & FRP DOWN PIPES	FILL LINES	TOP	5'-0" RAD
I	6	FIBERGLASS PIPE SUPPORT BRACKETS	PIPE SUPPORT	SEE DWG	180°



AERO-

CAT-


TAN 1111 AT ON

CLOSURE OF INACTIVE
NABORS LANDFILLS
MOUNT HOME, AR

DATE	TIME	LOCATION
06/21/2017	MATT	1111

Fiberglass Tank Solutions
2718 Normore Lane, Montpelier, VT 05659
☐ 873-371-9620

ITEM	QTY	DESCRIPTION	SERVICE	ELEV.	DEG.
A	1	18" SIDE MANWAY W/ COVER, EPDM GASKET & SS 316 BOLTS	MANWAY	3'-0" CL	270°
B	1	4" FLANGE NOZZLE W/ CONICAL GUSSETS	CONN. TANK 4	1'-8" CL	90°
C	1	4" FLANGE NOZZLE W/ CONICAL GUSSETS	CONN. TANK 1	1'-8" CL	180°
D	1	6" FLANGE NOZZLE	CLEAN OUT	1'-0" CL	45°
E	1	10" FIBERGLASS GOOSENECK VENT W/ BIRD SCREEN	VENT	TOP	CENTER
F	4	STEEL LIFTING LUGS	LIFTING LUG	SEE DWG	SEE DWG
G	6	STEEL HOLD DOWN LUGS	HOLD DOWN	SEE DWG	SEE DWG

[illegible]

L A S I O N O L L O A T O R S A N M A S R M N T S I O W N N O T A L L
 A N S N R A N R T N R N F S N N A I R O A L Y I S B A N
 A R M N E Y A T M I L L O S M O M L Y M A D P H M S T O M B

☐ A POULTRY NOISE


[illegible][illegible]

AN PRO-0000000000

REG-2	00	0000000000	TAN 3 LAN 11 W	CLOSURE OF INACTIVE NABORS LANDFILLS MOUNT HOME, AR	REG-2	06/21/2017	REVIEW BY MATT	06/28/2017	<input type="checkbox"/>
-------	----	------------	----------------	---	-------	------------	-------------------	------------	--------------------------



ITEM	QTY	DESCRIPTION	SERVICE	ELEV.	DEG.
A	1	18" SIDE MANWAY W/ COVER, EPDM GASKET & SS 316 BOLTS	MANWAY	3'-0" CL	90°
B	1	4" FLANGE NOZZLE W/ CONICAL GUSSETS	CONN. TANK 3	1'-8" CL	270°
C	1	4" FLANGE NOZZLE W/ CONICAL GUSSETS	CONN. TANK 2	1'-8" CL	180°
D	1	6" FLANGE NOZZLE	CLEAN OUT	1'-0" CL	315°
E	1	10" FIBERGLASS GOOSENECK VENT W/ BIRD SCREEN	VENT	TOP	CENTER
F	4	STEEL LIFTING LUGS	LIFTING LUG	SEE DWG	SEE DWG
G	6	STEEL HOLD DOWN LUGS	HOLD DOWN	SEE DWG	SEE DWG



00	0000000000	TAN	LAN	W
CLOSURE OF INACTIVE NABORS LANDFILLS MOUNT HOME, AR				
06/21/2017	06/21/2017	MATT		



Limited Warranty – Fiberglass Wet Wells

Fiberglass Tank Solutions, LLC (FTS) warrants to (Owner) that our underground wet well package, if installed, used and maintained in the United States in accordance with FTS published specifications, installation instructions and operating guidelines, all applicable laws and requirements, and the limited wet well applications defined herein, will be free from material defects in materials and workmanship for a period of one (1) year from date of original delivery by FTS. Wet well applications for the purpose of this warranty are limited to the collection and storage of water, wastewater or solids or liquid organic sewage at temperatures not to exceed 140 degrees F.

FTS warrants to the Owner that all wet well accessories, if installed, used and maintained in the United States in accordance with the FTS's' published specifications, installation instructions and operating guidelines, and all applicable laws and regulations, will be free from material defects in material and workmanship for a period of one (1) year following the date of original delivery by FTS.

The foregoing warranty does not extend to wet wells or accessories (collectively "Goods") damaged due to acts of God, war, terrorism, or failure of Goods caused, in whole or in part, by misuse, improper installation, storage, servicing, maintaining, or operation in excess of the rated capacity, contrary to their recommended use, or contrary to the wet well application defined above, whether intentional or otherwise, or any other cause or damage of any kind not the fault of FTS. FTS only warrants repairs or alternations performed by FTS or its authorized contractors.

Owner's sole and exclusive remedy for breach of warranty is limited at FTS's option to: (a) repair of the defective wet well or accessories, (b) delivery or replacement wet well or accessories to the point of original delivery, or (c) refund of the original purchase price of the whole or component in question. A claimant must give FTS the opportunity to observe and inspect the wet well and / or accessories prior to removal from the ground or the claim will be forever barred. All claims must be made in writing within one (1) year after wet well and /or accessory failure or be forever barred.

THE FOREGOING WARRANTY CONSTITUTES FTS'S EXCLUSIVE OBLIGATION AND FTS MAKES NO OTHER WARRANTY OR RERESENTAION, EXPRESS OR IMPLIED, WITH RESPECT TO THE WET WELL OR ANY SERVICE, ADVICE, OR CONSULTATION, IF ANY, FURNISHED TO THE OWNER BY FTS OR ITS REPRESENTATIVES, WHETHER AS TO MERCHANTABILITY, FITNESS FOR A PARTICULAR PRPOSE, OR OTHERWISE. THE SELLER (IBERGLASS TANK SOLUTIONS, LLC) UNDERTAKES NO RESPONSIBILITY FOR THE QUALITY OF THE GOODS, EXCEPT AS OTHERWISE PROVIDED IN THE CONTRACT. THE SELLER (FTS) ASSUMES NO RESPONSIBILITY THAT THE GOODS WILL BE FIT FOR ANY PARTICULAR PURPOSE FOR WHICH YOU (OWNER) MAY BE BUYING THESE GOODS, EXCEPT AS OTHERWISE PROVIDED IN THE CONTRACT. THE REMEDIES SET FORTH IN THE ABOVE WARRANTY ARE THE ONLY REMEDIES AVAILABLE TO ANY PERSON OR ENTITY FOR BREACH OF WARRANTY OR FOR THE BREACH OF ANY OTHER COVENANT, DUTY, OR OBLIGATION ON THE PART OF FTS. FTS SHALL HAVE NO LIABILITY OR

OBLIGATION TO ANY PERSON OR ENTITY FOR BREACH OF ANY OTHER COVENANT, DUTY, OR OBLIGATION UNDER THIS WARRANTY EXCEPT AS EXPRESSLY SET FORTH HEREIN. IT IS EXPRESSLY AGREED THAT THE WARRANTY DOES NOT FAIL OF ITS ESSENTIAL PURPOSE. FTS SHALL HAVE NO LIABILITY FOR COST OF INSTALLATION OR REMOVAL OF GOODS, ENVIRONMENTAL CONTAMINATIONS, FIRE, EXPLOSIONS, OR ANY OTHER CONSEQUENCES ALLEGEDLY ATTRIBUTABLE TO A BREACH OF WARRANTY OR INCIDENTAL CONSEQUENTIAL, PUNITIVE OR OTHER DAMAGES OF ANY DESCRIPTION, WHETHER ANY SUCH CLAIM OR DAMAGES BE BASED UPON WARRANTY, CONTRACT, NEGLIGENCE, STRICT LIABILITY OR OTHER TORT, OR OTHERWISE. IN NO EVENT SHALL FTS, INC.'S TOTAL LIABILITY HEREUNDER EXCEED THE ORIGINAL PURCHASE PRICE OF THE GOODS WHICH GAVE RISE TO SUCH LIABILITY.




278 Nomore Lane
Montreal, MO 65591
573-317-9620

PRECAST VAULT

SCURLOCK INDUSTRIES SHOP DRAWING

ASTM C-478



REINFORCEMENT

TOP: EQUIV. TO # 4 @ 5" O.C.E.W

WALLS: PER ASTM C-478

Scurlock Industries

of Springfield, Inc.

Box 1078 • 3401 W. Commercial

Springfield, MO 65801

417-862-5088 FAX 417-862-5090

CONTRACTOR:

**ADVANCED FLUID
TECHNOLOGIES**

PROJECT:

NABORS LANDFILL

DATE:


27 JUNE 17

STRUCTURE NO.:

VAULT

STATION NO.:


MANHOLE I.D. 48"



TOP: **13"**

RISER: **32"**

(2) SETTING
BLOCKS:



DIMENSIONS IN INCHES

UNLESS NOTED OTHERWISE


DRAWING NOT TO SCALE

FEATURES	YES	NO	DETAILS
HATCH(ES)	✓		ALUM. HATCH
			ALUM. HATCH BY CONTRACTOR
TOP:	✓		
SPECIAL			
BASE:			
ARCHES/SLEEVES	✓		
BOTTOM	✓		
EXTENDED BASE	✓		
JOINT MATERIAL	✓		
STEPS	✓		
SPECIAL	✓		SETTING BLOCKS

08-23-2016\\...MH\AIR RELEASE\PS\ASHI-VI

D-025 ST 150 PSI

D-025 STST 150 PSI



Combination Air Valve for Wastewater - Short Version

Description

The D-025 Combination Air Valve combines an air & vacuum component and an air release component in a single body. The valve is specifically designed to operate with liquids carrying solid particles such as wastewater and effluents. The combination air valve discharges air (gas) during the filling or charging of the system, admits air into the system during drainage and at water column separation and releases accumulated air (gas) from the system while it is operating under pressure. The valve's unique design enables the separation of the liquid from the sealing mechanism and assures optimum working conditions.

Applications

- Wastewater & water treatment plants.
- Wastewater and effluent water transmission lines.

Operation

The air & vacuum component discharges air at high flow rates during the filling of the system and admits air into the system at high flow rates during drainage and at water column separation.

High velocity air will not blow the float shut. Water will lift the float which activates the sealing of the valve.

At any time during system operation, should internal pressure of the system fall below atmospheric pressure, air will enter the system.

The smooth discharge of air reduces pressure surges and other destructive phenomena.

The intake of air in response to negative pressure protects the system from destructive vacuum conditions and prevents damage caused by water column separation. Air entry is essential to efficiently drain the system.

The air release component releases entrapped air in pressurized systems.

Without air valves, pockets of accumulated air may cause the following hydraulic disturbances:

- Restriction of effective flow due to a reduction of the flow area. In extreme cases this will cause complete flow stoppage.
- Obstruction of efficient hydraulic transmission due to air flow disturbances.
- Acceleration of cavitation damages.

- Increase in pressure transients and surges.
- Internal corrosion of pipes, fittings and accessories.
- Dangerous high-energy bursts of compressed air.
- Inaccuracies in flow metering.

As the system fills and is pressurized, the combination wastewater air valve functions in the following stages:

1. Air (gas) is discharged by the valve
2. When the liquid level reaches the valve's lower portion, the lower float is lifted, pushing the sealing mechanism to its sealing position.
3. The entrapped air is confined in a pocket between the liquid and the sealing mechanism. The air pressure is equal to the system pressure.
4. Increases in system pressure compress the trapped air in the upper section of the conical chamber. The conical shape assures the height of the air gap. This enables separation of the liquid from the sealing mechanism.
5. Entrapped air (gas), accumulating at peaks and along the system, rises to the top of the valve and displaces the liquid in the valve's body.
6. When the liquid level lowers to a point where the float is no longer buoyant, the float drops, unsealing the rolling seal. The air release orifice opens and allows part of the air that accumulated in the upper portion of the valve to be released to the atmosphere.
7. Liquid enters the valve. The float rises, pushing the rolling seal to its sealing position. The remaining air gap prevents the wastewater from fouling the mechanism.

When internal pressure falls below atmospheric pressure (negative pressure):

1. The floats will drop down, immediately opening the air & vacuum and air release orifices.
2. Air will enter into the system.

Main Features

- Working pressure range: 3 - 150 psi.
- Testing pressure: 360 bar.
- Maximum working temperature: 140° F.
- Maximum intermittent temperature: 194° F.
- The unique design of the valve prevents contact between the wastewater and the sealing mechanism by creating an air gap at the top of the valve. These features are achieved by:

- The conical body shape: designed to maintain the maximum distance between the liquid and the sealing mechanism and still obtain minimum body length.
 - Independent spring-guided linkage between the lower float/rod assembly and the upper float sealing mechanism: allows free movement of the float and rod. Vibrations and movement of the lower float due to turbulence will not unseat the upper float sealing mechanism.
 - The Rolling Seal Mechanism: less sensitive to pressure differentials than a direct float seal. It accomplishes this by having a comparably large orifice for a wide pressure range (up to 150 psi).
 - Funnel-shaped lower body: designed to ensure that residue wastewater matter will fall back into the system and be carried away by the main pipe.
- All inner metal parts made of stainless steel. Float made of composite materials.
 - 1 1/2" threaded discharge outlet enables connection of a vent pipe.
 - Dynamic design allows for high capacity air discharge while preventing premature closure.
 - The ball valve can be opened to release trapped pressure and drain the valve body prior to maintenance and for back-flushing during maintenance.

Valve Selection


- These valves are available in 2", 3" with a NPT male threaded connection or flanged 2", 3", 4", standard upon request.
- Valve is manufactured in stainless steel, also available in reinforced nylon.
- With a One-way, Out-only attachment, allows for air discharge only, prevents air intake.
- With a Vacuum Breaker, In-only attachment, allows for air intake only, prevents air discharge.
- With a Non-Slam discharge-throttling attachment, allows for free air intake, throttles air discharge.

Note

- The D-025 air valve is intended for use with raw wastewater. For use with aggressive liquids, please consult with our application engineers or with the marketing dept.
- For best suitability, it is recommended to send the fluid chemical properties along with the valve request.
- Upon ordering, please specify: model, size, working pressure, thread and flange standard and type of liquid.


D-025 Non-Slam Single Orifice Add-on Component Data Table

Inlet Size	Discharge Orifice	Total NS Area	NS Orifice	Switching Point	Flow at 5.8 psi
2", 3", 4"	1.5 Inch	0.02 Sq.In.	0.16 Inch	Spring loaded Normally closed	10.3 CFM




D-025-NS

AIR & VACUUM FLOWRATE



AIR RELEASE FLOWRATE




DIMENSIONS AND WEIGHTS


Inlet Size	Dimensions Inch		Connection C	Weight Lbs.		Orifice Area Sq.in	
	A	B		ST	STST	Air Rel.	A / V
2" Threaded	10.2	17.9	1½" NPT Female	31.7	31.7	0.018	1.246
2" Flanged	10.2	18.1	1½" NPT Female	35.7	35.7	0.018	1.246
3" Flanged	10.2	18.1	1½" NPT Female	-	-	0.018	1.246
4" Flanged	10.2	18.1	1½" NPT Female	40.5	40.5	0.018	1.246

PARTS LIST AND SPECIFICATION

No. Part	Material	
1. Camlock Connection	Polypropylene	
2. Rolling Seal Assembly	Polypropylene / Reinforced Nylon + E.P.D.M. + ST ST	
3. Float	Foamed Polypropylene	
4. Clamping Stem	Polypropylene / Reinforced Nylon	
5. Body	Reinforced Nylon / Stainless Steel SAE 316	
6. Domed Nut	Stainless Steel SAE 316	
7. O-Ring	BUNA-N	
8. Stopper	Polypropylene	
9. Spring	Stainless Steel SAE 316	
10. Washer	Stainless Steel SAE 316	
11. Stem	Stainless Steel SAE 316	
12. Body	Stainless Steel SAE 316	
13. Clamp	Stainless Steel SAE 316	
14. O-Ring	BUNA-N	
15. Float	Foamed Polypropylene	
16. Ball Valve 1/4 "	Stainless Steel	
17. Washer	Stainless Steel SAE 316	
18. Base	Stainless Steel SAE 316	




D-025 ST




A.R.I. USA, Inc. A.R.I. FLOW CONTROL ACCESSORIES Ltd. www.ariususa.com e-mail: ariususa@ari.co.il Tel: (559) 269-9653

A.R.I. FLOW CONTROL ACCESSORIES Ltd. reserves the right to make product changes without prior notice. To insure receiving updated information on parts specifications, please call the export dept. at the A.R.I. factory. A.R.I. FLOW CONTROL ACCESSORIES Ltd. shall not be held liable for any errors. All rights reserved.



SECTION B-B



Repl




Table 1: Common Size Combinations of Dual Containment Piping

Tabla 1: Combinaciones comunes de tamaños para tubería de doble contención


Nominal Size (in) Tamaño nominal	Carrier DR Transportador DR	Containment DR Contención DR	Carrier Pipe Tubería Transportador		Containment Pipe Tubería Contención		Approx. Support Spacing (in) Espacio de Soporte Aprox.	Weight (lbs/ft) Peso
			OD (in)	ID (in)	OD (in)	ID (in)		
1 x 3	11	11	1.315	1.047	3.5	2.826	34	1.6
1 x 4	11	11	1.315	1.047	4.5	3.633	34	2.5
	11	17	1.315	1.047	4.5	3.938	34	1.8
1½ x 4	11	11	1.900	1.533	4.5	3.633	34	2.7
	11	17	1.900	1.533	4.5	3.938	34	2.0
2 x 4	11	11	2.375	1.917	4.5	3.633	37	2.9
	11	17	2.375	1.917	4.5	3.938	37	2.2
2 x 6	11	11	2.375	1.917	6.625	5.349	37	5.6
	11	17	2.375	1.917	6.625	5.798	37	4.0
3 x 6	11	11	3.500	2.826	6.625	5.349	48	6.4
	11	17	3.500	2.826	6.625	5.798	48	4.7
4 x 8	11	11	4.500	3.633	8.625	6.963	53	10.7
	11	17	4.500	3.633	8.625	7.55	53	7.9
	17	17	4.500	3.938	8.625	7.55	48	7.2
6 x 10	11	11	6.625	5.349	10.75	8.679	60	18.1
	11	17	6.625	5.349	10.75	9.41	60	13.8
	11	32.5	6.625	5.349	10.75	10.049	60	10.8
	17	17	6.625	5.798	10.75	9.41	60	12.1
	17	32.5	6.625	5.798	10.75	10.049	60	9.2
8 x 12	11	11	8.625	6.963	12.75	10.293	68.5"	26.8
	11	17	8.625	6.963	12.75	11.16	68.5"	20.8
	17	17	8.625	7.550	12.75	11.16	60"	18.0
	17	32.5	8.625	7.550	12.75	11.919	60"	12.3

1. Pressure ranges from gravity flow to more than 200 psi
2. Carrier pipe sizes from 1" - 54" OD.
3. Containment pipe sizes from 3" - 63" OD.
4. Standard factory centralizer support spacing based upon limited deflection of carrier pipe.

1. La presión varía desde flujo por gravedad hasta más de 200 psi.
2. Tamaños del tubo transportador de 1 a 54 pulgadas de diámetro externo.
3. Tamaños del tubo de contención de 3 a 63 pulgadas de diámetro externo.
4. Espaciado estándar de fábrica del soporte centralizador en base a la deflexión límite de la tubería transportadora.

45° ELBOW

Codo De 45°




Nominal Size (in) Tamaño nominal	Carrier DR Transportador DR	Containment DR Contención DR	R (in)	H (in)	FC (in)
1 x 3	11	11	6.04	4.28	5
1 x 4	11	11, 17	6.04	4.07	5
1.5 x 4	11	11, 17	6.04	4.07	5
2 x 4	11	11, 17	6.04	4.07	5
2 x 6	11	11, 17	8.45	5.63	7
3 x 6	11	11, 17	8.45	5.63	7
4 x 8	11, 17	11, 17	9.96	6.21	8
6 x 10	11, 17	11, 17, 32.5	14.49	7.27	9.5
8 x 12	11, 17	11, 17, 32.5	16.9	7.36	10

45° LATERAL WYE




Y Lateral De 45°



Nominal Size (in) Tamaño nominal	Carrier DR Transportador DR	Containment DR Contención DR	L (in)	H (in)	FC (in)
2 x 4	11	11, 17	26.5	6.8125	20.4375
2 x 6	11	11, 17	35.5	7.75	29.25
3 x 6	11	11, 17	35.5	7.75	29.25
4 x 8	11, 17	11, 17	40	9.6875	32.1875
6 x 10	11, 17	11, 17	50.5	10.125	37.25
8 x 12	11, 17	11, 17	54.6	10.5625	38.0625

90° ELBOW

Codo De 90°



Nominal Size (in) Tamaño nominal	Carrier DR Transportador DR	Containment DR Contención DR	R (in)	H (in)	FC (in)
1 x 3	11	11	6.04	4.28	8.54
1 x 4	11	11, 17	6.04	4.07	8.54
1.5 x 4	11	11, 17	6.04	4.07	8.54
2 x 4	11	11, 17	6.04	4.07	8.54
2 x 6	11	11, 17	8.45	5.63	11.95
3 x 6	11	11, 17	8.45	5.63	11.95
4 x 8	11, 17	11, 17	9.96	6.21	13.83
6 x 10	11, 17	11, 17, 32.5	14.49	7.27	18
8 x 12	11, 17	11, 17, 32.5	16.9	7.36	19.9

DID YOU KNOW?


ISCO's Fusion Manual provides step-by-step instruction on how to operate McElroy Fusion equipment. It's printed in both English and Spanish and comes on waterproof, tear-proof paper to last longer in the elements of field work.

El manual de fusión de ISCO ofrece instrucciones detalladas sobre cómo operar el equipo de fusión McElroy. Está impreso en Inglés y Español y viene en el papel resistente al agua y a prueba de desgarros para que dure más tiempo en los elementos de trabajo en sitio.



END TERMINATION

Terminación De Extremo



Nominal Size (in) Tamaño nominal	Carrier DR Transportador DR	Containment DR Contención DR	L (in)	A (in)	B (in)
1 x 3	11	11	3	3.5	1.315
1 x 4	11	11, 17	3	4.5	1.315
1.5 x 4	11	11, 17	3	4.5	1.9
2 x 4	11	11, 17	3	4.5	2.375
2 x 6	11	11, 17	3	6.625	2.375
3 x 6	11	11, 17	3	6.625	3.5
4 x 8	11, 17	11, 17	4	8.625	4.5
6 x 10	11, 17	11, 17, 32.5	4	10.75	6.625
8 x 12	11, 17	11, 17, 32.5	4	12.75	8.62



**KEYS TO THE
FUTURE**


DID YOU KNOW?

In January 2013, ISCO announced its transition to an Employee Stock Ownership Plan (ESOP), handing the keys to the future to its dedicated employees.

En enero de 2013, ISCO anunció su transición a un Plan de Propiedad Participada de Empleados (ESOP), entregando las llaves del futuro a sus dedicados empleados.

90° ELBOW MOLDED

Codo De 90°
Moldeado



DR	17	11	9	7
Pressure Rating Resistencia a la Presión	125 psi	200 psi	250 psi	333 psi

Nominal Size (in) Tamaño nominal	A (in)	FC (in)
3/4	2.63	4
1	2.63	4
1 1/4	2.63	4
1 1/2	2.63	4
2	2.81	4.5
3	3	5.13
4	3	5.75
6	4.38	9
8	6	12
10	6	13.25
12	7.5	15.88

1. Some size/DR combinations may have limited availability.
2. Other DRs available with counter-bored ID at fitting end.

1. Algunos Tamaño / DR Combinaciones puede tener disponibilidad limitada.
2. Otros proyectos de resolución disponibles con receta aburrido identificación en final apropiado.

ISCO IN ACTION



Visit the link below to find out how ISCO provided delivery for fittings, saving the customer from delaying the project for months.


Servicio oportuno para el canal de riego de Utah - haga clic aquí para ver cómo ISCO ofreció entrega para accesorios, ayudando al cliente a no retrasar el proyecto por meses.

www.isco-pipe.com/CanalUT

BACK-UP RING - DUCTILE IRON FOR USE WITH FLANGE ADAPTER



Anillo De Respaldo- De Hierro Dúctil Para Uso Con El Adaptador De Brida



Nominal Size (in) Tamaño nominal	DR	Pressure Rating Resistencia a la Presión	Actual OD (in) DE Actual	OD (in)	BC (in)	BH (in)	T (in)	Bolt # Perno #
¾	7	335	1.05	3.88	2.75	0.625	0.5	4
1	7	335	1.315	4.25	3.13	0.625	0.56	4
1 ¼	7	335	1.66	4.63	3.5	0.625	0.63	4
1 ½	7	335	1.9	5	3.88	0.625	0.69	4
2	7	335	2.375	6	4.75	0.75	0.75	4
2	11	200	2.375	6	4.75	0.75	0.5	4
3	7	335	3.5	7.5	6	0.75	0.94	4
3	11	200	3.5	7.5	6	0.75	0.53	4
4	7	335	4.5	9	7.5	0.75	0.94	8
4	11	200	4.5	9	7.5	0.75	0.55	8
6	7	335	6.625	11	9.5	0.875	1	8
6	11	200	6.625	11	9.5	0.875	0.63	8
8	7	335	8.625	13.5	11.75	0.875	1.12	8
8	11	200	8.625	13.5	11.75	0.875	0.85	8
10	7	335	10.75	16	14.25	1	1.19	12
10	11	200	10.75	16	14.25	1	0.98	12
12	7	335	12.75	19	17	1	1.5	12
12	11	200	12.75	19	17	1	1.25	12
14	7	335	14	21	18.75	1.125	1.63	12
14	11	200	14	21	18.75	1.125	1.38	12
16	7	335	16	23.5	21.25	1.125	1.88	16
16	11	200	16	23.5	21.25	1.125	1.65	16
18	7	335	18	25	22.75	1.25	1.9	16
18	11	200	18	25	22.75	1.25	1.67	16
20	7	335	20	27.5	25	1.25	2.13	20
20	11	200	20	27.5	25	1.25	1.81	20
22	7	335	22	29.5	27.25	1.375	2.3	20
22	11	200	22	29.5	27.25	1.380	2	20
24	7	335	24	32	29.5	1.375	2.5	20
24	9	250	24	32	29.5	1.375	2.13	20
24	11	200	24	32	29.5	1.375	2.17	20


1. Standard surface treatment is painted primer. Optional surface treatments are available as galvanized, epoxy-coated, or powered-coated. Availabilities may be extended.

Nominal Size (in) Tamaño nominal	DR	Pressure Rating Resistencia a la Presión	Actual OD (in) DE Actual	OD (in)	BC (in)	BH (in)	T (in)	Bolt # Perno #
24	17	125	24	32.00	29.50	1.375	1.95	20
26	7	335	26	34.25	31.75	1.375	2.53	24
26	11	200	26	34.25	31.75	1.375	2.38	24
26	17	125	26	34.25	31.75	1.375	2	24
28	9	250	28	36.5	34	1.375	2.6	28
28	11	200	28	36.5	34	1.375	2.5	28
28	17	125	28	36.5	34	1.375	2.3	28
30	9	250	30	38.75	36	1.375	2.8	28
30	11	200	30	38.75	36	1.375	2.6	28
30	17	125	30	38.75	36	1.375	2.28	28
30	26	80	30	38.75	36	1.375	2.06	28
32	9	250	32	41.75	38.5	1.63	3	28
32	11	200	32	41.75	38.5	1.63	2.75	28
32	26	80	32	41.75	38.5	1.63	2.12	28
34	11	200	34	43.75	40.5	1.63	2.93	32
34	17	125	34	43.75	40.5	1.63	2.44	32
34	26	80	34	43.75	40.5	1.63	2.14	32
36	9	250	36	46	42.75	1.63	3.8	32
36	11	200	36	46	42.75	1.63	3.03	32
36	17	125	36	46	42.75	1.63	2.75	32
36	26	80	36	46	42.75	1.63	2.5	32
42	11	200	42	53	49.5	1.63	4.06	36
42	13.5	160	42	53	49.5	1.63	3.66	36
42	21	100	42	53	49.5	1.63	3	36
48	11	200	48	59.5	56	1.63	4.53	44
48	17	125	48	59.5	56	1.63	3.94	44
48	26	80	48	59.5	56	1.63	3.5	44
54	17	125	54	66.25	62.75	1.88	4	44
54	26	80	54	66.25	62.75	1.88	3.75	44
63	17	125	62.99	73	69.25	1.88	3.15	52
63	26	80	62.99	73	69.25	1.88	2.8	52

1. Tratamiento de la superficie Standard está pintado de imprimación. Tratamientos superficiales opcionales están disponibles como galvanizado, recubierta de polvo epoxi-recubiertos o. Disponibilidades podrán prorrogarse.

BLIND FLANGE HDPE AND PVC

Brida Ciega De HDPE Y PVC




Nominal Size (in) Tamaño nominal	Material materiales	OD (in)	BC (in)	BH (in)	T (in)	Bolt # Perno #
¾	HDPE, PVC	3.875	2.75	0.625	1	4
1	HDPE, PVC	4.25	3.13	0.625	1	4
1 ¼	HDPE, PVC	4.625	3.5	0.625	1	4
1 ½	HDPE, PVC	5	3.88	0.625	1	4
2	HDPE, PVC	6	4.75	0.75	1	4
3	HDPE, PVC	7.5	6	0.75	1	4
4	HDPE, PVC	9	7.5	0.75	1	8
6	HDPE, PVC	11	9.5	0.875	1	8
8	HDPE, PVC	13.5	11.75	0.875	1	8
10	HDPE, PVC	16	14.25	1	1	12
12	HDPE, PVC	19	17	1	1	12
14	HDPE, PVC	21	18.75	1.125	1	12
16	HDPE, PVC	23.5	21.25	1.125	1	16
18	HDPE, PVC	25	22.75	1.25	1	16
20	HDPE, PVC	27.5	25	1.25	1	20
22	HDPE, PVC	29.5	27.25	1.375	1	20
24	HDPE, PVC	32	29.5	1.375	1	20
26	HDPE	34.25	31.75	1.375	1	24
28	HDPE	36.5	34	1.375	1	28
30	HDPE, PVC	38.75	36	1.375	1	28
32	HDPE	41.750	38.5	1.625	1	28
36	HDPE, PVC	46	42.75	1.625	1	32
40	HDPE	50.75	47.25	1.625	1	36
42	HDPE	53	49.5	1.625	1	36
48	HDPE	59.5	56	1.625	1	44
54	HDPE	66.25	62.75	1.875	1.5	44
63	HDPE	73	69.25	1.875	1.5	52

1. Bolt circle for IPS Blind Flanges are the same for DIPS Blind Flanges 24" and smaller.
2. HDPE and PVC Blinds are not rated for full pressure above 6".
3. Steel Blinds may not be fully pressure rated above 10" depending on pipe (system) DR.

1. La circunferencia de los pernos en las bridas ciegas ips es que el de las bridas ciegas dips de 24 pulgadas o menos.
2. Las bridas ciegas de hdpe y pvc por encima de 6 pulgadas no están categorizadas para presión máxima.
3. Las bridas ciegas de acero puede que no estén categorizadas para presión total por encima de 10 pulgadas dependiendo del dr de la tubería (sistema)

FLANGE ADAPTER

Adaptador De Brida



DR	32.5	26	21	17	15.5	13.5	11	9	7
Pressure Rating Resistencia a la Presión	63 psi	80 psi	100 psi	125 psi	138 psi	160 psi	200 psi	250 psi	333 psi


Nominal Size (in) Tamaño nominal	Actual OD (in) DE Actual	D (in)	L (in)	7	9	11	13.5	15.5	17	21	26	32.5
				T (in)	T (in)	T (in)	T (in)	T (in)	T (in)	T (in)	T (in)	T (in)
¾	1.05	1.85	4.02	-	-	0.39	-	-	-	-	-	-
1	1.315	2.36	4.02	-	-	0.39	-	-	-	-	-	-
1 ¼	1.66	2.8	4.02	-	-	0.39	-	-	-	-	-	-
1 ½	1.9	3.15	4.02	-	-	0.39	-	-	-	-	-	-
2	2.375	4	6	0.45	0.45	0.402	0.402	0.402	0.402	0.402	0.402	0.402
3	3.5	5	6	0.625	0.625	0.598	0.598	0.598	0.598	0.598	0.598	0.598
4	4.5	6.598	6.8	1	1	0.8	0.8	0.8	0.8	0.8	0.8	0.8
6	6.625	8.5	8	1.2	1.2	0.799	0.799	0.799	0.799	0.799	0.799	0.799
8	8.625	10.598	9	1.625	1.625	1	1	1	1	1	1	1
10	10.75	12.799	10.75	2.299	1.5	1.299	1.299	1.299	1.28	0.902	0.902	0.902
12	12.75	15.252	11	2.598	1.875	1.54	1.5	1.5	1.54	1	1	1
14	14	17.5	11	3	2	1.701	1.701	1.701	1.625	1.098	1.098	1.098
16	16	20	12	3.858	2.25	1.902	1.902	1.902	1.875	1.201	1.201	1.201
18	18	21.098	12	3.63	2.5	2.1	2.1	2.1	2	1.25	1.25	1.25
20	20	23.5	12	3.938	3.49	2.3	2.3	2.3	2.27	1.39	1.39	1.39
22	22	25.6	12	4.36	3.92	2.5	2.5	2.5	2.5	1.52	1.52	1.52
24	24	27.9	14	4.643	4.36	2.9	2.9	2.9	2.75	1.667	1.667	1.667
26	26	29.75	14	-	4.643	2.955	2.955	2.955	2.955	1.711	1.711	1.711
28	28	32	14	-	5	3.182	3.182	3.182	3.182	1.842	1.842	1.842
30	30	34	14	-	5.357	3.409	3.409	3.409	3.409	1.974	1.974	1.974
32	32	36.125	14	-	5.714	3.636	3.636	3.636	3.636	2.105	2.105	2.105
34	34	38.125	14	-	6.071	3.864	3.864	3.864	3.864	2.237	2.237	2.237
36	36	40.5	14	-	6.429	4.091	4.091	4.091	4.091	2.368	2.368	2.368
42	42	47.125	21	-	-	4.772	4.773	4.773	4.773	2.763	2.763	2.763
48	48	53.5	21	-	-	5.455	5.455	5.455	5.455	3.158	3.158	3.158
54	54	59.625	21	-	-	-	-	-	-	3.553	3.553	3.553
63	62.99	66.79	21	-	-	-	-	-	-	4.145	4.145	4.145

TRANSITION FITTING

HDPE TO MALE THREADED METAL

Accesorio Transición HDPE A

Macho Roscado



DR	17	11	9	7
Pressure Rating Resistencia a la Presión	125 psi	200 psi	250 psi	333 psi

Nominal Size (in) Tamaño nominal	Actual OD (in) DE Actual	A (in)	B (in)	L (in)
1/2	0.840	1.6	6.4	8
3/4	1.050	1.8	6.2	8
1	1.315	2	4.25	6.25
1 1/4	1.660	2.5	6.75	9.25
1 1/2	1.900	2.5	6.75	9.25
2	2.375	3	6.25	9.25
3	3.500	4	5.25	9.25
4	4.500	4	5.25	9.25
6	6.625	5	7	12
8	8.625	7.0	8.0	15
10	10.750	8.0	8.0	16
12	12.750	9.0	9.0	18

1. Available in Brass, Carbon Steel (Epoxy Coated), 304 and 316 Stainless Steel
1. Disponible en bronce, acero al carbono recubierto con Epoxy y acero inoxidable 304 y 316.



ISCO ONLINE

AND ON-THE-GO

Find the resources you need by visiting isco-pipe.com on your desktop or mobile device.

ISCO en línea y en marcha: encuentre los recursos que necesita visitando isco-pipe.com en su dispositivo de escritorio o móvil.

www.isco-pipe.com

HDPE PIPE SIZES IPS PE3608 AND PE4710

Tamaños HDPE tuberías IPS PE3608 y PE4710

DR		11			13.5			15.5		
PE3608 Pressure Rating Resistencia a la Presión		160 psi			128 psi			110 psi		
PE4710 Pressure Rating Resistencia a la Presión		200 psi			160 psi			138 psi		
Nom. OD DE Nominal (in)	Actual OD DE Actual (in)	Min Wall Espesor Mini- mo de Pared (in)	Avg ID DI Promedio (in)	Weight Peso (lb/ft)	Min Wall Espesor Mini- mo de Pared (in)	Avg ID DI Promedio (in)	Weight Peso (lb/ft)	Min Wall Espesor Mini- mo de Pared (in)	Avg ID DI Promedio (in)	Weight Peso (lb/ft)
¾	1.05	0.095	0.848	0.13	---	---	---	---	---	---
1	1.32	0.12	1.062	0.2	---	---	---	---	---	---
1¼	1.66	0.151	1.34	0.314	---	---	---	---	---	---
1½	1.9	0.173	1.534	0.411	---	---	---	---	---	---
2	2.38	0.216	1.917	0.642	0.176	2.002	0.534	0.153	2.05	0.47
3	3.5	0.318	2.825	1.395	0.259	2.95	1.16	0.226	3.021	1.02
4	4.5	0.409	3.633	2.31	0.333	3.793	1.92	0.29	3.885	1.687
5	5.375	0.489	4.339	3.29	0.398	4.531	2.73	0.347	4.64	2.4
5	5.563	0.506	4.491	3.523	0.412	4.689	2.928	0.359	4.802	2.58
6	6.625	0.602	5.348	5	0.491	5.585	4.152	0.427	5.719	3.656
7	7.125	0.648	5.752	5.78	0.528	6.006	4.8	0.46	6.15	4.21
8	8.625	0.784	6.963	8.47	0.639	7.271	7.04	0.556	7.445	6.197
10	10.75	0.977	8.678	13.16	0.796	9.062	10.932	0.694	9.28	9.626
12	12.75	1.159	10.293	18.51	0.944	10.748	15.38	0.823	11.006	13.53
14	14	1.273	11.302	22.32	1.037	11.801	18.54	0.903	12.085	16.31
16	16	1.455	12.916	29.15	1.185	13.487	24.22	1.032	13.812	21.3
18	18	1.636	14.531	36.89	1.333	15.173	30.651	1.161	15.538	26.95
20	20	1.818	16.145	45.541	1.481	16.859	37.84	1.29	17.265	33.28
22	22	2	17.76	55.105	1.63	18.545	45.79	1.419	18.991	39.712
24	24	2.182	19.375	65.58	1.778	20.231	54.49	1.548	20.717	47.92
26	26	2.364	20.989	77.44	1.926	21.917	64.261	1.677	22.444	56.532
28	28	2.545	22.604	89.785	2.074	23.603	74.522	1.806	24.17	65.563
30	30	2.727	24.218	103.076	2.222	25.289	85.543	1.935	25.897	75.264
32	32	2.909	25.833	117.285	2.37	26.975	97.324	2.065	27.623	85.672
34	34	3.091	27.447	132.411	2.519	28.661	109.905	2.194	29.35	96.714
36	36	3.273	29.062	148.454	2.667	30.347	123.208	2.323	31.076	108.424
42	42	---	---	---	3.111	35.404	167.675	2.71	36.255	147.568
48	48	---	---	---	---	---	---	3.097	41.435	192.774
54	54	---	---	---	---	---	---	3.484	46.614	243.921
63	62.99	---	---	---	---	---	---	---	---	---
65	65	---	---	---	---	---	---	---	---	---

- Pressures are based on using water at 23°C (73°F).
- Average inside diameter calculated using nominal OD and minimum wall plus 6% for use in estimating fluid flows. Actual ID will vary.
- Other piping sizes or DR's may be available upon request.
- Standard Lengths:
 - 40' for 2"-24"
 - 50' for 26" and larger
 - Coils available for ¾ - 4" (6" by special order)

- Las presiones están basadas en el uso de agua a 23°C (73°F)
- El diámetro interno promedio calculado el diámetro externo nominal y la pared mínima más 6% para uso la estimación de flujos de fluidos. El diámetro interno real variará.
- Otros tamaños o DR de tubería pueden estar disponibles bajo pedido.
- Longitudes estándar
 - 40 pies para 2 - 24 pulgadas
 - 50 pies para 26 pulgadas o mayores
 - Bobinas disponibles para ¾ a 6 pulgadas (6 pulgadas para pedidos especiales)



WATER APPLICATION



LYALL-POLYTEC POLYETHYLENE BALL VALVES

California Office
2665 Research Dr.
Corona, CA 92882


Wisconsin Office
16875 West Ryerson Rd.
New Berlin, WI 53151

Customer Service
(800) 535-9255

RWLyall.com

Lyall Polytec Ball Valves provide high performance applications to the following areas:

- Water
- Agriculture
- Irrigation
- Sewer



No	Component	Material	Operating Feature
1	Body	Polyethylene	PE 4710 (PE100)
2	End	Polyethylene	PE 4710 (PE100)
3	Ball	Acetal/Polypropylene*	Excellent strength and thermal resistance
4	Retainer	Polypropylene	Positive seal under any condition. Retains seat under high differential pressure.
5	Ball Seat	Nitrile (NBR)	Reliable sealing from -20° F to 140° F
6	Stem	Acetal	Excellent durability and strength
7	Stem Seal	Nitrile (NBR)	Redundant sealing with dual O-rings
8	Weather Seal	Nitrile (NBR)	Protects from ground water and dirt.
9	Operator Nut	Polypropylene	2 inch (50mm) square or hexagon
10	Purge Connector	Polyethylene	Integral easy-purge connection


* 2 IPS (RP) valves and smaller = Acetal 2 IPS (FP) valves and larger = Polypropylene

Item	Operating Feature
Sizes	All standard 1/2 through 1-1/4 CTS and 1/2 through 16 IPS and 20 mm through 400 mm metric sizes
Design/Testing	ASME B16.40, AWWA C901, AWWA C906
Materials	High Density PE 4710
Operating Pressure (SDR 11)	200 PSI (PE4710)
Temperature	32° F to 140° F / 0° C to 60° C
Bore	Standard (Reduced) Port and Full Port
Pipe Connection	Butt Fusion, Socket Fusion, Electrofusion or LYCOFIT® Mechanical Fittings (up to 2 IPS)
Operation	90 degree operating standard (360° optional in 2 IPS ONLY)
Valve Boxes	Supported by all leading valve box manufacturers.

SMALL BODY PE VALVES



High Density PE 4710



CTS Valve Sizes and Dimensions (approx)

Nominal Valve Size	D inch/mm	L inch/mm	H inch/mm	C inch/mm	I inch/mm	Port	Cv	E inch/mm	Weight lbs/kg
1/2 CTS	0.625 / 15.9	11.50 / 292	5.12 / 130	3.70 / 94	1.06 / 27	Full	9	3.62 / 92	0.97 / 0.44
1 CTS	1.125 / 28.6	11.50 / 292	5.12 / 130	3.70 / 94	1.06 / 27	Full	36	3.62 / 92	1.01 / 0.46
1-1/4 CTS	1.375 / 34.9	11.50 / 292	5.12 / 130	3.70 / 94	1.06 / 27	Full	55	3.62 / 92	1.00 / 0.46

All CTS valve sizes are available in a full range of wall thicknesses. Contact your Lyall representative for available ISO and other metric sizes.

IPS Valve Sizes and Dimensions (approx)


Nominal Valve Size	D inch/mm	L inch/mm	H inch/mm	C inch/mm	I inch/mm	Port	Cv	E inch/mm	Weight lbs/kg
1/2 IPS / SDR 9.3	0.840 / 21.3	11.50 / 292	5.12 / 130	3.70 / 94	1.06 / 27	Full	20	3.62 / 92	0.97 / 0.44
3/4 IPS / SDR 11	1.050 / 26.7	11.50 / 292	5.12 / 130	3.70 / 94	1.06 / 27	Full	32	3.62 / 92	0.99 / 0.45
1 IPS / SDR 11	1.315 / 33.4	11.50 / 292	5.12 / 130	3.70 / 94	1.06 / 27	Full	50	3.62 / 92	1.01 / 0.46
1-1/4 IPS / SDR 11	1.660 / 42.1	11.50 / 292	5.12 / 130	3.70 / 94	1.06 / 27	Std	79	3.62 / 92	1.01 / 0.46
1-1/2 IPS / SDR 11	1.900 / 48.3	12.20 / 310	5.51 / 140	3.78 / 96	1.26 / 32	Std	104	2.80 / 71	1.80 / 0.80
2 IPS	2.375 / 60.3	12.20 / 310	5.51 / 140	3.78 / 96	1.38 / 35	Std	118	3.31 / 84	1.90 / 0.86

Where applicable, other SDR's are available upon request. Contact your Lyall representative for available ISO and other metric sizes.

LARGE BODY PE VALVES



High Density PE 4710



IPS Valve Sizes and Dimensions (approx)

Nominal Valve Size	D inch/mm	L inch/mm	H inch/mm	C inch/mm	I inch/mm	Port	Cv	E inch/mm	Weight lbs/kg
2 IPS / SDR 11	2.37 / 60.3	19.60 / 498	9.65 / 250	7.01 / 178	1.77 / 45	Full	164	6.69 / 170	4.19 / 1.90
3 IPS / SDR 11	3.50 / 88.9	21.29 / 541	12.00 / 305	8.50 / 216	2.52 / 64	Full	375	6.69 / 170	8.60 / 3.90
4 IPS / SDR 11	4.50 / 114.3	21.29 / 541	12.00 / 305	8.50 / 216	2.52 / 64	Std	407	6.69 / 170	9.70 / 4.40
4 IPS / SDR 11	4.50 / 114.3	24.02 / 610	14.92 / 381	10.39 / 264	3.58 / 91	Full	591	6.69 / 170	18.52 / 8.40
6 IPS / SDR 11	6.62 / 168.3	24.02 / 610	14.92 / 381	10.39 / 264	3.58 / 91	Std	854	6.69 / 170	22.27 / 10.1
6 IPS / SDR 11	6.62 / 168.3	26.18 / 665	18.94 / 485	13.03 / 331	4.80 / 122	Full	1280	6.69 / 170	38.36 / 17.4
8 IPS / SDR 11	8.62 / 219.1	30.12 / 765	24.80 / 630	16.57 / 421	6.69 / 170	Full	2146	6.69 / 170	91.49 / 41.5
10 IPS / SDR 11	10.75 / 273.0	30.12 / 765	24.80 / 630	16.57 / 421	7.95 / 202	Full	3074	6.69 / 170	97.22 / 44.1
12 IPS / SDR 11	12.75 / 323.8	30.12 / 765	24.80 / 630	16.57 / 421	7.95 / 202	Full	3645	6.69 / 170	100.75 / 75.70
14 IPS / SDR 11	14.00 / 355.6	35.83 / 910	31.18 / 805	19.33 / 491	11.38 / 289	Full	5736	6.69 / 170	248.02 / 112.5
16 IPS / SDR 11	16.00 / 406.4	35.86 / 910	31.18 / 805	19.33 / 491	11.38 / 289	Full	6559	6.69 / 170	256.40 / 116.3

Where applicable, other SDR's are available upon request. Contact your Lyall representative for available ISO and other metric sizes.

ADDITIONAL VALVE OPTIONS



Stem Extensions



Purge/Bypass Ports



**High Differential Bypass
(Standard in 12", 14" and 16" sizes)**



Factory Fused PE Pups



TRACKING & TRACEABILITY

Lyll has been a leader in the development and standardization of the Tracking & Traceability encoding system. In fact, in 2012 we began shipping gas pressure carrying components marked with the 16 character identifier as published in ASTM F2897. As such, all Lyll Polytec valves include a 2D-QR-Bar Code that when scanned with decoding software will provide:

- Manufacturer
- Manufacturer Lot Code
- Production Date
- Component Material
- Component Type
- Component Size



SUMMARY OF VALIDATION TESTING



Each valve is designed in accordance with AWWA C901 & 906 with guidance from ASME B16.40. Lyall, Polytec, and third party labs conduct testing under these specifications as well as other supplemental tests as follows:

SHELL TEST

Each valve is tested at both 4 PSIG and 1.5 x design pressure to verify the pressure boundary integrity of the valve shell.

SEAT TEST

Each valve seat (since the Lyall-Polytec valve is a bi-directional valve, both seats are tested) is tested at 4 PSIG and 1.5 x design pressure to verify the pressure containing ability of the valve closure and seat seals.

SUSTAINED PRESSURE VERIFICATION

Testing is conducted at a temperature of 176°F at 580 psi for 1,000 hours.

PRESSURE BOUNDARY VERIFICATION

This test is designed to verify the basic pressure boundary integrity of the valve shell. ASME B16.40 requires this test to be performed at 176°F for 1,000 hours.

CLOSURE VERIFICATION

This test is designed to verify the structural integrity and pressure retention capability of the valve closure element (ball). The valve is closed and the inlet pressurized at 1.1 x design pressure for 170 hours at 176°F or 1,000 hours at 100°F. The outlet is open to atmosphere.

TEMPERATURE RESISTANCE

This test is designed to verify that the valve will perform properly over the temperature range of -20° F to 140° F. The valve is first cooled to -20° F, operated against a differential pressure equal to the design pressure, and subjected to shell and seat leakage tests while at -20° F. The valve temperature is then raised to 140° F and the above process is repeated. In addition to operating properly and not leaking, the valve operating torque must not exceed specified limits at both temperatures.

FLOW TEST

This test is performed to verify that each valve design has at least the specified minimum flow capacity (Cv) in accordance with ASME B16.40.

Note: Cv values presented within this document are the typical values of Lyall-Polytec valves and are based upon the mathematical equation set forth by ASME B16.40. All Lyall-Polytec valves far exceed the minimum requirement set forth by ASME B16.40. Please contact your Lyall representative for a complete Test Data Package (TDP) that includes more detail on the testing that was performed.



In addition, the following tests were conducted to ensure that the product performance exceeds our customers' requirements.

IMPACT TEST

Each valve is subjected to impact testing at temperatures of 0° F and 100° F. A twenty pound weight with a special TUP is dropped from a height of three feet on the valve actuator, a total of five times. This test is performed at both temperatures. The valve must continue to operate properly and pass the basic valve shell and seat tests after the impacts.

TENSILE TEST

Each valve is subjected to a tensile test at loads which would create in the attached pipe either a 25% elongation or elongation equal to that caused by thermal expansion due to 100° temperature change. The valve must remain operable and not leak during or after this test.

CYCLE TEST

Each valve is tested for 1,000 cycles. The valves are opened each cycle against a 100 psig pressure differential. At the conclusion, each valve must pass the basic shell and seat tests.

Note: All Lyall-Polytec valves far exceed the minimum requirements set forth by ASME B16.40, AWWA C901 and AWWA C906. Please contact your Lyall representative for a complete Test Data Package (TDP) that includes more detail on the testing that was performed.



POLYTEC BALL VALVES for Water Application

- Meets or exceeds ASME B16.40, AWWA C901, AWWA C906
- Each valve includes material Tracking & Traceability coding per ASTM F2897.
- All product manufactured in an ISO 9001 certified facility.
- Maximized flow for optimal performance.
- Service rated to maximum allowable pressures.
- Precision manufacturing processes ensure lower operating torque.
- Bubble-tight seal throughout entire pressure and temperature range.
- Specially compounded nitrile seals (NBR) exceed industry standards.
- Valve body design provides resistance to mechanical and thermal loads making it the strongest part of a PE piping system.


California Office
2665 Research Dr.
Corona, CA 92882

Wisconsin Office
16875 West Ryerson Rd.
New Berlin, WI 53151

LIT-BVWATERDS-1116

Customer Service
(800) 535-9255

RWLyall.com



- Standard Overjacket
- Standard Metal Braid

CLT3-JT	CLT23-JT
CLT5-JT	CLT25-JT
CLT8-JT	CLT28-JT

- Stranded Copper Conductors
- Self Regulating Conductive Core
- Thermoplastic Elastomer Jacket

Description:

Nelson Type CLT self-regulating heater cable is a parallel circuit electric heater strip. An irradiation cross-linked conductive polymer core material is extruded over the multi-stranded, tin-plated, 18-gauge copper bus wires. The

conductive core material increases or decreases its heat output in response to temperature changes. A thermoplastic elastomer dielectric jacket is then extruded over the conductive core. A copper braid is installed over this jacket

providing a continuous ground path. A UV stabilized thermoplastic elastomer overjacket is provided to cover the braid for wet applications and exposure to the sun.

Principle of Operation:

The parallel bus wires apply voltage along the entire length of the heater cable. The conductive core provides an infinite number of parallel conductive paths permitting the cable to be cut to any length in the field with no dead or cold zones developing. The heater cable derives its self-regulating characteristic from the inherent properties of the conductive core material. As the core

material temperature increases, the number of conductive paths in the core material decrease, automatically decreasing the heat output. As the temperature decreases, the number of conductive paths increase, causing the heat output to increase. This occurs at every point along the length of the cable, adjusting the power output to the varying conditions along the pipe.

The self-regulating effect allows the cable to be overlapped without creating hot spots or burnout. As the cable self-regulates its heat output, it provides for the efficient use of electric power, producing heat only when and where it is needed, and also limiting the maximum surface temperature.

Application:

Nelson's Type CLT self-regulating heater cable is ideal for use in maintaining fluid flow under low ambient conditions. Freeze protection and low watt density process temperature systems such as pipelines, fire protection, process water, dust

suppression systems, hot water and structure anti-icing are typical applications for this product.

For other than metal pipe heating, see appropriate application guide.

The base product is supplied with a copper metal braid

with a thermoplastic elastomer overjacket for wet applications, exposure to the sun, and where mechanical abuse is a problem.

Performance and Rating Data:

Catalog Number	Service Voltage	Maximum Length	Maximum Maintenance Temperature	Maximum Intermittent Exposure
CLT3	120	221	150°F (65°C)	185°F (85°C)
CLT23	240	533	150°F (65°C)	185°F (85°C)
CLT5	120	178	150°F (65°C)	185°F (85°C)
CLT25	240	458	150°F (65°C)	185°F (85°C)
CLT8	120	142	150°F (65°C)	185°F (85°C)
CLT28	240	347	150°F (65°C)	185°F (85°C)


Circuit Breaker Selection:

Watt/Ft	Start-Up Temp.	Max. Length (Feet) Vs. Circuit Breaker Size					
		120 Volt			240 Volt		
		15A	20A	30A	15A	20A	30A
3	50°F (10°C)	221	---	---	533	---	---
	0°F (-18°C)	208	221	---	416	533	---
	-20°F (-29°C)	187	221	---	374	499	533
5	50°F (10°C)	178	---	---	413	458	---
	0°F (-18°C)	150	178	---	299	399	458
	-20°F (-29°C)	135	178	---	269	359	458
8	50°F (10°C)	142	---	---	289	347	---
	0°F (-18°C)	105	140	142	210	280	347
	-20°F (-29°C)	95	127	142	190	253	347

NOTES:

1. Circuit breakers are sized per national electrical codes.
2. When using 240 volt product at 208, 220 or 277 volts, use the circuit adjustment factors shown in the Voltage Adjustment Table.
3. When using 2 or more heater cables of different wattage ratings in parallel on a single circuit breaker, use the 15A column amperage of 15 amps, divide it by the maximum footage to arrive at an amps/foot figure for each cable. You can then calculate circuit breaker sizes for these combination loads. These amps/foot factors include the 125% sizing factor.
4. National electrical codes require ground-fault equipment protection for each branch circuit supplying electric heating equipment.

Power Output Rating:



**A CLT3
 CLT23**

**B CLT5
 CLT25**

**C CLT8
 CLT28**

WATTS PER FOOT X 3.28 = WATTS PER METER

PIPE TEMPERATURE °F CONVERSION TO °C = 5/9 (°F-32)

Catalog Numbers:

BASIC CATALOG NUMBERS			
Voltage	Watts Per Foot		
	3	5	8
120 VAC	CLT3	CLT5	CLT8
240 VAC	CLT23	CLT25	CLT28

Standard Feature Suffix:

-JT Copper Braid and Thermoplastic Elastomer Overjacket

Voltage Adjustment:

Use of products at other than nominal voltages requires minor adjustments in power and maximum circuit lengths.

ADJUSTMENT MULTIPLIER							
Product	208 VAC		220 VAC		277 VAC		Absolute Max Length
	Power	Length	Power	Length	Power	Length	
CLT23	.71	1.04	.81	1.02	1.34	.98	533 ft.
CLT25	.80	1.01	.87	1.00	1.22	1.02	458 ft.
CLT28	.87	1.00	.92	1.00	1.12	1.03	347 ft.

Approvals:

CSA
Ordinary Locations-



UL
Ordinary Locations-



Accessories:

- Connection Kits for Power Connection, Tee Splice, Splices and End Seals (Nelson PLT Series)
- Thermostatic Controls (Nelson TA, TH, TE and HC Series)
- Junction Boxes, Tapes and Warning Signs
- Custom Control, Monitoring and Power Panels

Nelson Heat Tracing Systems products are supplied with a limited warranty. Complete Terms and Conditions may be found on Nelson's website at www.nelsonheaters.com.

Lighted End of Circuit Termination Kit

CSA:

Class I, Division 2, Groups B, C, D
Class II, Groups E, F, G (Canada Only)
Class III (Canada Only)
Enclosure Type 4X, Temperature Code T6 ~ T3
Class 1 Zone 1; Ex e II; T6 ~ T3 ①

FM:

Class I, Division 2, Groups B, C, D
Class II, Groups E, F, G; Class III
Enclosure Type 4X, IP66, Temperature Code T ①
Class 1 Zone 1; AEx e IIC T
-40°C ≤ Tamb ≤ 55°C

Applications

- The HEL100 Lighted End of Circuit Termination Kit is designed for terminating one heater cable with a non-directional lens assembly and long life LED output
- Kits are used to connect and terminate Nelson self-regulating heater cable series LT-J, LT-JT, QLT-J, HLT-J, XLT-J and CLT-JT ②

Features


- Global-reach industrial-grade universal connection kits for Hazardous Locations
- Certified for NEC/CEC (AX Series) and IEC (EX Series) installations
- Incorporate rugged, non-metallic construction rated for IP66 / NEMA 4X
- Designed with corrosion resistant, antistatic enclosures and components
- Fit all wattages of Nelson LT-J, LT-JT, QLT-J, HLT-J, XLT-J and CLT-JT series self-regulating heater cables
- Min Installation Temp: -40°C (-40°F)
- Temp Use Range: -50°C to +55°C (-58°F to 131°F) ambient
- Conductor Size: 1 mm² (18 AWG) to 6 mm² (8 AWG)
- Voltage Range: 300 Vac Maximum
- Ingress Protection: NEMA 4X, IP66
- Max Amperage: 14 A CLT Series, 18 A LT, QLT, HLT Series, 25 A XLT Series
- Enclosure Material: Glass reinforced, carbon-loaded, polyester, UV resistant, polymer
- Weight: 0.4 kg (0.8 lb)

Accessories

- Pipe clamp to secure standoff to pipe (one is included in each kit):
 - PC03 – 80 mm (3 in) and smaller pipe
 - PC12 – 80 mm (3 in) to 12 inch (300 mm) pipe
 - PC20 – 300 mm (12 in) to 20 inch (500 mm) pipe
- Small pipe adaptor: HC-SPA – 25 mm (1.0 in) and smaller pipe

Ordering Information

- One kit should be ordered for each type of connection needed
- A pipe clamp of the appropriate size for the pipe must be selected (-3 for PC03, -12 for PC12, -20 for PC20) for each connection kit
- A small pipe adaptor kit must be ordered for each kit for installation on 25mm (1") or smaller pipe



① For temperature code, see heating cable or design information

② Ordinary Location Only

Lighted End of Circuit Termination Kit

CSA:

Class I, Division 2, Groups B, C, D
Class II, Groups E, F, G (Canada Only)
Class III (Canada Only)
Enclosure Type 4X, Temperature Code T6 – T3
Class 1 Zone 1; Ex e II; T6 – T3 ①

FM:

Class I, Division 2, Groups B, C, D
Class II, Groups E, F, G; Class III
Enclosure Type 4X, IP66, Temperature Code T ①
Class 1 Zone 1; AEx e IIC T
-40°C ≤ Tamb ≤ 55°C

Selection Table	
Kit Contents	HEL100
Lighted End Cap	1
Standoff	1
Silicone Power Termination Fitting	1
Silicone Adhesive	1
Cable Grommet	1
Locknut	1
Cable Tie	1

Micro-Lok® HP

High-Performance Fiber Glass Pipe Insulation

DESCRIPTION

Micro-Lok HP Fiber Glass Pipe Insulation is a high-performance insulation made from rotary glass fibers bonded with a thermosetting resin and produced in 36" (0.92 m) lengths. Micro-Lok HP insulation is used to insulate standard iron pipe and copper tubing. The 3' (0.92 m) sections are available plain or with a factory-applied vapor-barrier jacket. The all-service (ASJ) vapor-retarder jacket includes a longitudinal, self-sealing closure lap. The jacket system is adhered to each fiber glass section using a specially formulated adhesive to ensure jacket securement.

The factory-installed tape system permits installation at ambient temperatures down to 20°F (-7°C) and will not soften or separate when exposed to high ambient temperatures and humidity.

USES

Micro-Lok HP fiber glass pipe insulation is suitable for installation over hot, cold, concealed and exposed piping systems with operating temperatures up to 850°F (454°C). Weather-protective jacketing is required for outdoor applications. Pipes operating below ambient temperatures require all joints to be sealed with the factory-applied, self-seal lap and butt strips.


PHYSICAL PROPERTIES

Service Temp. Range (ASTM C411)	0°F to 850°F (-18°C to 454°C)
Moisture Sorption	<5% by weight
Alkalinity	<0.6% expressed as Na ₂ O
Corrosivity (ASTM C665)	Does not accelerate
Capillarity	Negligible (after 24 hours)
Shrinkage (ASTM C356)	None
Microbial Growth (ASTM C1338)	Does not promote microbial growth
Surface Burning Characteristics	Composite FHC 25/50 per ASTM E84, NFPA 255, CAN/ULC S102.2
Limited Combustibility	NFPA 90A and 90B
Jacketing	ASTM C1136 (Type I)
Water Vapor Permeance (ASTM E96 – Procedure A)	0.02 perms max.
Burst Strength (ASTM D774)	55 lbs/in ² (4.6 Kg/cm ²)
Tensile Strength (ASTM D828)	45 lbs./in. (7.9N/mm) width min. (MD) 30 lbs./in. (5.23N/mm) width min. (CD)


Operating Temperature Limits: 0°F to 850°F (-18°C to 454°C)

SPECIFICATION COMPLIANCE

- ASTM C547 Type I (Replaces HH-I-558B, Form D, Type III, Class 12, Class 13 up to 850°F [454°C])
- ASTM C585 – Dimension Standard
- ASTM C1136 (Jacketing) (Replaces HH-B-100B, Type I & II)
- MIL-I-22344D, MIL-PRF-22344E
- NRC 1.36, ASTM C795, MIL-I-24244C, MIL-DTL-24244D
- Coast Guard/IMO Approved 164.109/56/0 (plain, unjacketed only – excluding 7/8 x 1/2 [22 mm x 13 mm], 1/2 x 1/2 [13 mm x 13 mm])
- MEA compliant
- California Bureau of Home Furnishings and Thermal Insulation – Registry Number CA-T040 (CO)
- Firestop Assemblies: Meets requirement for jacketed fiber glass pipe insulation product density at or above 3.5 pcf.
- ASTM E84, CAN ULC S102.2 – 25/50 listed and labeled Intertek testing laboratories



THERMAL CONDUCTIVITY ("K") *



* Apparent thermal conductivity values are determined by applying procedures dictated per ASTM C1045 on test data obtained using ASTM Test Method C335. All values are based on nominal manufacturing and testing parameters, are subject to normal variation, and are not guaranteed for specification purposes or otherwise.

GREEN BUILDING ATTRIBUTES

Manufacturing Location	Defiance, Ohio (43512)	
Recycled Content (glass only)	41%	
Recycled Content (total product)	33%	
Volatile Organic Compounds (ASTM D5116)	Total	0.15 g/l
(Analysis ASTM D6196 & ASTM D5197)		
Fiber Glass Pipe Insulation	Formaldehyde	0.009 ppm
	Aldehydes	0.009 ppm
Volatile Organic Compounds (Calculated)	Total	<49 g/l
Self-Sealing Lap & Butt Strips		

GREEN BUILDING CERTIFICATIONS

GREENGUARD®	Certified
GREENGUARD® GOLD	Certified
LEED® Credits	
LEED-NC	
See JM.com/buildgreen JM LEED Credit Guide (HIG-1231)	

GREENGUARD® Certified products have been screened for more than 10,000 volatile organic compounds (VOCs) and meet stringent standards for low chemical emissions based on established criteria from key public health agencies.



Micro-Lok® HP

High-Performance Fiber Glass Pipe Insulation

SIZE AVAILABILITY

Insulation Thickness		Iron Pipe Size Range		Copper Tubing Size Range	
in.	mm	in.	mm	in.	mm
½	13	½-6	13-152	⅝-4⅝*	16-105
1	25	½-24	13-610	⅝-6⅝	16-156
1½	38	½-24	13-610	⅝-6⅝	16-156
2	51	½-24	13-610	1⅞-6⅝	29-156
2½	64	1-24	25-610	1⅞-6⅝	35-156
3	76	1-24	25-610	1⅞-6⅝	35-156
3½	89	1½-24*	38-610	—	—
4	102	3-24**	76-610	—	—
4½	114	3-24†	76-610	—	—
5	127	3-20††	76-508	—	—

Notes:

*2½" and 23" IPS not available in this insulation thickness.

**22" and 23" IPS not available in this insulation thickness.

†21", 22" and 23" IPS not available in this insulation thickness.

††19" IPS not available in this insulation thickness.

‡3½" CTS not available in this insulation thickness.

QUALIFICATIONS FOR USE

A sufficient thickness of insulation must be used to keep the maximum surface temperature of Micro-Lok HP insulation below 150°F (66°C). In addition, at operating temperatures above 500°F (260°C), Micro-Lok HP pipe insulation must be applied in a thickness ranging from 2" (51 mm) minimum to 6" (152 mm) maximum.

During initial heat-up to operating temperatures above 350°F (177°C), an acrid odor and some smoke may be given off as the organic binders used in the fiber glass pipe insulation begin to decompose. When this occurs, caution should be exercised to ventilate the area well. This loss of binder does not directly affect the thermal performance of the pipe insulation, but the compressive strength and resiliency of the product are reduced. For applications with excessive physical abuse or vibration at high temperatures, consult your local Insulation Systems Market Development Manager for alternate material recommendations.

CHILLED WATER SYSTEMS

For chilled water systems, see Chilled Water InsulSpec™ – 3-Part Specification, MECH-239.

APPLICATION RECOMMENDATIONS*

MICRO-LOK HP PIPE INSULATION AND BUTT STRIPS

1. Do not apply Micro-Lok HP insulation if air temperature is below 20°F (-7°C) or above 130°F (54°C) due to the effect of temperature on tape performance. We recommend stapling when application falls outside this temperature range.

When stapling, we recommend mastic be applied over staples to prevent moisture penetration.

2. If stored below 20°F (-7°C) or above 130°F (54°C), insulation cartons should stand within the recommended temperature range for 24 hours prior to application.

3. Once release paper is removed, both adhesive and lap must be kept free of dirt and water, and the lap sealed immediately.

4. When adhered, the lap and butt strips must be pressurized by rubbing firmly with a plastic squeegee or the back of a knife blade to ensure positive closure.

*For complete application recommendations and installation instructions, see MECH-238 and MECH-239 InsulSpec Specifications.



717 17th St.
Denver, CO 80202
800-654-3103
www.JM.com

North American Sales Offices, Insulation Systems

Eastern Region
P.O. Box 158
Defiance, OH 43512
(800) 334-2399
Fax: (419) 784-7866

Western Region & Canada
P.O. Box 5108
Denver, CO 80217
(800) 368-4431
Fax: (303) 978-4661

Technical specifications as shown in this literature are intended to be used as general guidelines only. Please refer to the Safety Data Sheet and product label prior to using this product. The physical and chemical properties of thermal insulation listed herein represent typical, average values obtained in accordance with accepted test methods and are subject to normal manufacturing variations. They are supplied as a technical service and are subject to change without notice. Any references to numerical flame spread or smoke developed ratings are not intended to reflect hazards presented by these or any other materials under actual fire conditions. Check with the Regional Sales Office nearest you for current information. All Johns Manville products are sold subject to Johns Manville's Limited Warranty and Limitation of Remedy. For a copy of the Johns Manville Limited Warranty and Limitation of Remedy or for information on other Johns Manville thermal insulation and systems, visit the Johns Manville website or call (800)654-3103.

SPECIFICATIONS

Aluminum Roll Jacketing is the premier protective outer surface for mechanical insulation systems including pipe, vessels, and equipment. It protects the insulation and underlying pipes/vessels from physical damage, UV exposure, corrosive atmospheres, and water.

Aluminum Roll Jacketing (also called cladding) is available in smooth, stucco embossed, and 3/16 corrugated (cross-crimped) finishes. For larger surfaces, box-rib and deep corrugated sheets are also available. Aluminum Roll Jacketing has a bare outer surface and comes standard with a 3 mil thick polyfilm moisture barrier heat-laminated to the interior surface to help prevent corrosion of the jacketing and the underlying metal pipe, vessel, or equipment.

Aluminum Roll Jacketing is typically manufactured using alloys 3105 or 3003 which have very similar composition and performance and are considered interchangeable for use as insulation jacketing. Both bare and polysurlyn lined Aluminum Roll Jacketing comply with the requirements of the ASTM Aluminum Jacketing Material standard, C1729, Type 1, which includes the strength and chemical composition requirements for compliance to ASTM B209 (Aluminum Alloy Standard).

Recommended Uses

Aluminum Roll Jacketing is recommended for use in all of the following Insulation system applications:

- Standard outdoor use on all pipe and vessel insulation systems up to 8 ft. outer diameter
- Indoor insulation system applications up to 8 ft. outer diameter where increased damage resistance is desired

Recommended Thicknesses

The thickness of Aluminum Roll Jacketing may vary based on the outer diameter of the insulation system per the requirements of ASTM C1729. This recommended thickness is shown in the table.

Outer Insulation Diameter (in)	Minimum Aluminum Jacket Thickness, inches (mm)	
	Rigid Insulation	Non-Rigid Insulation
≤ 8	.016 (0.4)	.016 (0.4)
Over 8 thru 11	.016 (0.4)	.020 (0.5)
Over 11 thru 24	.016 (0.4)	.024 (0.6)
Over 24 thru 36	.016 (0.4)	.032 (0.8)
> 36	.024 (0.6)	0.040 (1.0)



Available Surface Finishes:

- Stucco embossed
- Smooth

Compliance Standards:


- ASTM Aluminum Jacket standard C1729
- ASTM B209 (Aluminum Alloy Standard)

Installation & Operation Instructions

SERVICE REFERENCE

DIVISION 4	SECTION RT
SALES REFERENCE	PJ943
	168-562581-038
DATE	JANUARY, 2010

UAS Single Entry Power Connection Kit with integral thermostat for Self-Regulating & Constant Wattage Heating Cables



Description	Quantity
Junction box with Ambient Sensing Thermostat	1
Compression fitting	1
Washer for Thermostat	1
Locknut	1
Silicone termination boot	1
Pipe standoff	1
RTV	1
O-Ring	1
Self-regulating cable grommet	1
Constant wattage cable grommet	1

GENERAL

The UAS Single entry power connection kit/ with integral thermostat is used for electrical termination of selfregulating and constant wattage cables. Each kit contains the terminations needed to make all electrical connections.

INSTALLATION

⚠ WARNING

Hazard of Electric Shock. Disconnect all power before starting. All installations must be effectively grounded in accordance with the National Electrical Code to eliminate shock hazard.

⚠ WARNING


Turn off power before removing junction box cover at all times.

⚠ WARNING


Users should install adequate controls and safety devices with their electric heating equipment. Where the consequences of failure may be severe, back-up controls are essential. Although the safety of the installation is responsibility of the user, Chromalox will be glad to assist in making equipment recommendations.

Braid only cable instructions SRL-C, SRF-C, SRM/E-C
CWM-C cable special instructions denoted by *


1. For each cable, push braiding back from the end of the cable. 11 inches from cable end create a bulge. At the bulge, separate the braid to make an opening.




2. While bending the heating cable, work the cable through the braid opening. Pull the braid tight.




3. Insert cable through pipe standoff and grommet as shown. There should be 8 inches of cable past the grommet's edge. Attach the pipe standoff to the pipe with a pipe strap (Chromalox type PS not included) as shown. Leave braid of the cable outside of pipe standoff and connect to ground (grounding clamp not included). Tape cable pipe as shown. For pipes smaller than 1 1/2" diameter a small pipe adapter (Chromalox model SPA not included) is required.




4. Score the inner insulation 7 inches from the end. Lightly cut the inner jacket up the center to end of heating cable and remove the inner jacket from the cable.




5. Shave the core material from the outside of each bus wire. *Skip this step if using CWM-C constant wattage cable.




6. Starting at the end of the heating cable, using needle nose pliers or a knife, pull each bus wire away from the core material. *Separate CWM-C leads and strip 1/4" from each leadwire



7. Remove the exposed core material and cut 1/4" off the end of each bus wire. *Skip this step if using CWM-C constant wattage cable.



8. Liberally apply RTV over the exposed matrix and leads. Push the rubber boot over the heating cable. Trim lead ends as needed. *Boot is not needed when using CWM-C constant wattage cable.



INSTALLATION (cont'd.)

- Slide compression fitting over cable. Grommet should be placed inside pipe standoff. Termination boot should be spaced 1/2" from sealing grommet. Tighten compression fitting until it bottoms out against pipe standoff.




Figure 9

- Assemble junction box to compression fitting as shown. Tighten locknut until the junction box bottoms out against the lip of the compression fitting. To ensure that box is water tight make sure washer for thermostat is against the enclosure.




Figure 10

- Attach 3/4" conduit hub. Use a flat head screwdriver to release the terminal spring clamps and insert cable leads and grounding braid. Please see the electric diagrams below for proper wiring for your application. Attach junction box cover to seal enclosure.
Note: The conduit hub should be approved for Class 1, Div. 2; Class II Div. 1 & 2, Class III, Div. 1 & 2, and NEMA 4X rated by a nationally recognized testing laboratory.




Figure 11a




Figure 11b

Overjacketed cable instructions SRL-CR, SRL-CT, SRF-CR, SRM/E-CT CWM-CT cable instructions denoted by *

- and grommet as shown. 8 inches of cable should extend past the grommet. Attach the pipe standoff to the pipe with a pipe strap (Chromalox type PS not included) as shown. Attach extra cable to pipe as appropriate. For pipes smaller than 1 1/2" diameter optional small pipe adapter (Chromalox model SPA not included) is required.




Figure 12

- Score the outer insulation 7 inches from the end of the cable. Lightly cut the outer jacket up the center to the end of heating cable and remove the outer jacket from the cable. **WARNING: DO NOT CUT METAL BRAID.**




Figure 13

- Move braid back toward the overjacket, creating a bulge. At the bulge, separate the braid to make an opening.






Figure 14

INSTALLATION (cont'd.)


4. While bending the heating cable, work the cable through the braid opening. Pull the braid tight.




5. Score the inner insulation 6 inches from the end. Lightly cut the inner jacket up the center to end of heating cable and remove the inner jacket from the cable.




6. Shave the core material from the outside of each bus wire.
*Skip this step if using CWM-C constant wattage cable.




7. Starting at the end of the heating cable, using needle nose pliers or a knife pull each bus wire away from the core material.
*Separate CWM-C leads and strip 1/4" from each leadwire.




8. Remove the exposed core material and cut 1/4" of the end of each bus wire. *Skip this step if using CWM-C constant wattage cable.




9. Liberally apply RTV over the exposed matrix and leads. Push the rubber boot over the heating cable. Trim lead ends as needed. *Boot is not needed when using CWM-C constant wattage cable



10. Slide compression fitting over cable. Grommet should be placed inside pipe standoff. Termination boot should be spaced 1/2" from sealing grommet. Tighten compression fitting until it bottoms out against pipe standoff.





11. Assemble junction box to compression fitting as shown. Tighten locknut until the junction box bottoms out against the lip of the compression fitting. To ensure that box is water tight make sure washer for thermostat is against the enclosure.



INSTALLATION (cont'd.)

12. Attach 3/4" conduit hub. Use a flat head screwdriver to release the terminal spring clamps and insert cable leads and grounding braid. Please see the electric diagrams below for proper wiring for your application. Attach junction box cover to seal enclosure.

Note: The conduit hub should be approved for Class 1, Div. 2; Class II Div. 1 & 2, Class III, Div. 1 & 2, and NEMA 4X rated by a nationally recognized testing laboratory.



Limited Warranty:
Please refer to the Chromalox limited warranty applicable to this product at
<http://www.chromalox.com/customer-service/policies/termsofsale.aspx>.

Chromalox[®]
PRECISION HEAT AND CONTROL

1347 HEIL QUAKER BLVD., LAVERGNE, TN 37086
Phone: (615) 793-3900 www.chromalox.com



7801 Warden Road, Sherwood AR 72120
Phone: 501-835-3200
Fax: 501-835-3251
www.aftgrp.com

Installation Record at Startup

Project Job Number 9301601R Startup Date: 12/08/2017

Installer's Name Douglas Rogers AFT

Sump ID VLCS -1 Choose an item. Choose an item.

Side Slope Information:

Vertical Information:

Slope 1:1

Riser Diameter N/A Inches

Sump Diameter 63 Inches

Riser Length N/A Feet

Sump Depth 12 Feet

Vertical Depth N/A Feet

Pump & Motor Information:

Mfg unitra Model # UP-2507 S/N T2200008751-0790

GPM 25 @ 210 Ft. TDH

Motor Mfg Franklin Model 244508 S/N 17F14-29-03362C

Hp 1 Voltage 230 Phase 1 FLA 8.2

Motor Cable # of Conductors 3 Wire Size AWG 12 Length 14

Power Service Supply:

Breaker Size 30 Amp Wire Size AWG 6 Length 800 Ft

Incoming Voltage:

No Load L1-L2 248 L2-L3 X L1-L3 X % Unbalance —

Full Load L1-L2 248 L2-L3 X L1-L3 X

Full Load Amps L1 9 L2 9 L3 N/A % Unbalanced 0



7801 Warden Road, Sherwood AR 72120

Phone: 501-835-3200

Fax: 501-835-3251

www.aftgrp.com

Motor Run Amps: L1 7.8 L2 7.9 L3 N/A % Unbalanced .6%

Xducer/Float Information:

Xducer Mfg N/A Serial # N/A PSI Rating N/A

Float Mfg Connery Float 1 (NO) - NC (Circle One) Float 2 (NO) - NC (Circle One) Float 3 (NO) - NC (Circle One)

Control Panel:

MFG SJE Rhonbur Model # 112-1-W-1-1-1-2 Serial # N/A

Panel Style (Simplex) Duplex/Lead Lag (Circle One)

Set Points:

Pump On N/A Pump Off N/A POC N/A

Low Level N/A Sensor Fail N/A Xducer N/A

VFD Set Hz N/A Motor Starter Overload Setting N/A

Float 1 12 Inches Float 2 24 Inches Float 3 48 Inches

How to figure 3 Phase Unbalance % (Same For Volts)

EXAMPLE:

T1 = 51 amps

T2 = 46 amps

+ T3 = 53 amps

Total = 150 amps

$$\frac{150}{3} = 50 \text{ amps}$$

$$50 - 46 = 4 \text{ amps}$$

$$\frac{4}{50} = 0.08 \text{ or } 8\%$$



7801 Warden Road, Sherwood AR 72120
Phone: 501-835-3200
Fax: 501-835-3251
www.aftgrp.com

Installation Record at Startup

Project Job Number 9301601R Startup Date: 12/08/2017

Installer's Name Douglas Rogers

Sump ID VLGS-2 Choose an item. Choose an item.

Side Slope Information:

Vertical Information:

Slope 1:1

Riser Diameter N/A Inches

Sump Diameter 63 Inches

Riser Length N/A Feet

Sump Depth 12 Feet

Vertical Depth N/A Feet

Pump & Motor Information:

Mfg Univtra Model # UP2507 S/N 7220008751-0790

GPM 25 @ 210 Ft. TDH

Motor Mfg Franklin Model 244508 S/N 17E14-29-03362C

Hp 1 Voltage 230 Phase 1 FLA 8.2

Motor Cable # of Conductors 3 Wire Size AWG 12 Length 14

Power Service Supply:

Breaker Size 30 Amp Wire Size AWG #6 Length 325

Incoming Voltage:

No Load L1-L2 248 L2-L3 X L1-L3 X % Unbalance

Full Load L1-L2 248 L2-L3 X L1-L3 X

Full Load Amps L1 8.8 L2 8.8 L3 X % Unbalanced Ø



7801 Warden Road, Sherwood AR 72120
Phone: 501-835-3200
Fax: 501-835-3251
www.aftgrp.com

Motor Run Amps: L1 7.8 L2 7.8 L3 N/A % Unbalanced 0

Xducer/Float Information:

Xducer Mfg N/A Serial # N/A PSI Rating N/A

Float Mfg convey Float 1 NO - NC (Circle One) Float 2 NO - NC (Circle One) Float 3 NO - NC (Circle One)

Control Panel:

MFG STE Rhombus Model # 112-1-W-1-1-1-2 Serial # _____

Panel Style Simplex/Duplex/Lead Lag (Circle One)

Set Points:

Pump On N/A Pump Off N/A POC N/A

Low Level N/A Sensor Fail N/A Xducer N/A

VFD Set Hz N/A Motor Starter Overload Setting N/A

Float 1 12 Inches Float 2 24 Inches Float 3 48 Inches

How to figure 3 Phase Unbalance % (Same For Volts)

EXAMPLE:

$$\begin{array}{r} T1 = 51 \text{ amps} \\ T2 = 46 \text{ amps} \\ + T3 = 53 \text{ amps} \\ \hline \text{Total} = 150 \text{ amps} \end{array}$$

$$\frac{150}{3} = 50 \text{ amps}$$

$$50 - 46 = 4 \text{ amps}$$

$$\frac{4}{50} = 0.08 \text{ or } 8\%$$



7801 Warden Road, Sherwood AR 72120
Phone: 501-835-3200
Fax: 501-835-3251
www.aftgrp.com

Installation Record at Startup

Project Job Number 9301601R Startup Date: 12/8/2017

Installer's Name Douglas Rogers

Sump ID LCS-1 Choose an item. Choose an item.

Side Slope Information:

Slope 3:1

Riser Diameter 18" Inches

Riser Length 44 Feet

Vertical Depth 14.6 Feet

Vertical Information:

Sump Diameter _____ Inches

Sump Depth _____ Feet

Pump & Motor Information:

Mfg Unitra Model # up 2507 ~~T2200011794-~~ S/N T2200011794-0732

GPM 25 @ 210 Ft. TDH

Motor Mfg Franklin Model 17F14-30 S/N 17F14-30-07237C

Hp 1 Voltage 230 Phase 3 FLA _____

Motor Cable # of Conductors 4 Wire Size AWG 12 Length 45 ft

Power Service Supply:

Breaker Size 20 Amp Wire Size AWG #8 Length 150

Incoming Voltage:

No Load L1-L2 248 L2-L3 x L1-L3 x % Unbalance Φ

Full Load L1-L2 248 L2-L3 x L1-L3 x

Full Load Amps L1 6.4 L2 6.4 L3 x % Unbalanced Φ



7801 Warden Road, Sherwood AR 72120
Phone: 501-835-3200
Fax: 501-835-3251
www.aftgrp.com

Motor Run Amps: L1 3.5 L2 3.6 L3 3.6 % Unbalanced .1%

Xducer/Float Information:

Xducer Mfg Keller Serial # 160856 PSI Rating 10

Float Mfg N/A Float 1 NO – NC (Circle One) Float 2 NO – NC (Circle One) Float 3 NO – NC (Circle One)

Control Panel:

MFG AFT Model # WM-01A Serial # AFT-1A-201711-001

Panel Style Simplex/Duplex/Lead Lag (Circle One)

Set Points:

Pump On 12 Pump Off 24 POC 36

Low Level 6 Sensor Fail 276 Xducer 2

VFD Set Hz 50 Motor Starter Overload Setting _____

Float 1 N/A Inches Float 2 N/A Inches Float 3 N/A Inches

How to figure 3 Phase Unbalance % (Same For Volts)

EXAMPLE:

$$\begin{array}{r} T1 = 51 \text{ amps} \\ T2 = 46 \text{ amps} \\ + T3 = 53 \text{ amps} \\ \hline \text{Total} = 150 \text{ amps} \end{array}$$

$$\frac{150}{3} = 50 \text{ amps}$$

$$50 - 46 = 4 \text{ amps}$$

$$\frac{4}{50} = 0.08 \text{ or } 8\%$$



7801 Warden Road, Sherwood AR 72120
Phone: 501-835-3200
Fax: 501-835-3251
www.aftgrp.com

Installation Record at Startup

Project Job Number 9301601R Startup Date: 12/20/2017

Installer's Name Douglas Rogers AFT

Sump ID LCS-2 Choose an item. Choose an item.

Side Slope Information:

Slope 3:1

Riser Diameter 18" Inches

Riser Length 87 Feet

Vertical Depth 29 Feet

Vertical Information:

Sump Diameter _____ Inches

Sump Depth _____ Feet

Pump & Motor Information:

Mfg Unitra Model # UP-2507 S/N T2200011794-0733

GPM 25 @ 210 Ft. TDH

Motor Mfg Franklin Model 234534 S/N 17E14-30-02236C

Hp 1 Voltage 230 Phase 3 FLA 3.9

Motor Cable # of Conductors 4 Wire Size AWG 12 Length 90 Ft

Power Service Supply:

Breaker Size _____ Wire Size AWG _____ Length _____

Incoming Voltage;

No Load L1-L2 247 L2-L3 N/A L1-L3 N/A % Unbalance _____

Full Load L1-L2 247 L2-L3 N/A L1-L3 N/A

Full Load Amps L1 6.4 L2 6.3 L3 N/A % Unbalanced .7%



7801 Warden Road, Sherwood AR 72120
Phone: 501-835-3200
Fax: 501-835-3251
www.aftgrp.com

Motor Run Amps: L1 3.6 L2 3.5 L3 3.5 % Unbalanced .1%

Xducer/Float Information:

Xducer Mfg Keller Serial # 16080 PSI Rating 10

Float Mfg N/A Float 1 NO – NC (Circle One) Float 2 NO – NC (Circle One) Float 3 NO – NC (Circle One)

Control Panel:

MFG AFT Model # WM-1A Serial # AFT-1A-201711-002

Panel Style Simplex/Duplex/Lead Lag (Circle One)

Set Points:

Pump On 24 Pump Off 12 POC 36

Low Level 6 Sensor Fail 276 Xducer 2

VFD Set Hz 54 Motor Starter Overload Setting N/A

Float 1 N/A Inches Float 2 N/A Inches Float 3 N/A Inches

How to figure 3 Phase Unbalance % (Same For Volts)

EXAMPLE:

$$\begin{array}{r} T1 = 51 \text{ amps} \\ T2 = 46 \text{ amps} \\ + T3 = 53 \text{ amps} \\ \hline \text{Total} = 150 \text{ amps} \end{array}$$

$$\frac{150}{3} = 50 \text{ amps}$$

$$50 - 46 = 4 \text{ amps}$$

$$\frac{4}{50} = 0.08 \text{ or } 8\%$$



7801 Warden Road, Sherwood AR 72120
Phone: 501-835-3200
Fax: 501-835-3251
www.aftgrp.com

Installation Record at Startup

Project Job Number 9301601R Startup Date: 12/20/2017

Installer's Name Douglas Rogers AFT

Sump ID LCS-3 Choose an item. Choose an item.

Side Slope Information:

Vertical Information:

Slope 1:1

Riser Diameter 48 Inches

Sump Diameter _____ Inches

Riser Length 20 Feet

Sump Depth _____ Feet

Vertical Depth 12 Feet

Pump & Motor Information:

Mfg Unitra Model # UP-25-07 S/N T2200011794-0731

GPM 25 @ 210 Ft. TDH

Motor Mfg Franklin Model 234543 S/N 17E14-30-02257C

Hp 1 Voltage 230 Phase 3 FLA 3.9

Motor Cable # of Conductors 3 Wire Size AWG 12 Length 24 Ft

Power Service Supply:

Breaker Size 20 Wire Size AWG #10 Length 50

Incoming Voltage:

No Load L1-L2 249 L2-L3 X L1-L3 X % Unbalance _____

Full Load L1-L2 249 L2-L3 X L1-L3 X

Full Load Amps L1 6.5 L2 6.5 L3 X % Unbalanced Ø



7801 Warden Road, Sherwood AR 72120
Phone: 501-835-3200
Fax: 501-835-3251
www.aftgrp.com

Motor Run Amps: L1 3.5 L2 3.5 L3 3.5 % Unbalanced 0

Xducer/Float Information:

Xducer Mfg teller Serial # 160860 PSI Rating 10

Float Mfg N/A Float 1 NO – NC (Circle One) Float 2 NO – NC (Circle One) Float 3 NO – NC (Circle One)

Control Panel:

MFG AFT Model # WM-1A Serial # AFT-1A-201711-003

Panel Style Simplex/Duplex/Lead Lag (Circle One)

Set Points:

Pump On 24 Pump Off 32 POC 36

Low Level 6 Sensor Fail 276 Xducer 2

VFD Set Hz 55 Motor Starter Overload Setting N/A

Float 1 N/A Inches Float 2 N/A Inches Float 3 N/A Inches

How to figure 3 Phase Unbalance % (Same For Volts)

EXAMPLE:

$$\begin{array}{r} T1 = 51 \text{ amps} \\ T2 = 46 \text{ amps} \\ + T3 = 53 \text{ amps} \\ \hline \text{Total} = 150 \text{ amps} \end{array}$$

$$\frac{150}{3} = 50 \text{ amps}$$

$$50 - 46 = 4 \text{ amps}$$

$$\frac{4}{50} = 0.08 \text{ or } 8\%$$



7801 Warden Road, Sherwood AR 72120
Phone: 501-835-3200
Fax: 501-835-3251
www.aftgrp.com

Installation Record at Startup

Project Job Number 9301601R Startup Date: 1/23/2018

Installer's Name Douglas Rogers AFT

Sump ID LCS-4 Choose an item. Choose an item.

Side Slope Information:

Slope 3:1

Riser Diameter 18" Inches

Riser Length 35 Feet

Vertical Depth 11.6 Feet

Vertical Information:

Sump Diameter _____ Inches

Sump Depth _____ Feet

Pump & Motor Information:

Mfg unitra Model # up-2507 S/N T2200007115-1581

GPM 25 @ 210 Ft. TDH

Motor Mfg Franklin Model 234543 S/N 17E14-31-62490C

Hp 1 Voltage 230 Phase 3 FLA 3.9

Motor Cable # of Conductors 4 Wire Size AWG 12 Length 40

Power Service Supply:

Breaker Size 40 Wire Size AWG #6 Length 212

Incoming Voltage;

No Load L1-L2 248 L2-L3 X L1-L3 X % Unbalance _____

Full Load L1-L2 248 L2-L3 X L1-L3 X

Full Load Amps L1 6.6 L2 6.6 L3 X % Unbalanced 9



7801 Warden Road, Sherwood AR 72120
Phone: 501-835-3200
Fax: 501-835-3251
www.aftgrp.com

Motor Run Amps: L1 3.6 L2 3.6 L3 3.6 % Unbalanced Φ

Xducer/Float Information:

Xducer Mfg Keller Serial # 160824 PSI Rating 10

Float Mfg N/A Float 1 NO – NC (Circle One) Float 2 NO – NC (Circle One) Float 3 NO – NC (Circle One)

Control Panel:

MFG AFT Model # WM-1A Serial # AFT-1A-201711-004

Panel Style Simplex/Duplex/Lead Lag (Circle One)

Set Points:

Pump On 24 Pump Off 12 POC 36

Low Level 6 Sensor Fail 278 Xducer 2

VFD Set Hz 55 Motor Starter Overload Setting N/A

Float 1 N/A Inches Float 2 N/A Inches Float 3 N/A Inches

How to figure 3 Phase Unbalance % (Same For Volts)

EXAMPLE:

$$\begin{array}{r} T1 = 51 \text{ amps} \\ T2 = 46 \text{ amps} \\ + T3 = 53 \text{ amps} \\ \hline \text{Total} = 150 \text{ amps} \end{array}$$

$$\frac{150}{3} = 50 \text{ amps}$$

$$50 - 46 = 4 \text{ amps}$$

$$\frac{4}{50} = 0.08 \text{ or } 8\%$$



7801 Warden Road, Sherwood AR 72120
Phone: 501-835-3200
Fax: 501-835-3251
www.aftgrp.com

Installation Record at Startup

Project Job Number 9301601R Startup Date: 1/23/2018

Installer's Name Douglas Rogers AFT

Sump ID LCS-5 Choose an item. Choose an item.

Side Slope Information:

Slope 3:1

Riser Diameter 18 Inches

Riser Length 60 Feet

Vertical Depth 20 Feet

Vertical Information:

Sump Diameter _____ Inches

Sump Depth _____ Feet

Pump & Motor Information:

Mfg Unitra Model # up-2507 S/N T2200007115-1581

GPM 25 @ 210 Ft. TDH

Motor Mfg Franklin Model 234543 S/N 17E14-31-0248/C

Hp 1 Voltage 230 Phase 3 FLA 3.9

Motor Cable # of Conductors 4 Wire Size AWG 12 Length 65

Power Service Supply:

Breaker Size 40 Wire Size AWG 6 Length 545

Incoming Voltage:

No Load L1-L2 248 L2-L3 X L1-L3 X % Unbalance _____

Full Load L1-L2 248 L2-L3 X L1-L3 X

Full Load Amps L1 6.8 L2 6.8 L3 X % Unbalanced 0



7801 Warden Road, Sherwood AR 72120
Phone: 501-835-3200
Fax: 501-835-3251
www.aftgrp.com

Motor Run Amps: L1 3.5 L2 3.5 L3 3.5 % Unbalanced 0

Xducer/Float Information:

Xducer Mfg Keller Serial # 160843 PSI Rating 10

Float Mfg N/A Float 1 NO – NC (Circle One) Float 2 NO – NC (Circle One) Float 3 NO – NC (Circle One)

Control Panel:

MFG AFT Model # WM-1A Serial # AFT-1A-201711-005

Panel Style Simplex/Duplex/Lead Lag (Circle One)

Set Points:

Pump On 24 Pump Off 12 POC 36

Low Level 6 Sensor Fail 278 Xducer 2

VFD Set Hz 56 Motor Starter Overload Setting N/A

Float 1 N/A Inches Float 2 N/A Inches Float 3 N/A Inches

How to figure 3 Phase Unbalance % (Same For Volts)

EXAMPLE:

$$\begin{array}{r} T1 = 51 \text{ amps} \\ T2 = 46 \text{ amps} \\ + T3 = 53 \text{ amps} \\ \hline \text{Total} = 150 \text{ amps} \end{array}$$

$$\frac{150}{3} = 50 \text{ amps}$$

$$50 - 46 = 4 \text{ amps}$$

$$\frac{4}{50} = 0.08 \text{ or } 8\%$$



7801 Warden Road, Sherwood AR 72120
Phone: 501-835-3200
Fax: 501-835-3251
www.aftgrp.com

Installation Record at Startup

Project Job Number 9301601R Startup Date: 1/23/2018

Installer's Name Douglas Rogers

Sump ID LCS-6 Choose an item. Choose an item.

Side Slope Information:

Slope 3:1

Riser Diameter 18 Inches

Riser Length 50 Feet

Vertical Depth 16.8 Feet

Vertical Information:

Sump Diameter _____ Inches

Sump Depth _____ Feet

Pump & Motor Information:

Mfg Uniflow Model # UP-2507 S/N T2200007115-1573

GPM 25 @ 210 Ft. TDH

Motor Mfg Franklin Model 234543 S/N 17E14-30-02235C

Hp 1 Voltage 230 Phase 3 FLA 3.9

Motor Cable # of Conductors 4 Wire Size AWG 12 Length 55

Power Service Supply:

Breaker Size 50 Wire Size AWG 6 Length 736

Incoming Voltage:

No Load L1-L2 248 L2-L3 X L1-L3 X % Unbalance _____

Full Load L1-L2 248 L2-L3 X L1-L3 X

Full Load Amps L1 6.7 L2 6.7 L3 X % Unbalanced 0



7801 Warden Road, Sherwood AR 72120
Phone: 501-835-3200
Fax: 501-835-3251
www.aftgrp.com

Motor Run Amps: L1 3.6 L2 3.6 L3 3.6 % Unbalanced 0

Xducer/Float Information:

Xducer Mfg Keller Serial # 160857 PSI Rating 10

Float Mfg N/A Float 1 NO – NC (Circle One) Float 2 NO – NC (Circle One) Float 3 NO – NC (Circle One)

Control Panel:

MFG AFT Model # WM-1A Serial # AFT-1A-201711-006

Panel Style Simplex/Duplex/Lead Lag (Circle One)

Set Points:

Pump On 24 Pump Off 12 POC 36

Low Level 6 Sensor Fail 278 Xducer 2

VFD Set Hz 55 Motor Starter Overload Setting N/A

Float 1 N/A Inches Float 2 N/A Inches Float 3 N/A Inches

How to figure 3 Phase Unbalance % (Same For Volts)

EXAMPLE:

$$\begin{array}{r} T1 = 51 \text{ amps} \\ T2 = 46 \text{ amps} \\ + T3 = 53 \text{ amps} \\ \hline \text{Total} = 150 \text{ amps} \end{array}$$

$$\frac{150}{3} = 50 \text{ amps}$$

$$50 - 46 = 4 \text{ amps}$$

$$\frac{4}{50} = 0.08 \text{ or } 8\%$$



7801 Warden Road, Sherwood AR 72120
Phone: 501-835-3200
Fax: 501-835-3251
www.aftgrp.com

Installation Record at Startup

Project Job Number 9301601R Startup Date: 1/23/2018

Installer's Name Douglas Rogers AFT

Sump ID LGS-7 Choose an item. Choose an item.

Side Slope Information:

Slope 3:1

Riser Diameter 18 Inches

Riser Length 50 Feet

Vertical Depth 16.6 Feet

Vertical Information:

Sump Diameter _____ Inches

Sump Depth _____ Feet

Pump & Motor Information:

Mfg untra Model # up-2507 S/N T2200007115-1571

GPM 25 @ 210 Ft. TDH

Motor Mfg Franklin Model 234543 S/N 17E14-30-02244C

Hp 1 Voltage 230 Phase 3 FLA 3.9

Motor Cable # of Conductors 4 Wire Size AWG 12 Length 55

Power Service Supply:

Breaker Size 50 Wire Size AWG 6 Length 539

Incoming Voltage:

No Load L1-L2 248 L2-L3 X L1-L3 X % Unbalance _____

Full Load L1-L2 248 L2-L3 X L1-L3 X

Full Load Amps L1 6.7 L2 6.7 L3 X % Unbalanced Φ



7801 Warden Road, Sherwood AR 72120
Phone: 501-835-3200
Fax: 501-835-3251
www.aftgrp.com

Motor Run Amps: L1 3.5 L2 3.5 L3 3.5 % Unbalanced 0

Xducer/Float Information:

Xducer Mfg keller Serial # 160932 PSI Rating 10

Float Mfg N/A Float 1 NO – NC (Circle One) Float 2 NO – NC (Circle One) Float 3 NO – NC (Circle One)

Control Panel:

MFG AFT Model # WN-1A Serial # AFT-1A-201711-007

Panel Style Simplex/Duplex/Lead Lag
(Circle One)

Set Points:

Pump On 24 Pump Off 12 POC 36

Low Level 6 Sensor Fail 278 Xducer 2

VFD Set Hz 55 Motor Starter Overload Setting N/A

Float 1 N/A Inches Float 2 N/A Inches Float 3 N/A Inches

How to figure 3 Phase Unbalance % (Same For Volts)

EXAMPLE:

$$\begin{aligned} T1 &= 51 \text{ amps} \\ T2 &= 46 \text{ amps} \\ + T3 &= 53 \text{ amps} \\ \hline \text{Total} &= 150 \text{ amps} \end{aligned}$$

$$\frac{150}{3} = 50 \text{ amps}$$

$$50 - 46 = 4 \text{ amps}$$

$$\frac{4}{50} = 0.08 \text{ or } 8\%$$



7801 Warden Road, Sherwood AR 72120
Phone: 501-835-3200
Fax: 501-835-3251
www.aftgrp.com

Installation Record at Startup

Project Job Number 9301601R Startup Date: 1/22/2018

Installer's Name Douglas Rogers AFT

Sump ID LCS-8 Choose an item. Choose an item.

Side Slope Information:

Slope 3:1

Riser Diameter 18" Inches

Riser Length 60 Feet

Vertical Depth 20 Feet

Vertical Information:

Sump Diameter _____ Inches

Sump Depth _____ Feet

Pump & Motor Information:

Mfg unitra Model # up 2507 S/N T2200007115-1590

GPM 25 @ 210 Ft. TDH

Motor Mfg Franklin Model 234543 S/N 17E14-28-02430C

Hp 1 Voltage 230 Phase 3 FLA 3.9

Motor Cable # of Conductors 4 Wire Size AWG 12 Length 65

Power Service Supply:

Breaker Size 50 Wire Size AWG 6 Length 151

Incoming Voltage:

No Load L1-L2 248 L2-L3 X L1-L3 X % Unbalance

Full Load L1-L2 248 L2-L3 X L1-L3 X

Full Load Amps L1 6.7 L2 6.7 L3 _____ % Unbalanced _____



7801 Warden Road, Sherwood AR 72120
Phone: 501-835-3200
Fax: 501-835-3251
www.aftgrp.com

Motor Run Amps: L1 3.6 L2 3.6 L3 3.6 % Unbalanced 8

Xducer/Float Information:

Xducer Mfg Keller Serial # 161012 PSI Rating 16

Float Mfg N/A Float 1 NO – NC (Circle One) Float 2 NO – NC (Circle One) Float 3 NO – NC (Circle One)

Control Panel:

MFG AFT Model # WM-1A Serial # AFT-1A-201711-008

Panel Style Simplex/Duplex/Lead Lag (Circle One)

Set Points:

Pump On 24 Pump Off 12 POC 36

Low Level 6 Sensor Fail 278 Xducer 2

VFD Set Hz 55 Motor Starter Overload Setting N/A

Float 1 N/A Inches Float 2 N/A Inches Float 3 N/A Inches

How to figure 3 Phase Unbalance % (Same For Volts)

EXAMPLE:

$$\begin{array}{r} T1 = 51 \text{ amps} \\ T2 = 46 \text{ amps} \\ + T3 = 53 \text{ amps} \\ \hline \text{Total} = 150 \text{ amps} \end{array}$$

$$\frac{150}{3} = 50 \text{ amps}$$

$$50 - 46 = 4 \text{ amps}$$

$$\frac{4}{50} = 0.08 \text{ or } 8\%$$



7801 Warden Road, Sherwood AR 72120
Phone: 501-835-3200
Fax: 501-835-3251
www.aftgrp.com

Installation Record at Startup

Project Job Number 9301601R Startup Date: 1/22/2018

Installer's Name Douglas Rogers AFT

Sump ID LCS9 Choose an item. Choose an item.

Side Slope Information:

Slope 3:1

Riser Diameter 18" Inches

Riser Length 40 Feet

Vertical Depth 13.3 Feet

Vertical Information:

Sump Diameter _____ Inches

Sump Depth _____ Feet

Pump & Motor Information:

Mfg univtra Model # up 2509 S/N T2200008751-0788

GPM 25 @ 275 Ft. TDH

Motor Mfg Franklin Model 234514 S/N 11614-28-02213C

Hp 1.5 Voltage 230 Phase 3 FLA 5

Motor Cable # of Conductors 4 Wire Size AWG 12 Length 45

Power Service Supply:

Breaker Size 20 Wire Size AWG #10 Length 35

Incoming Voltage:

No Load L1-L2 248 L2-L3 X L1-L3 X % Unbalance —

Full Load L1-L2 248 L2-L3 X L1-L3 X

Full Load Amps L1 8.7 L2 8.7 L3 X % Unbalanced Φ



7801 Warden Road, Sherwood AR 72120
Phone: 501-835-3200
Fax: 501-835-3251
www.aftgrp.com

4.6
Motor Run Amps: L1 4.6 L2 4.6 L3 4.6 % Unbalanced 0

Xducer/Float Information:

Xducer Mfg Keller Serial # 160 845 PSI Rating 10

Float Mfg N/A Float 1 NO – NC (Circle One) Float 2 NO – NC (Circle One) Float 3 NO – NC (Circle One)

Control Panel:

MFG AFT Model # wn-1A Serial # AFT-1A-201711-009

Panel Style Simplex/Duplex/Lead Lag
(Circle One)

Set Points:

Pump On 24 Pump Off 12 POC 36

Low Level 6 Sensor Fail 276 Xducer 2

VFD Set Hz 55 Motor Starter Overload Setting N/A

Float 1 N/A Inches Float 2 N/A Inches Float 3 N/A Inches

How to figure 3 Phase Unbalance % (Same For Volts)

EXAMPLE:

T1 = 51 amps
T2 = 46 amps
+ T3 = 53 amps

Total = 150 amps

$\frac{150}{3} = 50$ amps

50 - 46 = 4 amps

$\frac{4}{50} = 0.08$ or 8%



CONSOLIDATED LAND SERVICES INCORPORATED

ENGINEERING
SURVEYING
MATERIALS TESTING
(501) 425-6161

2113 HIGHWAY 62 EAST
SUITE B
MOUNTAIN HOME, AR 72653
FAX (501) 424-3884

AIR TEST - SEWER

Project NABORS Landfills

No. _____

Date of Test _____

Line No. _____

Sta.	to Sta.	Pipe Diameter	Initial psig	Final psig	Elapsed Time
South LCS9 F.M. 0+00	to CAV 1 6+00	2" x 4" Dual Contained	9-27-17 100psi	99psi	Start 2:40 P.M. - End 3:40 P.M.
South CAV 1 F.M. 6+00	to CAV 2 10+00	2" x 4" Dual Contained	10-11-17 105psi	105psi	Start 11:27 A.M. - End 12:27 P.M.
South CAV 2 F.M. 10+00	to CAV 3 14+80	2" x 4" Dual Contained	10-12-17 100psi	96psi	Start 9:36 A.M. - End 11:53 A.M.
North VLCS 1 F.M. 0+00	to VLCS 2 6+60	2" x 4" Dual Contained	10-13-17 110psi	106psi	Start 12:42 P.M. - End 1:50 P.M.
North VLCS 2 F.M. 6+60	to CAV 10 8+85	2" x 4" Dual Contained	10-26-17 101psi	99psi	Start 8:25 A.M. - End 9:30 A.M.
North VLCS 1 F.M. 0+00	to Tank Farm ~13+54	2" x 4" Dual Contained	11-14-17 99psi	99psi	Start 11:21 A.M. - End 12:21 P.M.
West LCS 2 F.M. 0+00	to Tank Farm ~18+60	2" x 4" Dual Contained	12-13-17 96psi	95psi	Start 11:05 A.M. - End 12:05 P.M.
South LCS 9 F.M. 0+00	to Tank Farm ~	2" x 4" Dual Contained	12-20-17 100psi	100psi	Start 10:22 A.M. - End 11:22 A.M.

Except the Following Segments:

The above line meets or exceeds air exfiltration standards as required in the approved specifications for this job.

Contractor's Representative

City's Representative

City